BONUS 2 · CHECK THIS FIRST

Symptom Flowchart Four moves for any failed print, five suspects in order

1 Name the symptom. What you see, where, at what height. Several problems? Start with the one that happened first, lowest on the part.

2 Go back to a known starting point.

- An asterisk before the **Process** preset name means a changed value. Cannot say what? Click the reset arrow left of the dropdown.
- If the preset is one of your own (**User presets**), choose the matching one under **System presets** for the test.
- Check that each **Project Filaments** row names the spool that is on the printer.

Could the **plate** cause it?
Tile matches, washed
yes
no

Could the **filament** cause it?
Dry, right preset, feeding
yes
no

Could the **profile** cause it?
Unchanged preset; the setting the page names
yes
no

Could the **model** cause it?
Orientation, overhangs, thin parts
yes
no

Could the **machine** cause it?
Calibration, nozzle, wear parts, HMS message
yes

Check This First: before you suspect the machine, print with a clean plate of the type Studio expects, Bambu filament with its own preset, and an unchanged system preset. A problem that survives all three is worth reporting.

Skip a suspect that cannot cause the symptom. A clear sign moves one forward: a clicking extruder to the filament path (Chapter 11), a screen message to its code (Chapter 12).

3 Change ONE thing and write it down.
4 Test with a small print that still shows the symptom: the built-in **Cube** (right-click the plate > **Add Primitive**), two thin parts with a gap for stringing, or **Cut [C]** to print only the section near the trouble.

Fixed: keep the change, write it down.

Not fixed: undo it, then go to the next suspect.

Still failing after the machine? Ask for help on a forum or in a support ticket (Chapter 9, Asking for Help).

Symptom pages: what you see, where to look

What you see	Go to (Chapter 10 unless named)	Check this first
The first layer will not stick	**Chapter 4, Judge a First Layer in Ten Seconds**	The plate tile, then the two-minute wash
A corner peeled up, or the nozzle knocked the part off	**Lifts, Curls or Gets Knocked Off**	The plate tile names the plate on the bed; the plate is washed
Fine threads between parts or towers, up to a web	**Strings, Wisps and 'Cotton Candy'**	Is the spool dry? The plate plays no part in stringing
See-through walls, lines that do not touch, a thin feature missing	**Gaps, Thin Walls and Under-Extrusion**	Clicking or no flow at the toolhead means a clog (Chapter 11)
A nest of loose, curly plastic, or the print stops growing at one height	**Spaghetti and Prints That Fail Halfway**	What is left on the plate: a loose part, a tangle over an overhang, or stopped flow
Corners rise while the middle stays down; a crack between layers	**Warping and Cracked Layers**	Which material, on which printer? Not ABS or ASA on an open frame
A clean step sideways in the layers; faint waves after a sharp corner	**Shifted Layers, Waves and Ringing**	Speed mode changed during the print? Did anything hit the print?
Holes or a pillowed top, drooping overhangs, sagging bridges, zits	**Rough Tops, Saggy Overhangs and Messy Bridges**	Ctrl+L on **Prepare** for overhangs; top layers in **Preview**
A flared bottom edge, a part the wrong size, oval holes	**Parts That Do Not Fit: Elephant Foot and Size Errors**	Measure the part against the **Size** Studio shows