CTRL	VOL				(OUT	IN	
PI	DAL					MIDI		
I								
USB								
,	ITD /CL	10						
VIB/CHO			•					
V2		C2						
C1		V 3						
V1		С3						
LOW	VIB ON	ON	PERC SOFT	USSION FAST	THIRD	STOP	FAST	
ALT	PED. TO LOWER	PR. 1	PR. 2				REVERB OFF	
16" 8" VIB. SEL K.CLICK DRIVE REV. LEV								