

1.Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.

Ans. Steps to Test a USB Webcam

1. Connect it to a USB port on the computer.
2. Windows will usually install the driver automatically.
3. If the webcam does not work, install its driver.
4. Search for **Camera** in the Start menu.
5. You should see your face on the screen.
6. Click the **camera button**.
7. If the photo is clear, the webcam is working properly.

2.Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.

Ans. Steps to Set Up a Printer

1. Connect it to the computer using a **USB cable** or connect it to the same **Wi-Fi network**.
2. Make sure the printer has paper and ink/toner.
3. Install the correct printer driver if Windows does not install it automatically.
4. Go to **Settings → Devices → Printers & scanners → Add a printer**.
5. Choose your printer from the list and complete the setup.
6. Open the printer settings and select **Print Test Page**.
7. If the page prints correctly, the printer is ready to use.

3. Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem. Check for error icons and use the 'Scan for hardware changes' option after reconnecting.

Ans. Steps to Fix “Printer Not Detected”

1. Remove the USB cable from the computer.
2. Open **Device Manager** from the Start menu.
3. Check for a **yellow warning sign** near the printer or USB device.
4. Connect the USB cable again properly.
5. In Device Manager, click **Action** → **Scan for hardware changes**.
6. Windows should detect the printer again.
7. Try printing a test page to make sure it works.

4. A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications. Check if another app is using the webcam or if Zoom permissions are enabled.

Ans. Steps to Fix Webcam in Zoom

1. Close the Camera app and any other app that may be using the webcam.
2. Start Zoom and join a meeting.
3. Go to **Zoom** → **Settings** → **Video**.
4. Choose your webcam from the camera list.
5. Go to **Windows Settings** → **Privacy** → **Camera** and allow camera access.
6. Close Zoom completely and open it again.
7. Turn on the video in Zoom and check if your camera picture appears.