

Please read this Quick Start Guide to get up and running quickly. If you have any issues, refer to the "For More Information" section at the end of this guide.

I hank you for purchasing the Ember EM35x NCP Add-On Kit.

EM35x NCP Add-On Kit Quick Start Guide

ember

Enhancing Products through Connectivity

5. Changing the Adapter Properties

From InSight Desktop:

- A. Select the ISA3 connected to the EM35x NCP Breakout Board.
- **B.** Right-click on the adapter and select Adapter Properties.
- C. Select EM357-EZSP for radio processor.
- D. Select STM32F103RET host for host processor.
- **E.** Check Protect from automatic discovery changes.
- F. Click OK.

6. Running the First-Time Setup Wizard

- A. Launch ISD's First-Time Setup Wizard: click Start First-time Setup button or select Help | First-time setup wizard.
- B. Click Next and follow the on-screen instructions.
- C. Click Finish.


7. For More Information

Go to the Ember Developer Portal at http://portal.ember.com.

Copyright © 2010 Ember Corporation. All rights reserved. Ember is a registered trademark and the Ember logo and InSight are trademarks of Ember Corporation.

Place Hardware Identification List here

1. Unpacking the Contents



2. Before You Begin

 Make sure the EM35x Development Kit is set up and running properly. • Confirm that you have an internet connection.

3. Upgrading the Software



Launch Insight Desktop (ISD): Start | All Programs | Ember | InSight Desktop | InSight Desktop.



Update to the latest Ember software: Help | Update now. Click **OK** until prompted to restart. Then, restart ISD.




After restart, verify that ISD discovers the ISA3s. EM-ISA3-00, EM-ISA3-01, EM-ISA3-02 appear in the Adapters view | Default Group.

4. Connecting the Hardware



Replace one EM35x Development Kit Breakout Board with the EM35x NCP Breakout Board.

 On the EM35x Development Kit Board: disconnect ISP Cable from InSight Port and DEI Cable from DEI Port.



2. On the EM35x NCP Breakout Board: attach ISP Cable to InSight Port and DEI Cable to DEI Port.

