
Lesson 2 Call Action Group

MasterPi already has built-in action groups before delivery. The action groups are saved in "/home/pi/MasterPi/ActionGroups". You can view and call the built-in action group through PC software and the specific operation steps are as follow:

1. Operation Steps


- Please refer to the operation steps in file "1.Getting Ready/Lesson 3
 Deviation Adjustment/1.Set Environment Development" to install VNC and connect to Raspberry Pi system desktop
- 2) Double-click on system desktop, and then click "Execute" in pop-up prompt window to enter PC software, as the figure shown below:




3) Then, click "Open action file" and select the action group to be executed, then click "Open".

1






4) Now, action data list will display the servo value and running time of each action. (The screenshot shown below just display part of actions)



5) Click "Run" to perform all actions in action data list. If want to perform the current action group repeatedly, you can click "loop".




2. Import External Action Group

If want to call external action group, you can refer to the following operation steps. This section will import an action group "shake_hand.d6a" as example.

(The action group file must end in ".d6a")

 Insert a U disk with action file into any one of USB ports of Raspberry Pi, and then paste the action file to the system desktop, as the figure shown below:




2) Click and move the action file to the path "/home/pi/MasterPi/ActionGroups", as the figure shown below:



- 3) Then, double click and click execute to open PC software.
- Click "Open action file". Find the action group file to be imported and click "Open".

3





5) At this time, action data list will display the servo value and running time of each action.

