

```
const int LED_PIN = 13;

void setup() {
  pinMode(LED_PIN, OUTPUT);
}

void loop() {
  digitalWrite(LED_PIN, HIGH); // LED ON
  delay(1000);

  digitalWrite(LED_PIN, LOW);  // LED OFF
  delay(1000);
}
```

Basic PCB connection