Homework 4 ENERGY 293

Gabriel Buchsbaum

November 27, 2018

1 Equations

1.1 Electrical model




Figure 1: Equivalent circuit diagram (image from assignment)

From Kirchoff's current law:

$$I_{dlc} = I_f + I_d \tag{1}$$

From Kirchoff's voltage law:¹

$$V_{dlc} = V_{cf} - I_f R_f = V_{cd} - I_d R_d \tag{2}$$

From the defined behavior of a capacitor:

$$\dot{V}_{cf} = \frac{I_f}{C_f} \tag{3}$$

$$\dot{V}_{cd} = \frac{I_d}{C_d} \tag{4}$$

¹Using convention that positive current is discharging and negative current is charging. This is the convention implied by the circuit diagram and used in the temperature equations and example cycling plot, but is the opposite of the convention used in the equations from lecture notes.

Rearranging Equation 1:

$$I_f = I_{dlc} - I_d \tag{5}$$

Substituting Equation 5 into Equation 2:

$$V_{dlc} = V_{cf} - (I_{dlc} - I_d) R_f = V_{cd} - I_d R_d$$
(6)

Solving Equation 6 for I_d :

$$V_{cf} - I_{dlc}R_f + I_dR_f = V_{cd} - I_dR_d \tag{7}$$

$$I_d\left(R_f + R_d\right) = I_{dlc}R_f + V_{cd} - V_{cf} \tag{8}$$

$$I_d = \frac{I_{dlc}R_f + V_{cd} - V_{cf}}{R_f + R_d} \tag{9}$$

At each time instant, V_{cf} , V_{cd} , and I_{dlc} are known, and parameters R_f ., R_d , C_f , and C_d are given at the current temperature. Thus, the following process is used to determine \dot{V}_{cf} and \dot{V}_{cd} :

- 1. Calculate I_d using Equation 9
- 2. Calculate I_f using Equation 5
- 3. Calculate \dot{V}_{cf} and \dot{V}_{cd} using Equations 3 and 4

The combined equations are:

$$\dot{V}_{cf} = \frac{I_{dlc}R_d + V_{cf} - V_{cd}}{C_f R_f + C_f R_d} \tag{10}$$

$$\dot{V}_{cd} = \frac{I_{dlc}R_f + V_{cd} - V_{cf}}{C_dR_f + C_dR_d} \tag{11}$$

1.2 Thermal model

From the lecture slides:

$$\dot{Q}_{gen} = \begin{cases} i_{dlc}^2 R & i_{dlc} > 0\\ i_{dlc}^2 R - i_{dlc} v_{dlc} (1 - \eta) & i_{dlc} < 0 \end{cases}$$
 (12)

$$C_{th}\dot{T}_{dlc} + \frac{1}{R_{th}}T_{dlc} = \frac{1}{R_{th}}T_{air} + \dot{Q}_{gen}$$
(13)

For Equation 12, the value of v_{dlc} can be determined using Equation 2 and the current V_{cf} , V_{cd} , and I_{dlc} . Solving Equation 13 for \dot{T}_{dlc} :

$$\dot{T}_{dlc} = \frac{\frac{T_{air}}{R_{th}} + \dot{Q}_{gen} - \frac{T_{dlc}}{R_{th}}}{C_{th}} \tag{14}$$

Equations 12 and 14 can be combined into

$$\dot{T}_{dlc} = \begin{cases} \frac{\frac{T_{air}}{R_{th}} + i_{dlc}^2 R - \frac{T_{dlc}}{R_{th}}}{C_{th}} & i_{dlc} > 0\\ \frac{T_{clc}}{R_{th}} + i_{dlc}^2 R - i_{dlc} v_{dlc} (1 - \eta) - \frac{T_{dlc}}{R_{th}}}{C_{th}} & i_{dlc} < 0 \end{cases}$$
(15)

These two models can be solved simultaneously in the same ODE function. Since the ode45 solver provides the current values of V_{cf} , V_{cd} , and T_{dlc} , and can also use a given I_{dlc} and T_{air} , all that needs to be done is determine the values of the electrical parameters at the current T_{dlc} and return the results of Equations 10, 11, and 15

2 Matlab code

```
% Eliminate all extraneous variables and plots
clearvars
\% First run with air temperature of 0 C
Tair = 0;
% Set initial conditions
IC = [0, 0, Tair];
% Generate 50 seconds of rest before first cycle
Idlc = 0;
[t0, V0] = ode45(@(t, V)odefcn(t, V, Idlc, Tair), [-50, 0], IC);
I0 = zeros(length(t0),1);
% to, Vo, and IO refer to time, differential equation results, and
% current at 0 C. They are constantly added to in each cycle.
% Run 5 cycles
for i = 1:5
    \% Start with charging art of cycle
    Idlc = -100;
    % Use event function to stop when Vdlc reaches rated voltage.
    % The anonymous function @(t, V)event(t,V,Idlc) allows ode45
    \% to interpret using it as a function of t and \textbf{V}\text{,} while still
    % using Idlc to calculate Vdlc.
    options = odeset('Events',@(t, V)event(t,V,Idlc));
    % Gain initial conditions from end of VO
    IC = VO(length(t0),:);
    \% Run from last time value to arbitrary large time.
    % The event function should stop it well before this time.
    tRange = [max(t0), 1000000];
    % Run ode45 solver on this part of the cycle. The anonymous
    % function @(t,V)odefcn(t,V,Idlc,Tair) allows ode45 to interpret
    % the ODE function as a function of just t and V, while still
    % using the Idlc and Tair parameters.
    [t1,V1] = ode45(@(t,V)odefcn(t,V,Idlc,Tair), tRange, IC, options);
    % Store array of current values
    I1 = zeros(length(t1),1) + Idlc;
    \% Continue with first resting step
    Idlc = 0;
    % Initial conditions are from the end of charging
    IC = V1(length(t1),:);
    % Go from end of charging to 15 seconds past it
    tRange = [max(t1), max(t1)+15];
    [t2,V2] = ode45(@(t,V)odefcn(t,V,Idlc,Tair), tRange, IC);
    % Store array of current values
    I2 = zeros(length(t2),1);
    % Discharge step
    Idlc = 100;
    \% Refresh event function with new current
    options = odeset('Events', @(t, V) event(t, V, Idlc));
    % Initial conditions taken from end of rest
```

```
IC = V2(length(t2),:);
    % Run from end of rest to arbitrary large time.
    % The event function should stop it well before this time.
    tRange = [max(t2), 1000000];
    [t3,V3] = ode45(@(t,V)odefcn(t,V,Idlc,Tair), tRange, IC, options);
    % Store array of current values
    I3 = zeros(length(t3),1) + Idlc;
    % Second resting step
    Idlc = 0;
    % Initial conditions are from the end of discharging
    IC = V3(length(t3),:);
    \% Go from end of discharge to 15 seconds past it
    tRange = [max(t3), max(t3)+15];
    [t4, V4] = ode45(@(t, V)odefcn(t, V, Idlc, Tair), tRange, IC);
    % Store array of current values
    I4 = zeros(length(t4),1);
    \% Concatenate the results to the tO, VO, and IO arrays
    t0 = vertcat(t0, t1, t2, t3, t4);
    V0 = vertcat(V0, V1, V2, V3, V4);
    I0 = vertcat(I0, I1, I2, I3, I4);
end
% Go through each time value and calculate the Vdlc at that time
Vdlc0 = zeros(length(t1), 1);
for i = 1:length(t0)
    Vdlc0(i) = voltage(V0(i,:), I0(i));
end
% Repeat process with air temperature of 40 C
Tair = 40;
IC = [0, 0, Tair];
Idlc = 0;
[t40, V40] = ode45(@(t, V)odefcn(t, V, Idlc, Tair), [-50, 0], IC);
I40 = zeros(length(t40),1);
for i = 1:5
    Idlc = -100;
    options = odeset('Events', @(t, V) event(t, V, Idlc));
    IC = V40(length(t40),:);
    tRange = [max(t40), 1000000];
    [t1,V1] = ode45(@(t,V)odefcn(t,V,Idlc,Tair), tRange, IC, options);
    I1 = zeros(length(t1),1) + Idlc;
    Idlc = 0;
    IC = V1(length(t1),:);
    tRange = [max(t1), max(t1)+15];
    [t2, V2] = ode45(@(t, V)odefcn(t, V, Idlc, Tair), tRange, IC);
    I2 = zeros(length(t2),1);
    Idlc = 100;
    options = odeset('Events',@(t, V)event(t,V,Idlc));
```

```
IC = V2(length(t2),:);
    tRange = [max(t2), 1000000];
    [t3,V3] = ode45(@(t,V)odefcn(t,V,Idlc,Tair), tRange, IC, options);
    I3 = zeros(length(t3),1) + Idlc;
    Idlc = 0;
    IC = V3(length(t3),:);
    tRange = [max(t3), max(t3)+15];
    [t4, V4] = ode45(@(t, V)odefcn(t, V, Idlc, Tair), tRange, IC);
    I4 = zeros(length(t4),1);
    t40 = vertcat(t40, t1, t2, t3, t4);
    V40 = vertcat(V40, V1, V2, V3, V4);
    I40 = vertcat(I40, I1, I2, I3, I4);
end
Vdlc40 = zeros(length(t1), 1);
for i = 1:length(t40)
    Vdlc40(i) = voltage(V40(i,:), I40(i));
end
% Plot and save results
% Vdlc at 0 C
figure
yyaxis left
plot(t0, I0)
ylim([-160,160])
xlabel("Time (s)")
ylabel("Current (A)")
grid on
yyaxis right
plot(t0, Vdlc0)
ylim([-0.1,3.1])
ylabel("Voltage (V)")
saveas(gcf,'Vdlc_0.png')
% Voltage at 40 C
figure
yyaxis left
plot(t40, I40)
ylim([-160,160])
xlabel("Time (s)")
ylabel("Current (A)")
grid on
yyaxis right
plot(t40, Vdlc40)
ylim([-0.1,3.1])
ylabel("Voltage (V)")
saveas(gcf,'Vdlc_40.png')
% Temperature at 0 C
figure
yyaxis left
plot(t0, I0)
ylim([-160, 160])
xlabel("Time (s)")
```

```
ylabel("Current (A)")
grid on
yyaxis right
plot(t0, V0(:,3))
ylim([-0.4, 12.4])
ylabel("Temperature (C)")
saveas(gcf,'Tdlc_0.png')
% Temperature at 40 C
figure
yyaxis left
plot(t40, I40)
ylim([-160, 160])
xlabel("Time (s)")
ylabel("Current (A)")
grid on
yyaxis right
plot(t40, V40(:,3))
ylim([39.6, 52.4])
ylabel("Temperature (C)")
saveas(gcf,'Tdlc_40.png')
% ODE function to determine how Vcf, Vcd, and Tdlc change.
% It takes in a time value, an array containing the Vcf, Vcd,
% and Tdlc, Idlc, and Tair. It returns a vertical array showing
\% the derivatives of Vcf, Vcd, and Tdlc.
function dVdt = odefcn(t, V, Idlc, Tair)
Vcf = V(1);
Vcd = V(2);
Tdlc = V(3);
% Obtain electrical parameters at the current temperature
[Rd, Rf, Cd, Cf] = Eparams(Tdlc);
% Solve for Id and If
Id = (Idlc * Rf - Vcf + Vcd) / (Rd + Rf);
If = Idlc - Id;
% Solve for derivatives of Vcf and Vcd
dVcf = -If / Cf;
dVcd = -Id / Cd;
% Obtain temperature parameters
[R, eta, Rth, Cth] = Tparams;
% Determine heat generated
if Idlc >= 0 % if discharging
    Qgen = Idlc^2 * R;
else % if charging
    Qgen = Idlc^2 * R - Idlc * voltage(V, Idlc) * (1 - eta);
% Solve for derivative of temperature
dTdlc = (Tair / Rth + Qgen - Tdlc / Rth) / Cth;
% Place derivatives in vertical array to return
dVdt = [dVcf; dVcd; dTdlc];
% Event function to stop charge and discharge cycles
function [ev,s,dir] = event(t, V, Idlc)
% Determine Vdlc
```

```
Vdlc = voltage(V, Idlc);
\% Trigger when Vdlc is rated voltage or half rated voltage
ev = [Vdlc - 2.7; Vdlc - 1.35];
% Stop in both cases
s = [1; 1];
\% Only trigger when rising to 2.7V or falling to 1.35V
dir = [1; -1];
end
\% Function to calculate Vdlc with given Vcf, Vcd, and Idlc
function Vdlc = voltage(V, Idlc)
Vcf = V(1);
Vcd = V(2);
Tdlc = V(3);
\% Obtain electrical parameters at current temperature
[Rd, Rf, Cd, Cf] = Eparams(Tdlc);
% Split Idlc into Id and If
Id = (Idlc * Rf - Vcf + Vcd) / (Rd + Rf);
% Calculate Vdlc
Vdlc = -Id * Rd + Vcd;
end
% Function to determine electrical parameters at a given temperature
function [Rd, Rf, Cd, Cf] = Eparams(Tdlc)
% Take parameter values at each temperature and interpolate
Rd = interp1([-18, 25, 50], [0.238, 0.287, 0.226], Tdlc);
Rf = interp1([-18, 25, 50], [0.549, 0.533, 0.496], Tdlc)*10^-3;
Cd = interp1([-18, 25, 50], [64.3, 64.3, 112.1], Tdlc);
Cf = interp1([-18, 25, 50], [1355, 1368, 1481], Tdlc);
end
% Function to store temperature parameters (to keep in one location)
function [R, eta, Rth, Cth] = Tparams
R = 0.00047;
eta = 0.9;
Rth = 4.5;
Cth = 320;
end
```

3 Results




Figure 2: V_{dlc} under given cycling with T_{air} of 0 °C




Figure 3: T_{dlc} under given cycling with T_{air} of $0\,^{\circ}\mathrm{C}$




Figure 4: V_{dlc} under given cycling with T_{air} of 40 °C




Figure 5: T_{dlc} under given cycling with T_{air} of 40 °C

As Figures 2 and 4 show, the voltage change is effectively linear when charging and discharging the capacitor. When the capacitor is at rest, the voltage increases or decreases somewhat due to charge moving between C_f and C_d . There is a jump in voltage at the beginning and end of each phase caused by the amount of current flowing through R_f and R_d changing dramatically.

As Figures 3 and 5 show, the temperature always rises when the capacitor is charging or discharging, but rises faster when charging than discharging. The temperature decreases slightly towards toom temperature during resting periods, but not enough to overcome the increase during the rest of the cycle.

There is no particularly significant difference between the supercapacitor behavior at 0 °C and 40 °C. Voltage change is slightly slower at the higher temperature, but the difference is minimal. Also, the temperature rise is greater at the higher temperature, most likely due to the longer time that the supercapacitor is drawing current or having current drawn from it.