

Drive Systems — Course Notes

Printed version • Version: 27 September 2026

Where to write your answers: if you have access to a device, use the **online course notes** instead — you can type your answers into the answer panels and they are saved as you go. Otherwise, write your answers in your **jotter**, with the task and question number beside each answer.



Scan for the online
course notes

Section 1: Introduction to Mechanisms

Mechanisms are devices that **convert one motion or force into another**. They can be simple — like door handles, scissors and light switches — or complex, as used in industrial robots, cars and bikes.

Mechanisms play a vital role in industry. Most industrial processes have electronic control systems but rely on the movement of mechanisms to do work: pressing large steel sheets, lifting components and cutting material.

All mechanisms: involve motion • involve force • should make a job easier • need an input to work • produce an output.

Types of motion

There are four basic kinds of motion:



Rotary

Turning in a circle.

e.g. wheels, clock hands, gears



Linear

Movement in a straight line.

e.g. paper trimmer, lift moving between floors



Reciprocating

Backwards and forwards in a straight line.

e.g. sewing machine needle, car engine piston



Oscillating

Swinging backwards and forwards in an arc.

e.g. clock pendulum, playground swing

Task 1 — Types of motion

Copy the table into your jotter and tick the correct type(s) of motion for each activity.

Activity	Rotary	Linear	Reciprocating	Oscillating
Playground swing				
100m sprint				
Pedalling a bike				
Bungee jump				
Playground see-saw				
Curling stone				

List as many machines or tools from your school's practical rooms as you can for each type of motion.

Rotary:

Linear:


Reciprocating:

Oscillating:

Standard symbols for mechanisms


Engineers usually draw mechanisms using simple **standard symbols** rather than realistic pictures. Because everyone uses the same symbols (set out in British Standards), a drawing made by one engineer can be read correctly by any other engineer, anywhere, without extra explanation. Symbols are also much quicker to draw than a realistic sketch, they leave no doubt about which component is meant, and they make it easy to see how motion passes through a system.

In the exam you are much more likely to be asked to **read** a diagram drawn with these symbols, or **complete** one that is partly drawn, than to draw a whole system from memory.




Simple gear train

Two circles that **touch**: the gears mesh directly.



Belt drive

Two pulleys apart, joined by **solid** lines for the belt.



Chain drive

Two sprockets apart, joined by **dashed** lines for the chain.



Rack and pinion

A circle (pinion) touching a straight line (rack).

In each symbol the dot marks the shaft, which you are looking at end-on.

We will look at each of these drive systems in more detail in the following sections.

Friction in drive systems

Wherever parts of a drive system rub or slide against each other, there is **friction**. This happens where gear teeth mesh, where shafts turn in their bearings, and where a belt or chain wraps round a pulley or sprocket. Friction turns some of the energy put into the system into forms that are not useful, so **less energy reaches the output** than was put in.



Heat

Rubbing surfaces warm up. Some of the input energy is lost as heat.



Noise

Meshing teeth and running chains make sound, which is also wasted energy.




Wear

Surfaces slowly wear away, so teeth, belts and chains need replacing.



Lower efficiency

Less useful energy out means the system is less efficient.



You met **efficiency** in Energy and Efficiency: efficiency compares the useful energy out with the energy put in. The more friction there is in a drive system, the lower its efficiency.

Reducing friction: engineers **lubricate** gears and chains with oil or grease, support shafts in **bearings**, and keep parts clean and correctly lined up. This keeps parts cooler, makes them last longer and wastes less energy.

Friction is not always a problem. A belt drive **needs** friction between the belt and the pulleys to grip, which is why belts must be kept tight. If there is too little friction, the belt slips.

Section 2: Gears

Gears are **toothed wheels** designed to transmit rotary motion and power from one part of a mechanism to another. They are used to increase or decrease output speed, and can also change the direction of rotation. The most common type is the **spur gear**.

Real-life examples: The gearbox inside a cordless drill or electric screwdriver, a food mixer and a mechanical clock all use spur gears to change speed and direction.



Simple gear trains

When two or more gears mesh together they form a **gear train**. The input gear is called the **driver**; the output gear is called the **driven**. The teeth on the driver effectively push the teeth on the driven gear.

Meshing gears **rotate in opposite directions**. If the driver is clockwise, the driven is anticlockwise.



NoGrind Simulator — simple gear train

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

If gear A (driver) has 24 teeth and makes one full revolution, its 24 teeth pass the contact point. This pushes gear B around — and because gear B only has 12 teeth, it makes **two** complete revolutions for every one of gear A.

Gear equations

The data booklet gives this equation for drive systems:

$$\text{Input speed} \times \text{input size} = \text{output speed} \times \text{output size}$$

This is a universal equation that covers both gears and pulleys. When dealing with gears, lots of people find the ‘teeth times turns’ equation easier to use:

$$\text{Teeth}_{\text{In}} \times \text{Turns}_{\text{In}} = \text{Teeth}_{\text{Out}} \times \text{Turns}_{\text{Out}}$$

Turns can be revolutions per second (rev s^{-1}) or per minute (rev min^{-1})

This works because every tooth on the driver that passes the meshing point pushes one tooth on the driven gear past it. The number of teeth that pass must be the same for both gears.

WORKED EXAMPLE 1 — CALCULATE THE OUTPUT SPEED

A driver gear has 48 teeth and rotates at 10 rev s^{-1} . The driven gear has 20 teeth. Calculate its speed.

1 Write the equation: $\text{Teeth}_{\text{In}} \times \text{Turns}_{\text{In}} = \text{Teeth}_{\text{Out}} \times \text{Turns}_{\text{Out}}$

2 Substitute: $48 \times 10 = 20 \times T_{\text{Out}}$

3 Solve: $T_{\text{Out}} = \frac{48 \times 10}{20} = 24 \text{ rev s}^{-1}$

WORKED EXAMPLE 2 — CALCULATE THE NUMBER OF TEETH

A motor gear has 36 teeth and rotates at 380 rev s^{-1} clockwise. The driven gear rotates at 152 rev s^{-1} . How many teeth does the driven gear have?

1 $36 \times 380 = T_{\text{Out}} \times 152$

2 $T_{\text{Out}} = \frac{36 \times 380}{152} = 90 \text{ teeth}$

Task 2 — Simple gear train calculations

Calculate the missing quantity in each gear train. Build them in NoGrind to check your answers.

a) Driver: 45 teeth, 20 rev s⁻¹. Driven: 15 teeth. Calculate the output speed.

b) Driver: 12 teeth, 30 rev min⁻¹. Driven: 20 rev min⁻¹. Calculate the number of teeth on the driven gear.

Section 3: Velocity Ratio in Gears

The **velocity ratio (VR)** describes how much the speed changes between the driver and the driven gear. The data booklet gives it in terms of speed:

$$VR = \frac{\text{speed of input}}{\text{speed of output}}$$


From the data booklet.

For gears, VR can also be found from the number of teeth:

$$VR = \frac{\text{Teeth}_{\text{out}}}{\text{Teeth}_{\text{in}}}$$

The teeth version is the other way up from the speed version. A driven gear with **more** teeth turns **more slowly**, so VR is greater than 1.


WORKED EXAMPLE 1 — SPEED INCREASE (VR < 1)



Gear A: 24 teeth (driver). Gear B: 12 teeth (driven).

- 1 $VR = \frac{\text{Teeth}_{\text{Out}}}{\text{Teeth}_{\text{In}}} = \frac{12}{24} = 0.5 \text{ (or 1:2)}$
- 2 If gear A rotates at 90 rev min^{-1} CW, gear B rotates at 180 rev min^{-1} ACW.

WORKED EXAMPLE 2 — SPEED DECREASE (VR > 1)



Gear A: 8 teeth (driver). Gear B: 24 teeth (driven).

- 1 $VR = \frac{24}{8} = 3 \text{ (or 3:1)}$
- 2 If gear A rotates at 90 rev min^{-1} CW, gear B rotates at 30 rev min^{-1} ACW.

Task 3 — Velocity ratio calculations

For each gear train, calculate the missing value and the velocity ratio.

- a) Driver: 28 teeth, $1000 \text{ rev min}^{-1}$. Driven: 54 teeth. Calculate the output speed and VR.

- b) Driver: 112 teeth, 12 rev s^{-1} . Driven: 96 rev s^{-1} . Calculate the number of teeth and VR.

- c) Driver: 32 teeth, speed unknown. Driven: 74 teeth, 240 rev min^{-1} . Calculate the driver speed and VR.

- d) Driver: 75 rev s^{-1} , teeth unknown. Driven: 280 rev s^{-1} , 60 teeth. Calculate the number of driver teeth and VR.

- e) It is sometimes necessary to get a change in speed without changing the direction of the driven gear. How do you think this can be done?



NoGrind Simulator — simple and idler gear trains

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

Investigation — Simple gear train challenge

Using the NoGrind simulator with gears of approximately 8, 16, 24 and 40 teeth:

1. Build a simple gear train that **increases** the speed of the driven gear. Record the gear sizes you used and calculate the VR.

2. Build a simple gear train that **decreases** the speed. Record the gear sizes and VR.


3. Note the direction of the driver and driven gears. What do you notice? How does adding more gears affect direction?

Section 4: Idler Gears

To make the driven gear rotate in the **same direction** as the driver, a third gear — called an **idler gear** — is inserted between them.

The idler gear has **no effect on the velocity ratio** of the system. It only changes the direction of the output. The size of the idler does not matter.

Real-life example: Idler gears are commonly found in printing presses, where multiple rollers must all turn in the same direction to feed paper through correctly.




In the diagram above, gears A and C rotate in the **same direction**. The VR is still calculated from driver A to driven C only


— the idler is ignored: $VR = \frac{12}{24} = 0.5$.

Task 4 — Idler gear calculations

a) Gear A: 28 teeth, $1000 \text{ rev min}^{-1}$. Gear B (idler): 10 teeth. Gear C: 54 teeth. Calculate the VR and the speed of C.



b) Gear A: 120 teeth, 30 rev s^{-1} . Gear B (idler): 24 teeth. Gear C: 40 teeth. Calculate the VR and speed of C.



Section 5: Compound Gear Trains



Simple gear trains are limited in the velocity ratio they can produce — very large or very small speed changes require impractically large gears. A **compound gear train** solves this by mounting pairs of gears on the same shaft (the **intermediate shaft**), multiplying the gearing effect in a much smaller space.

In a compound gear train, two gears on the same intermediate shaft rotate together at the same speed. The total VR is found by **multiplying the individual VRs**.

Real-life examples: Compound gear trains are found in car gearboxes, mechanical clocks, and hand-powered food whisks — anywhere a large speed change is needed in a small space.

Real-life examples

Compound gear train diagram



Calculating compound gear VR

WORKED EXAMPLE — COMPOUND GEAR TRAIN

Input gear: 20 teeth. Large gear on intermediate shaft: 80 teeth. Small gear on intermediate shaft: 10 teeth. Output gear: 60 teeth. Input speed: 240 rev s^{-1} .

- 1 **VR of first pair:** $VR_1 = \frac{80}{20} = 4$
- 2 **VR of second pair:** $VR_2 = \frac{60}{10} = 6$
- 3 **Total VR:** $VR_{\text{total}} = VR_1 \times VR_2 = 4 \times 6 = 24$
- 4 **Output speed:** $\text{Speed}_{\text{Out}} = \frac{\text{Speed}_{\text{In}}}{VR} = \frac{240}{24} = 10 \text{ rev s}^{-1}$




NoGrind Simulator — compound gear train

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

Task 5 — Compound gear calculations

A compound gear train is driven by a motor at 1000 rev/min. Gear A = 20 teeth, Gear B = 60 teeth (on intermediate shaft with A), Gear C = 40 teeth, Gear D = 50 teeth (output).




- Calculate the total velocity ratio.
- Calculate the output speed.

Using the NoGrind simulator, build a compound gear train using gears of 8, 16, 24 and 40 teeth that produces the greatest possible speed increase. Calculate the VR of your system.

Section 6: Worm and Wheel


 **Interesting — but not examined:** This section does not appear in the N5 course specification or QS exams. It gives useful real-world context but you do not need to learn it for assessment.

A **worm gear** is another way to achieve large speed reductions. The worm looks like a screw thread and is fixed to the driver shaft. It meshes with a **worm wheel** fixed to the driven shaft, which runs at **90°** to the driver shaft.



Real-life examples: Worm gears are used in guitar tuning pegs, steering mechanisms, and conveyor belt drives — any application that needs a large speed reduction in a compact space, and where the drive should be self-locking (the

worm wheel cannot back-drive the worm).



For calculation purposes, treat the worm as a **single-tooth gear**. One full rotation of the worm advances the worm wheel by exactly one tooth.

WORKED EXAMPLE — WORM AND WHEEL

A worm meshes with a 30-tooth worm wheel. The motor rotates at 100 rev s^{-1} . Calculate the output speed.

- 1 VR: $\frac{\text{Teeth}_{\text{Out}}}{\text{Teeth}_{\text{In}}} = \frac{30}{1} = \mathbf{30:1}$
- 2 Output speed: $\frac{100}{30} = \mathbf{3.33 \text{ rev s}^{-1}}$



NoGrind Simulator — worm and wheel

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.


Section 7: Belt Drives

 **Interesting — but not examined:** This section does not appear in the N5 course specification or QS exams. It gives useful real-world context but you do not need to learn it for assessment.

Belt drives transmit rotary motion between shafts that may be far apart. A **belt** wraps around two or more **pulleys** — thin metal discs with a groove cut into the rim. The belt is tensioned by pulling one pulley out and locking it in place.

Unlike meshing gears, belt drives do **not reverse the direction of rotation**. To reverse direction, the belt must be crossed between the pulleys.

Real-life examples: Belt drives are used in washing machines, lathes, air compressors and car alternators — wherever a smooth, quiet drive is needed between shafts that are too far apart for gears.




Belt drive calculations

Belt drives also enable rotation speeds to be changed. The calculations are similar to gear trains but rather than using numbers of teeth, pulley diameters are used.

Pulley A - Driver

Pulley B - Driven



$$\text{Diameter}_{\text{Driver}} \times \text{Turns}_{\text{Driver}} = \text{Diameter}_{\text{Driven}} \times \text{Turns}_{\text{Driven}}$$

Velocity ratio for belt drives

$$VR = \frac{\text{Diameter}_{\text{Driven}}}{\text{Diameter}_{\text{Driver}}}$$

$$\text{Output speed} = \frac{\text{Input speed}}{VR}$$

WORKED EXAMPLE — BELT DRIVE VR AND OUTPUT SPEED

Driver pulley diameter: 120 mm. Driven pulley diameter: 40 mm. Input speed: 1200 rev/min.

1 VR: $\frac{40}{120} = 1/3$ (or 1:3)

2 Output speed: $\frac{1200}{1/3} = 3600 \text{ rev/min}$ (speed increase because driven pulley is smaller)

Types of belt

Flat belt



- Simple rectangular cross-section
- Runs on flat-faced pulleys
- Inexpensive and easy to replace
- No lubrication needed
- Suitable for light loads and high speeds
- Can slip under heavy loads

V-belt

- Wedge-shaped cross-section that grips the pulley groove
- Transmits more **torque** than a flat belt due to the wedging action
- Multiple V-belts can be used side by side where extra power is needed
- Less likely to slip than a flat belt
- Absorbs shock loads without damage
- Widely used in industrial machinery and car engines


Toothed (timing) belt

- Interlocking teeth prevent any slipping
- Maintains precise timing between driver and driven shafts
- Used where slippage would cause damage — e.g. car engine timing belt
- Quiet and low maintenance in operation
- More expensive than flat or V-belts
- Cannot absorb shock loads — teeth can shear if overloaded



Jockey pulley


A **jockey (tensioner) pulley** is a spring-loaded pulley used to keep the belt correctly tensioned. Too slack and the belt slips; too tight and the bearings wear out.



Stepped-cone pulleys

A variety of output speeds can be achieved without changing pulleys by using **stepped-cone pulleys** — a series of pulleys of different diameters fixed to the same shaft. Moving the belt to a different step changes the speed ratio.

Real-life example: Stepped-cone pulleys are used on pillar drills and some lathes to select different cutting speeds depending on the material being worked.



Task 6 — Belt drive calculations

Calculate the missing quantities. In each case the left pulley is the driver.

- Driver diameter: 40 mm, 1200 rev/min. Driven diameter: 80 mm. Calculate the output speed and VR.
- Driver diameter: 60 mm, 900 rev/min. Output speed: 300 rev/min. Calculate the driven diameter and VR.
- Driven diameter: 120 mm, 500 rev/min. VR = 3. Calculate the driver diameter and input speed.

Research: Name three real-world machines or systems that use belt and pulley drives.

Sketch or describe a belt drive system that produces a **decrease** in speed with a **change in direction** of the driven pulley.



NoGrind Simulator — belt drives

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

Section 8: Chain Drives



Interesting — but not examined: This section does not appear in the N5 course specification or exams. It gives useful real-world context but you do not need to learn it for assessment.

Where large forces must be transmitted with **no slippage**, a **chain drive** is used. Instead of a pulley, a toothed wheel called a **sprocket** drives a chain, which in turn drives another sprocket. Chain drives do not slip.

Real-life examples: Bicycles, motorcycles, and industrial conveyor systems all use chain drives where a positive, non-slip drive is essential.

Advantages of chain drives

- Very strong — will not slip under normal conditions
- Transmits large forces reliably
- Positive drive — no loss of motion

Disadvantages of chain drives

- Must be oiled regularly
- Chain and sprockets prone to wear
- More expensive than belt drives
- Noisier than belt drives



Chain drive equation

$$\text{Teeth}_{\text{Driver}} \times \text{Turns}_{\text{Driver}} = \text{Teeth}_{\text{Driven}} \times \text{Turns}_{\text{Driven}}$$

$$\text{VR} = \frac{\text{Teeth}_{\text{Driven}}}{\text{Teeth}_{\text{Driver}}}$$

WORKED EXAMPLE — BICYCLE CHAIN DRIVE VR


A bicycle has 60 teeth on the pedal sprocket (driver) and 10 teeth on the rear wheel sprocket (driven). Calculate the VR.

- 1 $\text{VR} = \frac{\text{Teeth}_{\text{Driven}}}{\text{Teeth}_{\text{Driver}}} = \frac{10}{60} = \mathbf{1/6 \text{ (or 1:6)}}$
- 2 For every 1 revolution of the pedals, the wheel turns 6 times — a speed increase.

 **Interesting — but not examined:** The following section on Derailleur gears gives useful real-world context but does not appear in the N5 course specification or QS exams. Read it for interest but you do not need to learn it for assessment.

Derailleur gears

Racing bikes and mountain bikes use **Derailleur gears** — a spring-loaded jockey wheel that keeps the chain tensioned while allowing it to be moved between different sprockets on a cassette (rear hub) and different chainrings (front). This gives a wide range of gear ratios for different terrains.



Task 7 — Chain drive calculations

a) Driver sprocket: 48 teeth, 60 rev/min. Driven sprocket: 16 teeth. Calculate the output speed and VR.

b) Driver: 24 teeth, 200 rev/min. Output speed: 50 rev/min. Calculate the number of teeth on the driven sprocket and the VR.

A cyclist wants to go faster suddenly and puts extra force into the pedals. Explain why the chain must not slip for this to work, and what would happen if it did.



NoGrind Simulator — chain drives

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

Section 9: Converting Motion

Many mechanisms involve changing one type of motion into another. For example, the **rotary** motion of a pillar-drill handle is changed to the **linear** motion of the drill bit moving down.


Cams



Interesting — but not examined: Cams do not appear in the N5 course specification or QS exams. This section gives useful real-world context but you do not need to learn it for assessment.


A **cam** is a specially shaped piece of metal or plastic that converts input **rotary** motion into output **oscillating** or **reciprocating** motion. The cam works by guiding a **follower** held against it by its own weight or a spring.

There are several types of cam — each producing a different pattern of follower movement:



- **Circular (eccentric) cam** — produces a smooth, continuous rise and fall of the follower
- **Pear-shaped cam** — has a **dwell period** (the follower is stationary for part of the revolution) followed by a rapid rise and fall. Used on car camshafts to operate engine valves.
- **Heart cam** — designed to produce a uniform, constant rise in the follower
- **Drop (snail) cam** — follower rises gradually then drops suddenly; used in alarm clock mechanisms

Real-life examples: Cams are used in car engine camshafts to open and close valves, in sewing machines to create stitch patterns, and in some music boxes.



 **Interesting — but not examined:** The cam part names below (crown, heel, dwell, stroke) give useful context but are not required knowledge for the N5 exam. You do not need to memorise these terms for assessment.

Cam terminology

- **Crown** — the highest point of the cam profile (follower at maximum height, valve fully open)
- **Heel** — the lowest point of the cam profile (follower at rest, valve closed)
- **Dwell period** — the part of the cam rotation where the follower is stationary
- **Stroke** — the distance between the crown and heel (= the distance the valve opens)

Task 8 — Cams


A pear-shaped cam and follower forms a simple locking mechanism. Name the cam (A) and the follower (B). How much of a turn does the wheel make to push the lock-bolt closed? Describe why the spring is needed.

A cam on a car engine valve mechanism turns half a revolution from the position shown below (follower at heel). What distance does the valve move? (The stroke of the cam is 8 mm.)

Section 10: Crank and Slider

 **Interesting — but not examined:** This section does not appear in the N5 course specification or QS exams. It gives useful real-world context but you do not need to learn it for assessment.

A **crank-and-slider** mechanism converts between **rotary** and **reciprocating** motion. The crank rotates while the slider (piston) reciprocates in a straight line. The longer the crank, the further the slider moves.



Real-life examples: Car engines (piston to crankshaft), power hacksaws, reciprocating pumps and steam engines all use the crank-and-slider mechanism.

The crank-and-slider is used in two main ways:

- **Reciprocating → Rotary:** Car engines — pistons connected to a crankshaft by connecting rods. As pistons move down in sequence they keep the crankshaft turning.
- **Rotary → Reciprocating:** Power hacksaw — a motor drives a crank connected to a saw frame that slides back and forth on an arm.

Task 9 — Crank and slider

A crank-and-slider mechanism is used in a fabric-testing machine. The crank is 30 mm long. A wire brush is attached to the slider.


- a) What is the distance from A (one end of slider travel) to B (the other end)?
- b) What effect does the wire brush have on the fabric?

Section 11: Rack and Pinion

 **Interesting — but not examined:** This section does not appear in the N5 course specification or QS exams. It gives useful real-world context but you do not need to learn it for assessment.

A **rack and pinion** mechanism converts **rotary** motion to **linear** motion (or vice versa). A round spur gear (the **pinion**) meshes with a flat toothed bar (the **rack**).

Real-life examples: Rack and pinion mechanisms are used in car steering systems, pillar drills, camera tripods and stairlift tracks.



There are three ways a rack and pinion can be used:

1. Rack moves linearly → pinion rotates (e.g. gripper mechanism)
2. Pinion rotates on fixed centre → rack moves linearly (e.g. camera tripod, pillar drill)
3. Rack is fixed, pinion rotates → pinion's centre moves linearly (e.g. lathe carriage)



NoGrind Simulator — rack and pinion

This interactive simulator is in the online course notes. Scan the QR code, or use a device, to open it.

Task 10 — Rack and pinion

A rack is 200 mm long with a pitch (tooth spacing) of 2 mm. It meshes with a pinion that has 20 teeth.

- a) If the pinion rotates one full revolution, how far does the rack move? (Hint: distance = number of teeth × pitch)
- b) How many complete revolutions of the pinion are needed to move the rack from one end to the other?

Without looking back at Section 1, draw the standard symbols for the following mechanisms: simple gear train, belt drive, chain drive, rack and pinion.

Section 12: Design Challenges

These are original design problems, set out the same way as a practical assignment: a **context**, a numbered **specification**, then **design, build, test and evaluate** tasks. They only use the gear content you need for the exam (simple gear trains, idler gears and compound gear trains).

Work through each challenge on your own first. Use the NoGrind simulators from Sections 2–5 to build and test your design, then compare with the model solution.

Design Challenge 1: Hand-cranked whisk

Context: A S1 class is building hand-cranked kitchen whisks for a charity bake sale. Pupils can turn the handle comfortably at about 60 rev/min, but the whisk needs to spin much faster to work well. Testing showed that pupils find the whisk confusing to use if it spins the opposite way to the handle.

- i The handle is turned at 60 rev/min.
- ii The whisk must turn at 180 rev/min.
- iii The whisk must turn in the **same direction** as the handle.
- iv Only spur gears with 8, 16, 24 or 40 teeth can be used, and no more than three gears in total.

Design Challenge 1 — Hand-cranked whisk

- a) Calculate the velocity ratio the gear train must have.

- b) Design: sketch or describe a gear train that meets every point of the specification. Label the driver, the driven gear and any other gears, with their number of teeth.

- c) Build and test: build your design in the NoGrind idler gear simulator (Section 3). Record the output speed and the direction of the whisk gear.

- d) Evaluate: for each specification point (i–iv), state whether your design meets it and give evidence from your calculations or testing.

Design Challenge 2: Stage scenery winch

Context: The school drama department wants a small motorised winch to raise and lower a lightweight backdrop. The motor they have runs far too fast to drive the winch drum directly, so a gearbox is needed. To keep the wiring simple, the drum must wind in the same direction as the motor turns.

- i** The motor turns at 1500 rev/min.

- ii** The winch drum must turn at 60 rev/min.

- iii** The drum must turn in the **same direction** as the motor.

- iv** Only spur gears with 8, 16, 24 or 40 teeth can be used, and no more than four gears in total.

Design Challenge 2 — Stage scenery winch

- a) Calculate the velocity ratio the gearbox must have. Explain why a simple gear train of two gears cannot meet specification point iv.
-
- b) Design: sketch or describe a compound gear train that meets every point of the specification. Show which gears share a shaft, and show that your total VR is correct.
-
- c) Build and test: build your design in the NoGrind compound gear simulator (Section 5). Record the drum speed and direction.
-
- d) Evaluate: for each specification point (i–iv), state whether your design meets it and give evidence. Explain why your drum turns the same way as the motor.

Design Challenge 3: Model wind turbine

Context: A community energy group on a Scottish island is building a model wind turbine for a school open day. In a steady breeze the rotor blades turn slowly, but the small generator only produces a useful voltage when it spins quickly. A gearbox is needed between the rotor and the generator.

- i** In a steady breeze the rotor turns at 40 rev/min.

- ii** The generator must turn at 600 rev/min.

- iii** The generator must turn in the **same direction** as the rotor.

- iv** Only spur gears with 8, 16, 24 or 40 teeth can be used, and no more than four gears in total.

Design Challenge 3 — Model wind turbine

- a) Calculate the velocity ratio the gearbox must have. Is this a speed increase or a speed decrease?
-
- b) Design: sketch or describe a gear train that meets every point of the specification. Label the driver (on the rotor shaft), the driven gear (on the generator shaft) and the teeth on every gear.
-
- c) Build and test: build your design in the NoGrind compound gear simulator (Section 5), with the input set to 40 rev/min. Record the generator speed and direction.
-
- d) Evaluate: for each specification point (i–iv), state whether your design meets it. Then suggest what would happen to the generator speed if the wind got stronger.