


HOW TO ENABLE SERIAL CONSOLE ACCESS ON CATALYST 8000V ROUTERS IN VMANAGE MODE

- In Cisco SD-WAN, Catalyst 8000v Routers do not accept Console connections by default
- This doc outlines the steps to enable Console access on Cat8Kv Routers in vManage Mode

Step 1: Edit the Device Template attached to the cEdge Routers

- From the vManage GUI, go to Configuration > Templates > Device Templates
- Edit the Device Template attached to the cEdge Routers (C8000v's)






HOW TO ENABLE SERIAL CONSOLE ACCESS ON CATALYST 8000V ROUTERS IN VMANAGE MODE

Step 2: Create a CLI Add-On Template

Click Additional Templates, then under the CLI Add-On Template, click the dropdown and **Create Template**






HOW TO ENABLE SERIAL CONSOLE ACCESS ON CATALYST 8000V ROUTERS IN VMANAGE MODE


Step 3: Add the "platform console serial" command

- Give the CLI Add-On Template a Name and optional Description
- Under CLI CONFIGURATION add the command platform console serial and save




Step 4: Apply the CLI Add-On Template

Click the dropdown next to CLI Add-On Template and choose the template you created




Step 5: Push the configuration changes to the cEdge Routers

Click through the configuration deployment screens and confirm the changes on the devices




You should see the **Status** of **Success** once complete



Step 6: Reboot the cEdge Routers

In the virtual topology, right-click the Cat8Kv-1 and Cat8Kv-2 routers, Stop them - wait a few seconds for the operation to complete - then Start them again





Step 7: Log in to the cEdge Routers via the Console

- Double-click the cEdge routers in the virtual topology to open the console window
- Login credentials are listed in the virtual topology

```
Restricted UseUn authorised Logins tracked
User Access Verification
Username: admin
Password: C1sc0123!
Cat8Kv-2>enable
Cat8Kv-2#show ip int brief
Interface
                      IP-Address
                                     OK? Method Status
                                                                      Protocol
GigabitEthernet1
                      150.101.2.1
                                      YES other
                                                up
                                                                      up
                      unassigned YES unset
GigabitEthernet2
                                                                      up
GigabitEthernet2.101
                      192.168.101.102 YES other
                                                up
                                                                      up
                      169.254.111.2 YES other
GigabitEthernet2.169
                                                up
                                                                      up
GigabitEthernet3
                      unassigned
                                      YES unset
                                                up
                                                                      up
GigabitEthernet4
                      unassigned
                                      YES unset
                                                up
Sdwan-system-intf
                      172.17.102.1
                                     YES unset
                                                up
                                                                      up
vmanage system
                      unassigned
                                      YES unset
                                                up
                                                                      up
Loopback65528
                      192.168.1.1
                                      YES other
                                                up
                                                                      up
Loopback65529
                      11.1.102.1
                                      YES other
                                                up
                                                                      up
NVI0
                      unassigned
                                      YES unset
                                                up
                                                                      up
Tunnel1
                      150.101.2.1
                                      YES TFTP
                                                up
                                                                      up
```

Note: cEdge Routers in vManage mode do not support configuration changes from the CLI:

```
Cat8Kv-2#config t
This command is not supported in Controller mode.
Please use the equivalent command - config-transaction
Cat8Kv-2#config-transaction
admin connected from 127.0.0.1 using console on Cat8Kv-2
Cat8Kv-2(config)# interface Tunnel1
Cat8Kv-2(config-if)# shut
Cat8Kv-2(config-if)# commit
                           d': This device is being managed by vMana
Cat8Kv-2(config-if)#
```