




USB HUB RPI CAMERA




SOLAR CHARGE CONTROLLER




BATTERY MONITORING




MAIN / ESP REG



RPI REG




SIM MODULE SMPM




STRAPPING PINS CONFIGURATION


Strapping Pin	Default Configuration
MTMS (GPIO4)	FLOATING (-)
MTDI (GPIO5)	FLOATING (-)
GPIO8	FLOATING (-)
GPIO9	PULL UP (1)
GPIO15	FLOATING (-)




SIGNALS (ESP - RPI - SIM)




I2C PULL-UP




RST PULL-UP




SIM MODULE RESET / PWR KEY




SIM MODULE NETWORK LED




Humidity + Temp Sensor




ESP32-C6-MINI-1




RASPBERRY PI ZERO W




SIM MODULE




GSM ANTENNA CONNECTOR




GNSS ANTENNA CONNECTOR



ESIM SOCKET



USIM SOCKET



ESP PROGRAMMING

