


Computer Organisation and Architecture

Smruti Ranjan Sarangi, IIT Delhi

Chapter 7 Computer Arithmetic

PROPRIETARY MATERIAL. © 2014 The McGraw-Hill Companies, Inc. All rights reserved. No part of this PowerPoint slide may be displayed, reproduced or distributed in any form or by any means, without the prior written permission of the publisher, or used beyond the limited distribution to teachers and educators permitted by McGraw-Hill for their individual course preparation. PowerPoint Slides are being provided only to authorized professors and instructors for use in preparing for classes using the affiliated textbook. No other use or distribution of this PowerPoint slide is permitted. The PowerPoint slide may not be sold and may not be distributed or be used by any student or any other third party. No part of the slide may be reproduced, displayed or distributed in any form or by any means, electronic or otherwise, without the prior written permission of McGraw Hill Education (India) Private Limited.





These slides are meant to be used along with the book: Computer Organisation and Architecture, Smruti Ranjan Sarangi, McGrawHill 2015 Visit: http://www.cse.iitd.ernet.in/~srsarangi/archbooksoft.html

Outline

* Addition

- * Multiplication
- Division
- * Floating Point Addition
- Floating Point Multiplication
- * Floating Point Division



Adding Two 1 bit Numbers

* Let us add two 1 bit numbers — a and b


$$* 0 + 0 = 00$$

$$*$$
 0 + 1 = 01

* The lsb of the result is known, as the sum, and the msb is known as the carry



Sum and Carry



a	b	S	C
0	0	0	0
0	1	1	0
1	0	1	0
1	1	0	1

$$S = a \oplus b = \overline{a}.b + a.\overline{b}$$

 $c = a.b$


Truth Table



Half Adder

* Adds two 1 bit numbers to produce a 2 bit result







Full Adder

Add three 1 bit numbers to produce a 2 bit output

$$a+b+c_{in}=2*c_{out}+s$$

а	b	c _{in}	S	C _{out}
0	0	0	0	0
0	1	0	1	0
1	0	0	1	0
1	1	0	0	1
0	0	1	1	0
0	1	1	0	1
1	0	1	0	1
1	1	1	1	1



Equations for the Full Adder

$$s = a \oplus b \oplus c_{in}$$

$$= (a.\overline{b} + \overline{a}.b) \oplus c_{in}$$

$$= (a.\overline{b} + \overline{a}.b).\overline{c_{in}} + \overline{a.\overline{b}}.\overline{b.c_{in}}$$

$$= a.\overline{b}.\overline{c_{in}} + \overline{a.b.\overline{c_{in}}} + \overline{(a.\overline{b})}.\overline{(\overline{a.b})}.c_{in}$$

$$= a.\overline{b}.\overline{c_{in}} + \overline{a.b.\overline{c_{in}}} + (\overline{a} + b).(a + \overline{b}).c_{in}$$


$$= a.\overline{b}.\overline{c_{in}} + \overline{a.b.\overline{c_{in}}} + \overline{a.\overline{b.c_{in}}} + a.b.\overline{c_{in}}$$


$$= a.\overline{b.\overline{c_{in}}} + \overline{a.b.\overline{c_{in}}} + \overline{a.\overline{b.c_{in}}} + a.b.\overline{c_{in}}$$

$$c_{out} = a.b + a.c_{in} + b.c_{in}$$




Circuit for the Full Adder







Addition of two n bit numbers



- * We start from the lsb
- * Add the corresponding pair of bits and the carry in
- Produce a sum bit and a carry out




Observations

- We keep adding pairs of bits, and proceed from the lsb to the msb
- * If a carry is generated, we add it to the next pair of bits
- * At the last step, if a carry is generated, then it becomes the msb of the result
- * The carry effectively ripples through the bits



Ripple Carry Adder





Operation of the Ripple Carry Adder

- Problem : Add A + B
- Number the bits : A₁ to A_n and B₁ to B_n
 - * Isb \rightarrow A₁ and B₁
 - * msb \rightarrow A_n and B_n
- Use a half adder to add A₁ and B₁
- * Send the carry(c) to a full adder that adds : $A_2 + B_2 + c$
- Proceed in a similar manner till the msb



How long does the Ripple Carry Adder take?

* Time:

- * Time of half adder : t_h
- Time of full adder : t_f
- * Total Time : $t_h + (n-1)t_f$



Asymptotic Time Complexity

- * Most of the time, we are primarily interested in the order of the function
- * For example : we are only interested in the n^2 term in $(2n^2 + 3n + 4)$
- * We do not care about the constants, and terms with smaller exponents
 - * 3n and 4
- * We can thus say that :



* $2n^2 + 3n + 4$ is order of (n^2)

The O notation

* Formally:

- * We say that: f(n) = O(g(n))
- * if, $|f(n)| \le c|g(n)|$, for all $n > n_0$. Here c is a positive constant.

* In simple terms:

- * Beyond a certain n, g(n) is greater-than-equal to a certain constant times f(n)
 - * For example, beyond 15, $(n^2 + 10n + 16) \le 2n^2$



Example of the big O Notation


 $f(n) = 3n^2 + 2n + 3$. Find its asymptotic time complexity. **Answer:**

$$f(n) = 3n^2 + 2n + 3$$

$$\leq 3n^2 + 2n^2 + 3n^2 (n > 1)$$

$$\leq 8(n^2)$$

Hence, $f(n) = O(n^2)$.



 $8n^2$ is a strict upper bound on f(n) as shown in the figure.



Big O Notation - II

Example:

 $f(n) = 0.00001n^{100} + 10000n^{99} + 234344$. Find its asymptotic time complexity.

Answer: $f(n) = O(n^{100})$

* We shall use the asymptotic time complexity metric (big O notation) to characterize the time taken by different adders



Ripple Carry Adders and Beyond

- * Time complexity of a ripple carry adder:
 - * O(n)



Can we do better than O(n)?








Carry Select Adder O(Vn) time

- Group bits into blocks of size (k)
- If we are adding two 32 bit numbers A and B, and k = 4, then the blocks are :



 Produce the result of each block with a small ripple carry adder



Carry Select Adder - II

- In this case, the carry propagates across blocks
- Time complexity is O(n)



Idea:

- Add the numbers in each block in parallel
- Stage I: For each block, produce two results
 - Assuming an input carry of 0
 - Assuming an input carry of 1



Carry Select Adder – Stage II

- For each block we have two results available
- * Result → (k sum bits), and 1 carry out bit
- * Stage II
 - Start at the least significant block
 - The input carry is 0
 - Choose the appropriate result from stage I
 - We now know the input carry for the second block
 - Choose the appropriate result
 - Result contains the input carry for the third block



Carry Select Adder – Stage II

- Given the result of the second block
 - Compute the carry in for the third block
 - Choose the appropriate result
- * Proceed till the last block
- At the last block (most significant positions)
 - Choose the correct result
 - * The carry out value, is equal to the carry out of the entire computation.



How much time did we take?

- * Our block size is k
 - * Stage I takes k units of time
- * There are n/k blocks
 - Stage II takes (n/k) units of time
- * Total time : (k + n/k)

$$\frac{\partial (k+n/k)}{\partial k} = 0$$

$$\Rightarrow 1 - \frac{n}{k^2} = 0$$

$$\Rightarrow k = \sqrt{n}$$




Time Complexity of the Carry Select Adder

- * T = O(\sqrt{n} + \sqrt{n}) = O(\sqrt{n})
- * Thus, we have a Vn time adder



Can we do better?





Carry Lookahead Adder (O(log n))

- * The main problem in addition is the carry
- If we have a mechanism to compute the carry quickly, we are done
- * Let us thus focus on computing the carry without actually performing an addition



Generate and Propagate Functions

- * Let us consider two corresponding bits of A and B
 - A_i and B_i
- Generate function : A new carry is generated (C_{out} = 1)
- Propagate function : C_{out} = C_{in}
- * Generate and Propagate Functions are :

$$g_i = A_i . B_i$$
$$p_i = A_i \oplus B_i$$



Using the G and P Functions

* If we have the generate and propagate values for a bit pair, we can determine the carry out

$$C_{out} = g_i + p_i \cdot C_{in}$$



Example

Example:

Let $A_i = 0$, $B_i = 1$. Let the input carry be C_{in} . Compute g_i , p_i , and C_{out} .

Answer:

$$g_i = A_i.B_i = 0.1 = 0$$

$$p_i = A_i \oplus B_i = 0 \oplus 1 = 1$$

$$C_{out} = g_i + p_i \cdot C_{in} = C_{in}$$



G and P for Multi-bit Systems

- * $C_{out}^{i} \rightarrow output carry for i^{th} bit pair$
- * $C_{in}^{i} \rightarrow input carry for i^{th} bit pair$
- * $g_i \rightarrow generate$ value for i^{th} bit pair
- * $p_i \rightarrow propagate value for ith bit pair$



G and P for Multibit Systems - II

$$C_{out}^1 = g_1 + p_1.C_{in}^1$$

$$C_{out}^2 = g_2 + p_2 \cdot C_{out}^1$$

= $g_2 + p_2 \cdot (g_1 + p_1 \cdot C_{in}^1)$
= $(g_2 + p_2 \cdot g_1) + p_2 \cdot p_1 \cdot C_{in}^1$

$$C_{out}^{3} = g_{3} + p_{3}.C_{out}^{2}$$

$$= g_{3} + p_{3}. \left((g_{2} + p_{2}.g_{1}) + p_{2}.p_{1}.C_{in}^{1} \right)$$

$$= (g_{3} + p_{3}.g_{2} + p_{3}.p_{2}.g_{1}) + p_{3}.p_{2}.p_{1}.C_{in}^{1}$$



G and P for multibit Systems - III

$$C_{out}^{4} = g_{4} + p_{4}.C_{out}^{3}$$

$$= g_{4} + p_{4}. \left((g_{3} + p_{3}.g_{2} + p_{3}.p_{2}.g_{1}) + p_{3}.p_{2}.p_{1}.C_{in}^{1} \right)$$

$$= (g_{4} + p_{4}.g_{3} + p_{4}.p_{3}.g_{2} + p_{4}.p_{3}.p_{2}.g_{1}) + p_{4}.p_{3}.p_{2}.p_{1}.C_{in}^{1}$$




Patterns

1 bit	$C_{out}^1 = \underbrace{g_1}_{G_1} + \underbrace{p_1}_{P_1} \cdot C_{in}^1$
2 bit	$C_{out}^2 = \underbrace{g_2 + p_2.g_1}_{G_2} + \underbrace{p_2.p_1}_{P_2}.C_{in}^1$
3 bit	$C_{out}^3 = \underbrace{g_3 + p_3.g_2 + p_3.p_2.g_1}_{G_3} + \underbrace{p_3.p_2.p_1}_{P_3}.C_{in}^1$
4 bit	$C_{out}^{4} = \underbrace{g_{4} + p_{4}.g_{3} + p_{4}.p_{3}.g_{2} + p_{4}.p_{3}.p_{2}.g_{1}}_{\mathring{G}_{4}} + \underbrace{p_{4}.p_{3}.p_{2}.g_{1}}_{\mathring{P}_{4}} + \underbrace{p_{4}.p_{3}.p_{2}.p_{1}}_{\mathring{P}_{4}}.C_{in}^{1}$
n bit	$C_{out}^n = G_n + P_n.C_{in}^1$



Computing G and P Quickly

* Let us divide a block of n bits into two parts



- Let the carry out and carry in be : C_{out} and C_{in}
- * We want to find the relationship between

*
$$G_{1,n}$$
, $P_{1,n}$ and $(G_{m+1,n}, G_{1,m}, P_{m+1,n}, P_{1,m})$



Computing G and P Quickly - II

$$C_{out} = G_{m+1,n} + P_{m+1,n} \cdot C_{sub}$$

$$= G_{m+1,n}$$

$$+ P_{m+1,n} \cdot (G_{1,m} + P_{1,m} \cdot C_{in})$$

$$= G_{m+1,n} + P_{m+1,n} \cdot G_{1,m} + P_{m+1,n} \cdot P_{1,m} \cdot C_{in}$$

$$C_{out} = G_{1,n} + P_{1,n} \cdot C_{in}$$

$$G_{1,n} = G_{m+1,n} + P_{m+1,n}.G_{1,m}$$

$$P_{1,n} = P_{m+1,n} P_{1,m}$$



Insight into Computing G and P quickly

* Insight:

- * We can compute G and P for a large block
 - By first computing G and P for smaller sub-blocks
 - And, then combining the solutions to find the value of G and P for the larger block
- Fast algorithm to compute G and P
 - * Use divide-and-conquer
 - Compute G and P functions in O (log (n)) time




Carry Lookahead Adder – Stage I

- * Compute G and P functions for all the blocks
- * Combine the solutions to find G and P functions for sets of 2 blocks
- * Combine the solutions fo find G and P functions for sets of 4 blocks
- *
- *
- Find the G and P functions for a block of size: 32 bits



Carry Lookahead Adder – Stage I






CLA Adder – Stage I

- * Compute G, P for increasing sizes of blocks in a tree like fashion
- * Time taken:
 - * Total : log(n) levels
 - * Time per level : O(1)
 - * Total Time : O(log(n))



CLA Adder – Stage II





Connection of the G,P Blocks

- Each G,P block represents a range of bits (r2, r1)(r2 > r1)
 - * The (r2, r1) G,P block is connected to all the blocks of the form (r3, r2+1)
 - * The carry out of one block is an input to all the blocks that it is connected with
- * Each block is connected to another block at the same level, and to blocks at lower levels




Operation of CLA – Stage II

- * We start at the leftmost blocks in each level
 - * We feed an input carry value of C_{in}¹
 - * Each such block computes the output carry, and sends it to the all the blocks that it is connected to
- * Each connected block
 - Computes the output carry
 - Sends it to all the blocks that it is connected to
- * The carry propagates to all the 2 bit RC adders



CLA Adder – Stage II





Time Complexity

- * In a similar manner, the carry propagates to all the RC adders at the zeroth level
- * Each of them compute the correct result
- * Time taken by Stage II:
 - * Time taken for a carry to propagate from the (16,1) node to the RC adders
 - * O(log(n))
- * Total time : O(log(n) + log(n)) = O(log(n))



Time complexities of different adders:

- Ripple Carry Adder: O(n)
- Carry Select Adder: $O(\sqrt{n})$
- Carry Lookahead Adder: $O(\log(n))$



Outline


- * Addition
- * Multiplication



- * Division
- Floating Point Addition
- * Floating Point Multiplication
- * Floating Point Division



Multiplicands



- * 13 → Multiplicand
- * 9 → Multiplier



* $117 \rightarrow Product$

Basic Multiplication

- * Consider the lsb of the multiplier
 - * If it is 1, write the value of the multiplicand
 - If it is 0, write 0
- For the next bit of the multiplier
 - If it is 1, write the value of the multiplicand shifted by 1 position to the left
 - If it is 0, write 0
- * Keep going



Definitions

Partial sum: It is equal to the value of the multiplicand left shifted by a certain number of bits, or it is equal to o. Partial product: It is the sum of a set of partial sums.

- * If the multiplier has m bits, and the multiplicand has n bits
 - * The product requires (m+n) bits




Multiplying 32 bit numbers

- * Let us design an iterative multiplier that multiplies two 32 bit signed values to produce a 64 bit result
- * What did we prove before
 - * Multiplying two signed 32 bit numbers, and saving the result as a 32 bit number is the same as
 - Multiplying two unsigned 32 bit numbers (assuming no overflows)
- * We did not prove any result regarding saving the result as a 64 bit number




Class Work



Theorem: A signed n bit number $A = A_{1 \dots n-1} - A_n 2^{n-1}$. A_i is the ith bit in A's 2's complement based binary representation (the first bit is the LSB). $A_{1 \dots n-1}$ is a binary number containing the first n-1 digits of A's binary 2's complement representation.



Iterative Multiplier



- * Multiplicand (N), Multiplier (M), Product(P) = MN
- * U is a 33 bit register and V is a 32 bit register
- beginning: V contains the multiplier, U = 0
- UV is one register for the purpose of shifting




Algorithm

Algorithm 1: Algorithm to multiply two 32 bit numbers and produce a 64 bit result

```
Data: Multiplier in V, U = 0, Multiplicand in N
Result: The lower 64 bits of UV contains the product
i ← 0
for i < 32 do
     i \leftarrow i + 1
     if LSB of V is 1 then
          if i < 32 then
               U \leftarrow U + N
          end
          else
               U \leftarrow U - N
          end
     end
     UV \leftarrow UV >> 1 (arithmetic right shift)
end
```





Example





3 * (-2)







Operation of the Algorithm

- * Take a look at the lsb of V
 - * If it is $0 \rightarrow do nothing$
 - * If it is $1 \rightarrow Add N$ (multiplicand) to U

Right shift

- * Right shifting the partial product is the same as left shifting the multiplicand, which
- Needs to be done in every step
- * Last step is different



The Last Step ...

- In the last step
 - Isb of V = msb of M (multiplier)
 - * If it is $0 \rightarrow do nothing$
- * If it is 1
 - Multiplier is negative
 - * Recall : $A = A_{1 ... n-1} 2^{n-1}A_n$
 - Hence, we need to subtract the multiplicand if the msb of the multiplier is 1



Time Complexity

- * There are *n* loops
 - * Each loop takes log(n) time
 - * Total time : O(n log(n))



Booth Multiplier

- We can make our iterative multiplier faster
- * If there are a continuous sequence of 0s in the multiplier
 - * do nothing
- * If there is a continous sequnce of 1s
 - * do something smart

$$M = \sum_{k=i}^{k=j} 2^k = 2^{j+1} - 2^i$$





For a Sequence of 1s

- Sequence of 1s from position i to j
 - * Perform (j-i+1) additions

$$A = \sum_{k=i}^{k=j} 2^k$$

New method

- Subtract the multiplicand when we scan bit i (! count starts from 0)
- * Keep shifting the partial product
- * Add the multiplicand(N), when we scan bit (j+1)
- * This process, effectively adds $(2^{j+1}-2^i)$ * N to the partial product
- Exactly, what we wanted to do ...



Operation of the Algorithm

- Consider bit pairs in the multiplier
 - (current bit, previous bit)
 - Take actions based on the bit pair
 - * Action table

(current value, previous value)	Action
0,0	_
1,0	subtract multiplicand from U
1,1	_
0,1	add multiplicand to U



Booth's Algorithm

Algorithm 2: Booth's Algorithm to multiply two 32 bit numbers to produce a 64 bit result

```
Data: Multiplier in V, U = 0, Multiplicand in N
Result: The lower 64 bits of UV contain the result
i ← 0
prevBit ← 0
for i < 32 do
     i \leftarrow i + 1
     currBit \leftarrow LSB \ of \ V
     if (currBit, prevBit) = (1,0) then
          U \leftarrow U - N
    end
    else if (currBit, prevBit) = (0,1) then
          U \leftarrow U + N
     end
    prevBit ← currBit
     UV \leftarrow UV >> 1 (arithmetic right shift)
end
```



Outline of a Proof

- * Multiplier (M) is positive
 - * msb = 0
 - * Divide the multiplier into a sequence of continuous 0s and 1s
 - * $01100110111000 \rightarrow 0,11,00,11,0,111,000$
 - For sequence of 0s
 - Both the algorithms (iterative, Booth) do not add the multiplicand
 - For a run of 1s (length k)
 - * The iterative algorithm performs k additions
 - Booth's algorithm does one addition, and one subtraction.
 - * The result is the same



Outline of a Proof - II

Negative multipliers

$$*$$
 msb = 1

*
$$M = -2^{n-1} + \sum_{(i=1 \text{ to } n-1)} M_i 2^{n-1} = -2^{n-1} + M'$$

*
$$M' = \sum_{(i=1 \text{ to } n-1)} M_i 2^{n-1}$$

* Consider two cases

- * The two msb bits of M are 10
- * The two msb bits of M are 11



Outline of a Proof - III

* Case 10

- * Till the (n-1)th iteration both the algorithms have no idea if the multiplier is equal to M or M'
- * At the end of the (n-1)th iteration, the partial product is:
 - * Iterative algorithm: M'N
 - * Booth's algorithm : M'N
 - * If we were multiplying (M' * N), no action would have been taken in the last iteration. The two msb bits would have been 00. There is no way to differentiate this case from that of computing MN in the first (n-1) iterations.



Outline of a Proof - IV

* Last step

- Iterative algorithm :
 - Subtract 2ⁿ⁻¹N from U
- * Booth's algorithm
 - * The last two bits are 10 (0 \rightarrow 1 transition)
 - Subtract 2ⁿ⁻¹N from U
- * Both the algorithms compute :
 - * $MN = M'N 2^{n-1}N$
 - * in the last iteration



Outline of a Proof - V


- * Case 11
- * Suppose we were multiplying M' with N
 - Since (M' > 0), the Booth multiplier will correctly compute the product as M'N
 - * The two msb bits of M' are (01)
 - In the last iteration (currBit, prevBit) is 01
 - * We would thus add 2ⁿ⁻¹N in the Booth's algorithm to the partial product in the last iteration
 - The value of the partial product at the end of the (n-1)th iteration is thus:
 - * M'N 2ⁿ⁻¹N




Outline of a Proof - VI

- * When we multiply M with N
 - * In the $(n-1)^{th}$ iteration, the value of the partial product is : $M'N 2^{n-1}N$
 - * Because, we have no way of knowing if the multiplier is M or M' at the end of the (n-1)th iteration
 - In the last iteration the msb bits are 11
 - * no action is taken
 - * Final product : $M'N 2^{n-1}N = MN$ (correct)












Time Complexity

- * O(n log(n))
- * Worst case input
 - * Multiplier = 10101010... 10




O(log(n)²) Multiplier

- * Consider an *n* bit multiplier and multiplicand
- * Let us create *n* partial sums





Tree Based Adder for Partial Sums






Time Complexity

- * There are log(n) levels
- * Each level takes
 - * Maximum log(2n) time
 - * Adds two 2n bit numbers
- * Total time:
 - * $O(\log(n) * \log(n)) = O(\log(n)^2)$



Carry Save Adder



- * A + B + C = D + E
- * Takes three numbers, and produces two numbers



1 bit CSA Adder

- * Add three bits a, b, and c
 - * such that a + b + c = 2d + e
 - * d and e are also single bits
- * We can conveniently set
 - * e to the sum bit
 - * d to the carry bit



n-bit CSA Adder

$$A + B + C = \sum_{i=1}^{n} A_i 2^{i-1} + \sum_{i=1}^{n} B_i 2^{i-1} + \sum_{i=1}^{n} C_i 2^{i-1}$$

$$= \sum_{i=1}^{n} (A_i + B_i + C_i) 2^{i-1}$$

$$= \sum_{i=1}^{n} (2D_i + E_i) 2^{i-1}$$

$$= \sum_{i=1}^{n} D_i 2^i + \sum_{i=1}^{n} E_i 2^{i-1}$$



$$= D + E$$

n-bit CSA Adder - II

- * How to generate D and E?
 - Add all the corresponding sets of bits (A_i, B_i, and C_i) independently
 - * set D_i to the carry bit produced by adding (A_i, B_i, and C_i)
 - set E_i to the sum bit produced by adding (A_i, B_i, and C_i)
- Time Complexity:
 - All the additions are done in parallel
 - This takes O(1) time




Wallace Tree Multiplier

* Basic Idea

- Generate n partial sums
- * Partial sum : $P_i = 0$, if the ith bit in the multiplier is 0
- * $P_i = N \ll (i-1)$, if the the ith bit in the multiplier is 1
- Can be done in parallel : O(1) time
- Add all the n partial sums
 - Use a tree based adder



Tree of CSA Adders





Tree of CSA Adders

- * Group the partial sums into sets of 3
 - * Use an array of CSA adders to add 3 numbers (A,B,C) to produce two numbers (D,E)
 - Hence, reduce the set of numbers by 2/3 in each level
- * After $log_{3/2}(n)$ levels, we are left with only two numbers
- * Use a CLA adder to add them




Time Complexity

- * Time to generate all the partials sums \rightarrow O(1)
- * Time to reduce n partial sums to sum of two numbers
 - * Number of levels \rightarrow O(log(n))
 - * Time per level \rightarrow O(1)
 - * Total time for this stage \rightarrow O(log(n))
- * Last step
 - * Size of the inputs to the CLA adder \rightarrow (2n-1) bits
 - * Time taken \rightarrow O(log(n))
- * Total Time : O(log(n))



Outline

- * Addition
- * Multiplication
- Division



- * Floating Point Addition
- Floating Point Multiplication
- * Floating Point Division



THE END

