



ROW1	MX_KEY K1	MX_KEY K5 2ndF 1 0 2	MX_KEY K9	MX_KEY K13 COMP 1 0 2	MX_KEY K17	MX_KEY K21 F<->E 1 0 0 2	MX_KEY K25	MX_KEY K29 OFF 1 0 2	MX_KEY K33 x->M 1 0 2	MX_KEY K37 ON 1 0 2
	MX_KEY K2	MX_KEY K6 DRG 1 0 2	MX_KEY K10	MX_KEY K14	MX_KEY K18	MX_KEY K22	MX_KEY K26	MX_KEY K30	MX_KEY K34 RM 1 0 2	MX_KEY K38 CE 1 0 0 2
ROW2	MX_KEY K3	MX_KEY K7	MX_KEY K11	MX_KEY K15	MX_KEY K19	MX_KEY K23	MX_KEY K27	MX_KEY K31	MX_KEY K35	MX_KEY K39
ROW3	MX_KEY K4	MX_KEY K8	MX_KEY K12	MX_KEY K16	MX_KEY K20	MX_KEY K24	MX_KEY K28	MX_KEY K32	MX_KEY K36	MX_KEY K40
ROW4	1 0 2	1 0 2	1 0 2	root 2	1002	x2 1 0 2	1 0 2	1 0 2	1 0 2	1 0 2
	COL1	COL2	COL3	COL4	COL5	9700	COL7	COI.8	6700	COL10





