Expansion connector (CN8) CAN (UCANPHY micro) ← Neopixel (CN12) (CN4 & CN5) I2C qwiic (CN2) **USB** (on Pico on back side) serial (CN3) servo (CN7) Reset button (SW1) Status LED (D4 & D5)