

Hard Reset BBPOS EMV Readers

Step 1: Locate the square-shaped BBPOS EMV device



Step 2: Locate the 'Reset Button' hole.



Step 3: Press & Hold the "Reset Button" by placing a small object (paperclip or toothpick) inside hole for 10 seconds.



Step 4: After pressing the "Reset Button", plug everything back in and restart the terminal.

