

THE SCREW-IN PIPE SUPPORT

SET IT ONCE. IT HOLDS.

The height-adjustable screw anchor that supports water and sewage lines in soft, uneven ground — no digging, no concrete, no callbacks.

NO DIGGING

NO CONCRETE

INSTALLS IN SECONDS

FIELD PROVEN

THE PROBLEM

SAGGING LINES	lost grade, standing waste
SHIFTING BEDDING	settles after backfill
CONCRETE & CRIBBING	slow, heavy, permanent
REWORK	dig it up, do it again

WHY EZE-SET WINS

SOFT & UNEVEN GROUND	the auger bites deep
REUSABLE & REMOVABLE	back it out, reset it
CORROSION-PROOF	built for buried, wet service
GRADE ON DEMAND	adjust before or after backfill

THE SYSTEM

THREE PARTS. ZERO FUSS.



ANCHOR, PLATE & CRADLE

01 SCREW ANCHOR

One piece, threaded to the point. Drives straight into soft or uneven ground and stays put — no excavation, no poured base.

02 ADJUSTER PLATE

Threads up and down the shaft to set height. Your grade control lives on the anchor itself, so fine-tuning never means re-digging.

03 PIPE CRADLE

Locks onto the bolt head and grips the line — no sag, no shift, no drift. Interchangeable cradles fit multiple pipe sizes.



ANCHORED & SET



CRADLE LOCKED



GRADE CONTROL



HOLDS IN THE MUCK

HOW IT WORKS

THREE STEPS. ONE TOOL.

01 DRIVE Screw it in. The threaded auger anchors deep in seconds, even where other supports can't bite.	02 SET Drop the pipe into the cradle. It locks onto the bolt head and grips the line — no sag, no shift, no drift.	03 DIAL IN Thread the adjuster plate up or down to hit exact grade. Fine-tune anytime, before or after backfill.
--	---	---

ON THE JOB

WORKS THE WAY YOU DO.

PRESSURE SYSTEMS Complete the full piping install, then drill the holes for the “squirt” test and run it. Once testing is done, set the chamber over top — no additional supports, and no zip-tying the pipes to the chamber.	GRAVITY-FEED SYSTEMS Set the grade and run your testing. Then set the chambers over top for the final install — the line stays exactly where you dialed it in.
---	--

SPECIFICATIONS

AT A GLANCE

PIPE CAPACITY	Fits 1”–4” pipe — one anchor family across the full range, with interchangeable cradles.
GROUND CONDITIONS	Clay, gravel, sand, or sandy-loam soils. Holds in soft, uneven ground where blocking can't.
MATERIAL	Impact-resistant ABS — a proven record of longevity in underground applications. Corrosion-proof in buried, wet service. UV-resistant type available for above-ground irrigation and exposed runs.
INSTALLATION	Direct burial into native soils. Screw-in by hand or driver — no excavation, no concrete, no cribbing.
HEIGHT ADJUSTMENT	Threaded adjuster plate travels the shaft for exact grade; adjustable before or after backfill.
SERVICEABILITY	Fully reusable and removable — back it out and reset it. Nothing poured, nothing left behind.

LAUNCHING 2026

GET EZE-SET FIRST.

Distributor, contractor, or utility? Ask for pricing, samples, and availability from the first production run.

PRICING & AVAILABILITY

btownebill2020@gmail.com

DEMO VIDEO & DETAILS

ezset.ca