

1Raise

03/10/2019

Principle I

- *Raise is development, excavated in upward direction.
- *Raise can be vertical or incline.
- *Inclination of raises varies in between 90 degree to 15 degree.
- *Incline up ward development, through which man can not walk up with out any aid (rope, ladder, car, lift etc) is called raise.

Applicability I

- *Raises are applicable in ore body, whose dip exceeds 15 degree or above.
- *Raises are excavated along with shaft for purposes like ore handling, shaft bottom cleaning, ventilation.
- *Ore pass is excavated by raising.
- *Raise is used for ventilation, communication, movement of person with help of ladder, rope etc.
- *Flat deposit also require raise to develop different facilities.
- *Vertical or incline raise is used for excavating shaft.

Applicability II

- *Raise is used for stope development.
- *Raise is used as entry to ore body.
- *Raise is part of stoping as slot raise, finger raise, ore draw funnel etc.
- *Raise is used as second entry to mine.
- *Raise is used as emergency exit from mine or part of mine.
- *

Reference I

*