








| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>7. Check the license list. There should be an <b>EdgeOne Node License</b> and <b>EdgeIPS Pro 216 Software License</b></p>  <p><b>Update EdgeIPS Pro 216 firmware and patterns</b></p> <ul style="list-style-type: none"> <li>- Go to <b>Admin &gt; Licensing &amp; Updates &gt; Component Updates &gt; Edge Devices</b>, find the “Actions” column and:</li> <li>- Click <b>Update Now</b> for following patterns <ul style="list-style-type: none"> <li>TXOne Antivirus Patterns for EdgeIPS Pro</li> <li>TXOne CPSDR Patterns for EdgeIPS Pro</li> <li>TXOne IPS Pattern (v2) for EdgeIPS Pro</li> </ul> </li> <li>- Click Upload for <b>EdgeIPS Pro Series Firmware</b> and upload the file from <b>Desktop\Training\Edge\EdgeIPSPro</b></li> </ul>  |



| Items           | Descriptions                                                                                                                                                                                                                                                                                                                                                                                |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <p>8. Notice the green banners indicating when the software has been successfully imported. The Device tab will display the latest versions and release dates.</p>  <p>9. Now change the VMware network adapter for the <b>EdgeOne</b> server and the <b>LabConsole</b> to <b>bridged (VMnet11)</b>".</p> |
| Expected Result | <p>EdgeOne configuration tasks completed.</p> <ul style="list-style-type: none"> <li>- Date / Time settings and Time Zone setup.</li> <li>- EdgeOne upgraded to latest version</li> <li>- Licenses activated.</li> <li>- Device components updated.</li> </ul>                                                                                                                              |



## Lab3: EdgeIPS Pro 216 Hardware, Installation and Lab setup.

**Table 7 EdgeIPS Pro 216 Hardware and Installation**

| Items              | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application target | Host A and B                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Steps              | <p><b>Din Rail Mounting (Informational)</b></p>  <p><b>Power Supply Connection</b></p> <ol style="list-style-type: none"> <li>EdgeIPS Pro 216 supports dual power input.</li> <li>Verify the power supply <b>polarity</b> (V+, V-) before you connect power socket to EdgeIPS Pro 216.</li> <li>DC Jack: 12V, Terminal block: 12 - 48V</li> </ol>  |


| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p><b>EdgeIPS Pro 216 Lab network wiring and VMWare configuration</b></p> <ol style="list-style-type: none"> <li> <p>EdgeIPS Pro 216 hardware network wiring diagram.</p> <p><b>Do not turn on the EdgeIPS Pro 216 yet.</b></p>  </li> <li> <p><b>(Optionally)</b> Assign physical host IP address 1.1.1.1/32 for <b>Host A</b> LAN Adapter and physical host IP address 1.1.1.2/32 for <b>Host B</b> LAN Adapter. This provides additional network isolation with the Lab network.</p>  </li> <li> <p>Bridge the VMWare network adapter to the physical network interface.</p> </li> <li> <p>In VMware workstation, go to the VMWare Virtual Network Editor. <b>Bridge</b> VMnet11 to your physical UTP LAN Adapter. <b>This is an important step.</b> Make sure to bridge to the right physical network adapter. (no virtual adapter, no wifi adapter,...)</p> </li> </ol> |

| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|-------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p><b>Note:</b></p> <p>Bridging a VMnet (virtual) network adapter to a specific physical LAN adapter may not be possible if one of the VMnet adapters is set to “<b>Auto</b>” mode. To resolve this, change the adapter from “<b>Auto</b>” to “<b>Bridged</b>” and assign it to the specific physical network card connected to your physical UTP port.</p>  <ol style="list-style-type: none"> <li>Now that the Virtual Network has been configured, connect your VMS to the right virtual network.</li> <li><b>Host A</b> bridged (VMnet11): EdgeOne, LabConsole (<b>Stop all other VMs on host A</b>)</li> <li><b>Host B</b> bridged (VMnet11): Win7 (<b>Stop all other VMs on host B</b>)</li> </ol>  |

| Items           | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <p>8. In VMWare, open the VM images <b>Win7 (do this on Host B!)</b></p> <p>9. Restore the VM <b>Win7</b> to snapshot <b>ReadyforLabs</b>. In VMware workstation, double-check the Network adapter of this VM: it must be set to <b>bridged (VMnet11)</b>.</p> <p>10. Power on the VM. Click "<b>I Moved It</b>" when this is the first power on of this VM</p>  <p>11. Log in using the following credentials.<br/>User: <b>txone</b> (TXOne Expert)<br/>Password: <b>12345678</b></p> <p>12. Log in to the VM <b>LabConsole (on Host A)</b>, open "<b>cmd.exe</b>" and ping 192.168.23.24 (<b>Win7</b>). Make sure you are on Host A and the <b>Win7</b> is only running on Host B (It must not run on Host A as well.) This ping will test the network connection between the <b>LabConsole</b> on Host A and <b>Win7</b> on Host B.</p>  |
| Expected Result | EdgeIPS Pro 216 Wiring completed and VMWare network environment configuration completed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

## Lab4: EdgeIPS Pro 216 device initialization


**Table 8 EdgeIPS Pro 216 device initialization**

| Items              | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application target | <b>Host A</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Steps              | <ol style="list-style-type: none"> <li>Turn on the EdgeIPS Pro 216 (Connect the power supply plug to the EdgeIPS Pro 216). During power-on, the “<b>PWR1</b>” LEDs will be on. The port status LED will be RED, that means port in fail open mode. The EdgeIPS Pro 216 is still booting and it is connecting Port1 to Port2 without any traffic inspection.</li> </ol>  <p>The image shows the EdgeIPS Pro-216 device with a green power supply plug connected to the PWR1 12V port. The PWR1 LED is illuminated green. The STATE LED is illuminated red. The MGMT USB port is visible. The device is labeled 'TREND MICRO EdgeIPS Pro-216 SECURED BY txOne networks'.</p> <ol style="list-style-type: none"> <li>Once the EdgeIPS Pro 216 has booted, the “<b>PWR1</b>” LED and the “<b>STATE</b>” LED should be on.</li> </ol>  <p>The image shows the EdgeIPS Pro-216 device with the PWR1 LED and the STATE LED both illuminated green. The MGMT USB port is visible. The device is labeled 'TREND MICRO EdgeIPS Pro-216 SECURED BY txOne networks'.</p> <ol style="list-style-type: none"> <li><b>Factory-reset the EdgeIPS Pro 216</b><br/>Before using the EdgeIPS Pro 216, make sure to reset it (it may have been used by another student in another training). It may have been set to an IP that we don't know and it may have policies that we don't want.</li> </ol> |

To factory reset the EdgeIPS Pro 216, follow these steps:

- Insert a paperclip into the reset hole and press the switch.
- Keep pressing for a few seconds until the "**STATE**" LED starts blinking slowly. Continue holding until it blinks faster. At this point, the device has reset itself, and you can release the button.
- Avoid using a thick paperclip, sharp objects, or excessive force to prevent damage to the reset switch.

4. Launch the Chrome browser from **LabConsole** VM and go to: <https://192.168.127.254>. This should be reachable because the **LabConsole** VM has a secondary IP address in this network. You can check this by running "**ipconfig**".
5. Log in to the EdgeIPS Pro 216 device web console using following credentials and accept the EULA.  
**User: admin**  
**Password: txone**
6. You will be prompted to create a new user and set password. Create the following user: **txone** with the password: **12345678**





**Login Information Setup**



Change the default login name and password to prevent unauthorized access to your account.


New Login Name (ID)\*

New Password\*

Confirm Password\*


| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>7. Re-Log in to the EdgeIPS Pro 216 device web UI using the new credentials “txone/12345678”.</p>  <p>8. The EdgeIPS Pro 216 Device Web UI will show up when Log in was successful.</p>  <p>9. Go to <b>Network &gt; Device Settings</b> to configure a new device IP address of the EdgeIPS Pro 216.</p> <p><b>Device IP address:</b> 192.168.23.205</p> <p><b>Netmask:</b> 255.255.255.0</p> <p><b>Gateway:</b> 192.168.23.2</p> |



| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       |  <p>10. Click <b>“Save”</b>.</p> <p>11. Re-log in to the EdgeIPS Pro 216 device web UI using new device IP address, <a href="https://192.168.23.205">https://192.168.23.205</a></p>  <p>12. Set the Logout Timer to 60 minutes</p> <p>Navigate to <b>Administration &gt; Logout timer</b> (all the way down; the last option in the list... it may not be visible on the screen without scrolling down). Set the <b>“Log off idle users after”</b> to 60 minutes</p> |

| Items               | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                     |  <p>The screenshot shows the EdgIPS Pro web interface. The top navigation bar includes 'System', 'Visibility', 'Network', 'Object Profiles', and 'Security'. The breadcrumb trail indicates 'Administration &gt; Logout Timer'. The 'Logout Timer Setting' section shows 'Log off idle users after' with a dropdown menu set to '60 Minutes'. The dropdown menu is open, showing options: '10 Minutes', '15 Minutes', '30 Minutes', '60 Minutes' (selected and highlighted with a red box), and '60 Minutes' (repeated at the bottom). There are 'Save' and 'Cancel' buttons below the dropdown.</p> |
| Result and Comments | EdgIPS Pro 216 initialized successful and new device IP address assigned.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

## Lab5: Register EdgeIPS Pro 216 with EdgeOne for centralized management

**Table 9 Register EdgeIPS Pro 216 with EdgeOne for centralized management**

| Items              | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application target | <b>Host A</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Steps              | <ol style="list-style-type: none"> <li>Go to the EdgeIPS Pro 216 device web UI, go to <b>Administration &gt; System Time</b></li> <li>Configure System Time Settings</li> <li>If you are using the EdgeIPS Pro 216 in stand-alone mode, you need to setup NTP and the time zone here.<br/><br/>In our lab setup, we will link the EdgeIPS Pro 216 to the EdgeOne server. Once this is configured, the EdgeIPS Pro 216 will sync its time from EdgeOne.</li> <li>For the purpose of this training, set the Time Zone to <b>UTC</b></li> </ol>  |



| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>5. Go to <b>Administration &gt; Connection Settings</b> and configure the EdgeOne Server Address: <b>192.168.23.21</b> and click <b>Save</b>.</p>  <p>6. The connection status will show <b>“Connecting”</b> and after a few seconds when it has successfully connected to EdgeOne, it will change to <b>“Connected”</b>. If it remains in <b>“Connecting”</b> then the EdgeIPS Pro 216 is not able to connect to EdgeOne. This can be caused by a firewall on your laptop or by Security Software that runs on your laptop. (try to disable it to allow incoming connections) If you can’t fix this, ask your instructor for help.</p>  |




| Items           | Descriptions                                                                                                                                                                                                                                                                                        |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                 | <p>7. Check the EdgeIPS Pro 216 status LEDs, the “<b>MANAGED</b>” LED should be green. This means the EdgeIPS Pro 216 is managed by EdgeOne and the connection between EdgeIPS Pro 216 and EdgeOne is alive.</p>  |
| Expected Result | EdgeIPS Pro 216 registration to EdgeOne successful                                                                                                                                                                                                                                                  |




## Lab6: Device Group Management




**Table 10 Device Group Management**




| Items              | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application target | <b>Host A</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Steps              | <ol style="list-style-type: none"> <li>Log in to the VM <b>LabConsole</b> and navigate to <a href="https://192.168.23.21">https://192.168.23.21</a>.<br/>Log in with the following credentials:<br/><b>User: txone</b><br/><b>Password: 12345678</b></li> <li>Go to <b>Node &gt; EdgeIPS Family &gt; EdgeIPS Pro</b> and check if a new EdgeIPS Pro 216 is listed under the Device Group <b>"Ungrouped"</b>. Now upgraded the EdgeIPS Pro 216 to firmware version 2.x.</li> <li>Click <b>"Upgrade firmware"</b>.</li> </ol> |








| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>4. Click on <b>“Update”</b> to upgrade the EdgeIPS Pro 216 102 to the latest version of version 2.1 firmware.</p>  <p>5. There will be a <b>“Update Firmware”</b> icon next to the EdgeIPS Pro 216.</p>  <p>6. Once the upgrade task has completed, there will be a Green Check Mark.</p>  <p>7. Click <b>“Switch to Standby Firmware”</b> to switch the uploaded firmware from the “standby” partition to the “running” partition.</p>  |



| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>8. Click <b>“Yes”</b> to switch it to the running partition.</p>  <p>9. The EdgeIPS Pro 216 device icon will become grayed-out during the firmware switching process.</p>  <p>10. The EdgeIPS Pro 216 will come back online once the firmware switch is complete. The warning badge will disappear, and a green indicator will appear on the device icon.</p>  <p>11. Set the Edge Device Authentication Method to <b>“Passcode”</b> for a more secure authentication. Go to <b>Admin &gt; System &gt; Connection Settings &gt; Edge Device Authentication</b>. Configure the authentication method to <b>“Passcode”</b>: 12345678, apply to EdgeIPS Pro and click <b>“Save”</b>.</p> |

| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       |  <p>12. Go to the EdgeIPS Pro 216 Device web UI <a href="https://192.168.23.205">https://192.168.23.205</a>, go to <b>Admin &gt; System &gt; EdgeOne Connection Settings</b>. Configure the Authentication Method to the “Passcode”, Enter “12345678” and click “Test Connection”.</p>  <p>13. The web UI will show the result of test.<br/>Click “Save” if the connection test succeeded.</p>  |


| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|-------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>14. Go to the EdgeOne web UI <a href="https://192.168.23.21">https://192.168.23.21</a>. Go to <b>Admin &gt; Licensing &amp; Updates &gt; License Management</b>. You'll see there is 8 EdgeIPS Pro "Seat Count".</p>  <p>15. Go to <b>Node &gt; EdgeIPS Family &gt; EdgeIPS Pro</b> and click "Create New Edge Group" .</p>  <p>16. Name the group: "FAB12-10-27".</p>  |





| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>17. Select the Edge group “FAB12-10-27” and click “Edit Edge Group Settings”</p> <p></p>  <p>18. Enable all features under Edit Group Settings and click “Save”.</p>  <p>19. Click “Yes” to save the settings.</p>  |

| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p><b>Move the EdgeIPS Pro 216 from “Ungrouped” to “FAB12-10-27”</b></p> <ol style="list-style-type: none"> <li>1. Select <b>“Ungrouped”</b> from the Edge Group list.</li> <li>2. Select the EdgeIPS Pro 216 and click <b>“Change Group”</b>  .</li> </ol>  <ol style="list-style-type: none"> <li>3. Move the EdgeIPS Pro 216 to the group <b>“FAB12-10-27”</b>.</li> </ol>  <ol style="list-style-type: none"> <li>4. Select the Edge group <b>“FAB12-10-27”</b>. There should now be one EdgeIPS Pro 216 device in it. There may still be a yellow light next to the EdgeIPS Pro 216 device icon. This means EdgeOne is now syncing group policy settings with EdgeIPS Pro 216.</li> </ol> |

| Items               | Descriptions                                                                                                                                                                                                                                                                                          |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                     |  <p>5. The indicator will change to green when the EdgeOne group policy settings are synced with the EdgeIPS Pro 216 device.</p>  |
| Result and Comments | EdgeIPS Pro 216 Edge group “FAB12-10-27” created and EdgeIPS Pro 216 moved into it.                                                                                                                                                                                                                   |

## Lab7: Policy Enforcement Configuration

| Items              | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Application target | Host A and B                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Steps              | <p><b>Things to check before starting this Lab exercise.</b></p> <ol style="list-style-type: none"> <li>The <b>LabConsole</b> VM (which must run on <b>Host A</b>) has a hosted <b>FTP</b> server and a <b>web</b> server. Those will be used to verify the EdgeIPS Pro 216 policy enforcement.</li> <li>In the next steps, you will “<b>Download files over FTP</b>” or “<b>Download files over HTTP</b>”. Both activities are done from the <b>Win7</b> virtual machine, which should run on <b>Host B</b>.<br/>Use the following credentials.<br/><b>User: txone</b><br/><b>Password: 12345678</b></li> <li>Let’s first test if this works without the EdgeIPS Pro 216 (the EdgeIPS Pro 216 should be <b>powered off</b>)</li> </ol> <p><b>Download files over FTP.</b></p> <p>This is a “Standard Operating Procedure” (SOP). It can be seen as a “<b>subroutine</b>” in this lab. In the next steps, you will be asked to do this SOP a few times, but every time with different policy settings in the EdgeIPS Pro 216.</p> <ol style="list-style-type: none"> <li>On the VM <b>Win7</b>, which should run on <b>Host B</b>, open <b>cmd</b> from task bar</li> </ol>  |

| Items | Descriptions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|       | <p>2. Enter <b>"CD \users\txone\desktop"</b></p>  <p>3. Enter <b>ftp 192.168.23.196</b> to Log in to the FTP server, using the following credentials<br/> <b>User: user</b><br/> <b>Password: 12345678</b></p>  <p>4. Enter <b>"cd training"</b> to go to the <b>"training"</b> directory.</p> <p>5. Enter <b>"bin"</b> to switch to binary mode.</p>  <p>6. Enter <b>"get PE-in-zip.zip"</b> and <b>"get text-file.txt"</b> and check if the files have download successfully or not. If the download was successful, you should see the files on your desktop.</p>  |