







LASER RRE-LEATV-920

SETUP FOR BRAND


To switch brand, hold down **⏻** + number key until LED blink

SAMSUNG	⏻+1	LG	⏻+2
SONY	⏻+3	PHILIPS	⏻+4
PANASONIC	⏻+5	SHARP	⏻+6
TOSHIBA	⏻+7	HISENSE	⏻+8
GRUNDIG	⏻+9		

LEARNING




FACTORY RESTORE



LASER

RRE-LEATV-920

The function of two shortcuts button may be differ depend on the TV brand you are using.



SAMSUNG

N NETFLIX **Y** PRIME VIDEO

LG

N NETFLIX **Y** YOUTUBE

PHILIPS

N NETFLIX **Y** YOUTUBE

PANASONIC

N NETFLIX **Y** PRIME VIDEO

SHARP

N NETFLIX **Y** YOUTUBE

TOSHIBA

N NETFLIX **Y** YOUTUBE

HISENSE

N NETFLIX **Y** YOUTUBE

GRUNDIG

N NETFLIX **Y** YOUTUBE