

## **AN1760**

# Interfacing the AD8402 Digital Potentiometer to the MC68HC705J1A

By Mark Glenewinkel Field Applications Engineering Consumer Systems Group Austin, Texas

#### Introduction

The digital potentiometer (DP) allows many of the applications of mechanical trimming potentiometers to be replaced by a solid-state solution. The digital potentiometer has several benefits over a mechanical potentiometer, including compact size, freedom from shock or vibration, and the ability to withstand oil, dust, temperature extremes, and moisture.

The interface of a DP allows it to be electronically controlled by a microprocessor or microcontroller so that the user can adjust system parameters quickly and precisely. Also, automatic system initialization and calibration at the point of manufacture can be provided to increase accuracy and timeliness on the production line.

#### Some DP applications are:

- Volume control and panning
- LCD (liquid crystal display) contrast control
- Automatic gain control
- Programmable filters, delays, and time constants
- Power supply adjustment





## **Application Note**

Two major configurations of the DP include the rheostat (2-terminal configuration) and the potentiometer divider (3-terminal configuration).

This application note describes the interface between the MC68HC705J1A (J1A) and Analog Devices, Inc.'s AD8402 to create these configurations for various analog circuits. Since the J1A does not have a serial module on chip, a software I/O (input/output) driver is created to provide the appropriate serial bus signals to the AD8402.

Circuitry and example code are given to demonstrate the interface between the two parts.

#### AD8402 Overview

The AD8402 is a member of a series of digital potentiometers. This family consists of one, two, or four potentiometers. These are the AD8400, AD8402, and AD8403. This application note utilizes the AD8402 with a 50-k $\Omega$  fixed resistance per potentiometer.

#### **Features**

The AD8400 series of digital potentiometers provides these features:

- 256-position variable resistors
- Replaces one, two, or four mechanical potentiometers
- Devices are available in resistance values of 1 k $\Omega$ , 10 k $\Omega$ , 50 k $\Omega$ , and 100 k $\Omega$
- Power shutdown mode consumes less than 5 μA
- 3-wire SPI-compatible serial bus interface
- Midscale preset on device power-up
- +2.7 volt to +5.5 volt single-supply operation
- 8/14/24-pin DIP (dual in-line), 8/14/24-pin SOIC (small outline integrated circuit), and 14/24-pin TSSOP packages



Application Note AD8402 Overview

#### Description

The AD8400 series provides 256-position digitally controlled variable resistors (VR). The VR is designed with a fixed resistor value that has a wiper contact that taps the resistor at a point that is determined by an 8-bit digital code. The resistance between the wiper and either endpoint of the fixed resistor varies linearly with respect to the digital code latched into the VR. Each VR offers a programmable resistance between the A terminal and the wiper and the B terminal and the wiper. A unique switching circuit minimizes the inherent glitch found in traditional switched resistor designs by avoiding any make-before-break or break-before-make operation.

Each VR has its own latch to hold the 8-bit digital value defining the wiper position. These latches are updated from a 3-wire SPI (serial peripheral interface). Ten bits make up the data word needed for the serial input register. The first two address bits select a VR to modify and are then followed by eight data bits for the VR latch. The bits are clocked on the rising edge of the serial clock MSB (most significant bit) first. The  $\overline{\text{CS}}$  pin starts a serial transaction by going low and then latches the 10 bits of data clocked by going back high.

The AD8402 provides system enhancements such as VR reset and VR shutdown. When the  $\overline{RS}$  pin goes low, the values of the VR latches reset to a midscale value of \$80. When the  $\overline{SHDN}$  pin goes low, the part forces the resistor to an end-to-end open circuit on the A terminal and shorts the B terminal to the wiper. While in shutdown mode, the VR latches can be updated to new values. These changes will be active when the  $\overline{SHDN}$  pin goes back high.



## **Application Note**

#### **AD8402 Hardware Interface**

Pinout and Pin Descriptions

Figure 1 and Table 1 illustrate and describe the AD8402 pinout.




Figure 1. AD8402 Pinout

**Table 1. AD8402 Pin Descriptions** 

Pin	Symbol	Name	I/O/PWR	Description	
1	AGND	Analog ground	PWR	Analog ground; must be connected to DGND	
2	B2	B2 terminal	I/O	Terminal B for VR #2	
3	A2	A2 terminal	I/O	Terminal A for VR #2	
4	W2	W2 wiper	I/O	Wiper for VR #2	
5	DGND	Digital ground	PWR	Ground pin for digital circuitry	
6	SHDN	Shutdown	I	Shutdown controls VR1, VR2; makes terminal A an open circuit	
7	CS	Chip select	I	Selects the AD8042; when the $\overline{\text{CS}}$ pin goes high, the serial input register is decoded and the VR data is loaded	
8	SDI	Serial data	I	Input pin for the serial interface	
9	CLK	Serial clock	I	Clock pin for the serial interface, positive edge triggered	
10	RS	Reset	I	When RS goes low, VRs are reset to a midscale reading of \$80	
11	$V_{DD}$	Power	PWR	Positive power supply; speci ed for operation at +3 V and +5 V	



Application Note AD8402 Hardware Interface

**Table 1. AD8402 Pin Descriptions (Continued)** 

Pin	Symbol	Name	I/O/PWR	Description
12	W1	W1 wiper	I/O	Wiper for VR #1
13	A1	A1 terminal	I/O	Terminal A for VR #1
14	B1	B1 terminal	I/O	Terminal B for VR #1

#### **Block Diagram**




Figure 2. AD8402 Block Diagram

#### **Serial Bus Timing**

The serial port interface for the AD8402 is shown in **Figure 3**. Only logic levels are shown. Consult the AD8402 data sheet if detailed AC electrical characteristics are needed.



## **Application Note**




Figure 3. Serial Data Timing

**Table 2** is the logic truth table that describes the interaction among the CLK,  $\overline{CS}$ ,  $\overline{RS}$ , and  $\overline{SHDN}$  pins.

**Table 2. Control Truth Table** 

CLK	CS	RS	SHDN	Register Activity
0	0	1	1	No SR effect; enables SDO pin
Positive edge	0	1	1	Shift a bit in from SDI pin
X	Positive edge	1	1	Load SR data into addressed VR latch
X	1	1	1	No operation
Х	Х	0	1	Sets all VR latches to midscale reading of \$80
X	1	Positive edge	1	Latches all VR latches to \$80
Х	1	1	0	Open circuits all A terminals, connects wiper to B terminal



Application Note AD8402 Software Interface

#### **AD8402 Software Interface**

#### **Data Format**

The serial interface requires data to be in the format shown in **Figure 4**. First, the address bits of A1 and A0 must be sent. For the single channel AD8400, A1 = A0 = 0. For the dual channel AD8402 which is used in this application note, A1 = 0.

The next eight bits are the data value to be latched into the VR.




Figure 4. Data Format

## Programming the Variable Resistor

The nominal resistance,  $R_{AB}$ , between terminals A and B of the AD8402 used in this application note is 50 k $\Omega$ . The  $R_{AB}$  of the VR has 256 resistive contact points that can be accessed by the wiper terminal plus the B terminal contact.

For an 8-bit value of \$00, the wiper starts at the B terminal. The B terminal has an inherent resistance of 50  $\Omega$ . The next resistive connection has a digital value of \$01. It has a value equal to the B terminal resistance plus an LSB resistor value.

For the 50-k $\Omega$  part that is used, this LSB amount is equal to 50 k $\Omega$ /256 or 195.3125  $\Omega$ . Therefore, the resistive value at \$01 is 245.3125  $\Omega$  (50  $\Omega$ +195.3125  $\Omega$ ).

Each LSB increase moves the wiper up the resistor ladder until the last tap point is hit.



#### **Application Note**

Resistive value between terminal B and the wiper can be described as:

$$R_{WB}(D) = D * (R_{AB}/256) + R_{B}$$

where

R<sub>WB</sub> = resistance between the wiper and terminal B

D = digital value of the VR latch

 $R_{AB}$  = the nominal resistance between terminal A and B = 50 k $\Omega$ 

 $R_B$  = the resistance of terminal B = 50  $\Omega$ 

Table 3 illustrates this relationship.

Table 3.  $R_{WB}$  Resistance Values with  $R_{AB} = 50 \text{ k}\Omega$ 

D <sub>10</sub>	R <sub>WB</sub> (Ω)	Output State
255	49,854.6875	Full scale
128	25,050	Midscale
1	245.3125	1 least signi cant bit (LSB)
0	50	Zero-scale

NOTE:

Note that the zero-scale value produces a resistance of 50  $\Omega$ . Care should be taken to limit the current flow between the wiper and terminal B to a maximum value of 5 mA.

The VR is totally symmetrical. The resistance between the wiper and terminal A also produces a resistance value of  $R_{WA}$ . When setting the resistance for  $R_{WA}$ , the digital value of \$00 starts the resistance setting at its maximum value. As the digital value is increased, the  $R_{WA}$  resistance decreases.

This can be described as:

$$R_{WA}(D) = (256-D) * (R_{AB}/256) + R_{B}$$

where

 $R_{WA}$  = resistance between the wiper and terminal A

D = digital value of the VR latch

 $R_{AB}$  = the nominal resistance between terminal A and B = 50 k $\Omega$ 

 $R_B$  = the resistance of terminal B = 50  $\Omega$ 



Application Note Digital Potentiometer Applications

Table 4 illustrates this relationship.

Table 4.  $R_{WA}$  Resistance Values with  $R_{AB} = 50 \text{ k}\Omega$ 

D <sub>10</sub>	R <sub>WA</sub> (Ω)	Output State
255	245.3125	Full scale
128	25,050	Midscale
1	49,854.6875	1 least signi cant bit (LSB)
0	50,050	Zero scale

Programming the Potentiometer Divider The digital potentiometer can be easily used to generate an output voltage proportional to the voltage applied between terminals A and B. If terminal A is connected with +5 V and terminal B is connected to ground, the wiper voltage has a range of 0 V up to 1 LSB less than the +5 V. Each LSB is equal to the voltage across terminals A and B divided by 256. The wiper's output voltage can be described as;

$$V_W(D) = (D/256) * V_{AB} + V_{B}$$

where

V<sub>W</sub> = voltage on wiper

D = digital value of the VR latch

 $V_{AB}$  = voltage across terminal A and B

 $V_B$  = voltage at terminal B

## **Digital Potentiometer Applications**

Many applications can utilize the digital potentiometer to replace traditional mechanical resistors. When using the AD8042, certain boundary conditions must be observed for proper operation.

First, all analog signals must remain within the 0 to  $V_{DD}$  range used to supply the AD8042. If the potentiometer divider circuit is driving a low-impedance load, buffer the wiper with a rail-to-rail op amp like the MC33201, OP191, or OP279.



#### **Application Note**

Second, for bipolar DC applications and AC signals, a virtual ground will be needed to bias the op amp properly. For a  $V_{DD}$  of +5 V, the virtual ground must be set at 2.5 V. The connected virtual ground also must be able to sink and source current with all connected loads.

The following circuits show some basic circuits and op amp circuits implementing the digital potentiometer to program circuit parameters.

#### Variable Resistor

**Figure 5** shows the programmable resistor or digital rheostat configuration for the AD8042.




Figure 5. Programmable Resistor

#### Potentiometer Divider

**Figure 6** shows the programmable potentiometer divider for the AD8042.




Figure 6. Programmable Potentiometer Divider

**Inverting Op Amp** 

**Figure 7** shows one channel of the AD8042 connected in an inverting programmable op amp circuit. The virtual ground is set at +2.5 volts to allow the signal to span the +/–2.5-V range. Use a rail-to-rail op amp to provide maximum output swing. When powered up, the wiper is set at its midscale position of \$80.

According to the transfer function:

$$V_{Out} = -(R_{WB}/R_{WA}) * V_{In}$$

This will provide a gain of -1. As the digital value increases above its midscale position,  $R_{WB}$  increases and  $R_{WA}$  decreases. This will have an effect of amplifying the input signal. As the digital value decreases,  $R_{WB}$  decreases and  $R_{WA}$  increases and this will attenuate the signal.




Figure 7. Programmable Inverting Op Amp

Non-Inverting Op Amp

**Figure 8** shows one channel of the AD8042 connected in a non-inverting programmable op amp circuit. The virtual ground is set at +2.5 volts to allow the signal to span the +/–2.5-volt range. Use a rail-to-rail op amp to provide maximum output swing. When powered up, the wiper is set at its midscale position of \$80.

According to the transfer function:

$$V_{Out}$$
= (1+( $R_{WB}$ / $R_{WA}$ )) \*  $V_{In}$ 

This will provide a gain of +2. As the digital value increases above its midscale position,  $R_{WB}$  increases and  $R_{WA}$  decreases. This will have an effect of amplifying the input signal. As the digital value decreases,  $R_{WB}$  decreases and  $R_{WA}$  increases and this will attenuate the signal.



## **Application Note**




Figure 8. Programmable Non-Inverting Op Amp

Differential Op Amp

**Figure 9** shows two channels of the AD8042 connected in a differential programmable op amp circuit. The virtual ground is set at +2.5 volts to allow the signal to span the +/–2.5-volt range. Use a rail-to-rail op amp to provide maximum output swing. When powered up, the wiper is set at its midscale position of \$80.

According to the transfer function:

$$V_{Out} = V2_{In}^*(R_{WB2}/R_{WA2}) - V1_{In}^*(R_{WB1}/R_{WA1})$$

This will provide an output voltage of  $V2_{ln}-V1_{ln}$ . The resistor values can be changed as needed to provide amplification or attenuation to each input voltage.



Application Note Layout Considerations




Figure 9. Programmable Differential Op Amp

## **Layout Considerations**

Many considerations apply when laying out mixed signal designs such as the AD8042 and the MC68HC705J1A (J1A). Analog signal integrity may be greatly affected if proper layout design is not followed.

To ensure proper mixed-signal designs, use these design considerations:

- Physically separate critical analog circuits from the MCU's digital circuits. If possible, split the board in half to separate analog and digital circuits. Each half will have its own power and ground system and will be connected at a single post.
- If possible, do not let analog lines trace cross digital lines. If this
  must happen, make sure they cross at right angles to each other.
- Use power or ground traces to isolate the analog-input pins from the digital pins.
- With quality ceramic capacitors, bypass the power supplies to the proper ground at the operational amplifier power pins. Keep the bypass capacitors lead lengths as short as possible.



## Application Note

- To bypass low-frequency power supply noise, use tantalum or aluminum electrolytic capacitors of 5 to 20 μF. These should be placed near the point the power supplies enter the board.
- If economically possible, use separate analog and digital ground planes. The two ground planes should be tied together at the lowimpedance power-supply source.

#### MC68HC705J1A Hardware Interface

With only 20 pins, the J1A is one of the smaller members of the HC05 Family. It has a total of 1240 bytes of erasable programmable read-only memory (EPROM) and includes 14 I/O (input/output) pins. The schematic used for testing the J1A to AD8402 interface on the MMEVS development system is shown in **Figure 10**.

The pins used to drive the AD8402 on the J1A are:

- Port A, bit 0 This I/O pin (CLK) is configured as an output to drive the serial clock pin, CLK.
- Port A, bit 1 This I/O pin (SDO) is configured as an output to transmit data to the SDI pin.
- Port A, bit 2 This I/O pin (CS) is configured as an output to drive the chip select pin, CS.
- Port A, bit 3 This I/O pin (RS) is configured as an output to drive the reset pin, RS.

For further information on the MC68HC705J1A, consult the *MC68HC705J1A Technical Data*, Freescale document order number MC68HC705J1A/D.

The test circuit is designed to test the operation of the AD8402. VR1 can be used to test a potentiometer voltage divider. The voltage created on W1 of VR1 can be measured at TP1. VR2 can be used to test a variable potentiometer or rheostat. The resistance created on VR1 can be measured across TP2 and TP3.



Application Note MC68HC705J1A Test Software




Figure 10. J1A to AD8402 Interface Test Circuit

#### MC68HC705J1A Test Software

The flowcharts for the I/O-driven AD8402 appear in Figure 11 and Figure 12.

Figure 11 shows the flowchart for the transmit routine to the AD8402. This routine was written especially for the AD8402 and is not a fullfeatured representation of Motorola's SPI (serial peripheral interface) module found on other microcontrollers. Enhancements to the routine were not included to maximize the code's efficiency.

I/O driving is the process of toggling I/O pins with software instructions to emulate a certain piece of hardware peripheral. General I/O pins are used to send out the correct serial transmission protocol to the AD8402. The HC05 CPU provides special instructions to specifically manipulate single I/O pins. The AD8402 serial stream shown in Figure 3 will be recreated by three I/O pins on the J1A.



#### **Application Note**

This transmission has been put into a subroutine called TXD. The flowchart is in **Figure 11**. This subroutine is detailed here.

- 1. Start the transmission The  $\overline{CS}$  pin is written low.
- 2. *Initialization* Load the X register with 10; use it as a counter.
- 3. Write the serial output pin Bit 1 of VR\_ADDR is read. If it is high, a 1 is written to the SDO pin. If it is low, a 0 is written to the SDO pin.
- 4. Clock the serial clock pin The CLK pin is written high and then written low.
- Rotate VR\_ADDR and VR\_DATA Arithmetically shift left VR\_DATA (C <- bit 7) then rotate left VR\_ADDR (bit 0 <- C). The next bit to be sent out is now in bit 1 of VR ADDR.
- Is the loop done? The X register is decremented and checked to see if it is 0. If X is not 0, the code is executed at the start of writing the SDO pin, step 3. This loop continues until 10 transmissions are completed.
- 7. End the transmission The  $\overline{\text{CS}}$  pin is written high and the data is latched into the AD8402. Return from subroutine.

**Figure 12** shows the flowchart for the main test routine. The sequence of tests is:

- With 5 volts on A1 and B1 connected to ground, create 1.25 volts on W1. Test the voltage at TP1.
- 2. Reset the AD8402. The voltage at TP1 should now read 2.5 V.
- 3. With A2 open, create a ~10-k $\Omega$  resistance on VR2. Measure this resistance across TP2 and TP3.
- 4. Create a ramping voltage waveform on TP1. Using an oscilloscope, verify that the waveform ramps from 0 volts to 5 volts.

The assembly code for the test routine is provided in **Code Listing**.





Application Note Development Tools

## **Development Tools**

The interface was created and tested using these development tools:

- M68MMPFB0508 Freescale MMEVS platform board
- M68EM05J1A Freescale J1A emulation module
- Win IDE Version 1.02 Editor, assembler, and debugger by P&E Microcomputer Systems, Inc.

#### References

*MC68HC705J1A Technical Data*, Freescale document order number MC68HC705J1A/D, 1996.

*M68HC05 Applications Guide*, Freescale document order number M68HC05AG/AD, 1996.

AD8402 Datasheet, Analog Devices, Inc., 1997.



## **Application Note**




Figure 11. Serial Driver Flowchart



Application Note References




Figure 12. Main Test Routine Flowchart



#### **Application Note**

#### **Code Listing**

```
File name: AD8402.ASM
 Example Code for the MC68HC705J1A Interface to the
     Analog Devices Digital Potentiometer
 Ver: 1.0
 Date: June 23, 1998
 Author: Mark Glenewinkel
        Freescale Field Applications
        Consumer Systems Group
 Assembler: P&E IDE ver 1.02
 For code explanation and flow charts,
 please consult Freescale Application Note
    "Interfacing the AD8402 Digital Potentiometer to the MC68HC705J1A"
    Literature order number AN1760/D
*** Internal Register Definitions
             EOU
                     $00
PORTA
                                       ; PortA
DDRA
             EQU
                     $04
                                       ;data direction for PortA
*** Application Specific Definitions
SER PORT
             EOU
                     $00
                                       ; PortA is SER_PORT
SDO
             EQU
                     1T
                                       ;PortA, bit 0, data signal
CLK
             EQU
                     0Τ
                                       ;PortA, bit 1, clock signal
CS
             EQU
                     2Т
                                       ;PortA, bit 2, chip select
                     3T
                                       ;PortA, bit 3, reset signal
RS
             EQU
                     0Τ
                                       ;address for VR1
VR1
             EQU
VR2
             EQU
                     1T
                                       ;address for VR2
*** Memory Definitions
             EOU
                     $300
                                       ;start of EPROM mem
EPROM
RAM
             EOU
                     $C0
                                       ;start of RAM mem
RESET
             EQU
                     $7FE
                                       ; vector for reset
ORG
                     RAM
                                       ;storage for addr to be sent
VR_ADDR
             DB
                     $00
                     $00
                                       ;storage for data to be sent
VR_DATA
             DB
COUNTER
             DB
                     $00
                                       ;temp counter
```



## Application Note Code Listing

*** MAIN ROUT	INE ****	******	***********
	ORG	EPROM	start at beginning of EPROM
*** Initialize	e Ports		
START	bclr	CLK,SER_PORT	;CLK=0
	bclr	SDO,SER_PORT	;SDO=0
	bset	CS,SER_PORT	;CS=1
	bset	RS,SER_PORT	;RS=1
	lda	#%00001111	;make SER_PORT pins outputs
	sta	DDRA	
*** Create 1.	25V on W1		
	lda	#VR1	
	sta	VR_ADDR	;address VR1
	lda	#\$40	
	sta	VR_DATA	;1/4 of voltage range
	jsr	TXD	;send address and data
*** Reset AD8			
	bclr		;RS=0
	bset	RS,SER_PORT	;RS=1
*** Create a	~10K ohm :	reading on rheostat	VR2
	lda	#VR2	
	sta	VR_ADDR	;address VR2
	lda	#51T	
	sta	VR_DATA	;1/5 of resistor change
	jsr	TXD	;send address and data
*** Create a	voltage r	amp waveform on W1	
	clr	COUNTER	;COUNTER=0
RAMP_LOOP	lda	#VR1	
	sta	VR_ADDR	;address VR1
	lda	COUNTER	
	sta	VR_DATA	;data=COUNTER
	jsr	TXD	send address and data
	inc	COUNTER	; COUNTER=COUNTER+1
	bra	RAMP_LOOP	;infinite loop



## **Application Note**

\* \*\*\* Routine takes contents of VR ADDR and VR DATA and sends \*\*\* them out to the AD8402, MSB first \*\*\*  $VR\_ADDR$  and  $VR\_DATA$  are destroyed TXD bclr CS,SER\_PORT ;CS=0 ldx #10T ;set counter WRITE brclr 1, VR ADDR, CLR ;Check bit 1 of VR\_ADDR bset SDO, SER\_PORT ;SD0=1 bra CLOCK IT ;branch to clock\_it CLR ;SDO=0 bclr SDO, SER\_PORT brn CLR ; evens it out CLOCK\_IT bset CLK, SER\_PORT ;CLK=1 bclr CLK, SER\_PORT ;CLK=0 asl VR\_DATA ;rotate left VR\_DATA ;C=MSB of VR\_DATA rol VR\_ADDR ;rotate left with C decx ;decrement counter WRITE ;loop over? bne ;CS=1, latch data bset CS, SER\_PORT ;return from sub rts \*\*\* VECTOR TABLE \* ORG RESET DW START





#### **Application Note**

#### How to Reach Us:

#### Home Page:

www.freescale.com

#### E-mail:

support@freescale.com

#### **USA/Europe or Locations Not Listed:**

Freescale Semiconductor Technical Information Center, CH370 1300 N. Alma School Road Chandler, Arizona 85224 +1-800-521-6274 or +1-480-768-2130 support@freescale.com

#### Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) support@freescale.com

#### Japan

Freescale Semiconductor Japan Ltd. Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064
Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

#### Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

#### For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document. Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters which may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

