Riansares 4R — method, quotations, SEO, catalogue and templates

15. Sound estimating

15.1. The price per m² comes at the end

Correct order:

1. define scope;
2. measure each job;
3. separate substrates and methods;
4. calculate materials;
5. estimate labour;
6. include logistics;
7. include waste;
8. include access equipment and other site resources;
9. include coordination;
10. add contingency and margin;
11. divide by m² only for analysis.

Do not start with a rate per m² and force the work to fit it.

15.2. Commonly forgotten items

- protection;
- moving furniture;
- loading and transporting rubble;
- travel;
- accommodation;
- purchasing and delivery;
- drying;
- finishing details;
- junctions;
- seals;
- cleaning;
- coordination;

- warranties and snagging;
- tools and consumables;
- hidden damage;
- material compatibility.

15.3. Margin and profit

Gross margin is not net profit. It must cover:

- self-employment contributions or staffing overheads;
- vehicle;
- accounting and administrative services;
- insurance;
- telephone;
- customer acquisition;
- quotation preparation time;
- warranty;
- incidents;
- unbilled days.

Do not count a margin included in a worker’s rate and another business margin twice as though they were independent profits.

15.4. Reduce scope rather than give work away

When the client does not accept the amount:

- remove less urgent interventions;
- retain usable elements;
- separate optional items;
- propose phases;
- explicitly change quality levels;
- do not retain the same scope with a discount that eliminates margin and quality.

15.5. Preliminary and final quotations

Preliminary

- range;
- subject to a visit;
- few items;

- explanation of risks;
- confirm whether the order of magnitude fits.

Final

- measurements;
- materials;
- included scope;
- exclusions;
- payment terms;
- timeframe;
- warranty;
- hidden damage;
- optional items;
- revision and date.

---

16. Damp: general framework

16.1. Diagnosis before product

Do not start with “which paint to use”. Start with:

- where it appears;
- height;
- orientation;
- relationship with the ground;
- pipes;
- roof;
- rain;
- ventilation;
- temperature;
- salts;
- previous treatment;
- active or historic damp.

16.2. Compatible materials

For old damp or salt-affected walls, appropriate options may include:

- lime mortars;
- rehabilitation mortars;
- renovation mortars for damp and salt-affected substrates;
- mineral finishes;
- breathable paints.

They must be applied to a sound substrate after incompatible or loose material is removed.

16.3. Solutions that must not be sold as miracles

- anti-damp paint over a leak;
- gypsum plaster over a salt-affected wall;
- plasterboard bonded to a damp wall;
- mesh as a universal structural solution;
- textured stipple coating to hide major unevenness;
- breathable mortar as elimination of the source;
- internal waterproofing without analysing external water.

16.4. Useful content for clients

Explain:

- the difference between repairing a finish and eliminating the cause;
- why a wall may take time to dry;
- why stains reappear;
- what a sound substrate means;
- why trial openings are made;
- what the warranty covers;
- when a technical professional is needed.

17. Diagnosis and selective demolition

Principle:

Demolish only when there is a technical reason or the scope requires it.

Examples:

- do not strip out a bathroom if the leak is already repaired;
- do not remove sound tiles behind a wall lining if they do not interfere;
- do not demolish an old house’s layout if it can be improved safely;

- do not replace an extractor before testing it;
- do not dismantle an entire cistern if the aim is a temporary repair;
- do not remove a sound existing concrete floor base without analysing levels and adhesion.

Advantages:

- lower cost;
- less waste;
- less risk;
- less time;
- less collateral damage;
- a more defensible quotation.

18. Client communication

18.1. Short quotation message

Structure:

1. greeting;
2. provisional diagnosis in one sentence;
3. included work;
4. price or range;
5. main condition;
6. closing.

18.2. Correcting an error

Structure:

1. acknowledge the specific error;
2. identify the affected item;
3. provide the new total;
4. retain the technical recommendation where appropriate;
5. avoid excessive justification.

18.3. Client pressing on price

Response:

- explain cost drivers;
- propose reduced scope;

- separate optional items;
- do not disparage other quotations;
- do not accept responsibility without sufficient payment;
- clearly withdraw if infeasible.

18.4. Riansares 4R WhatsApp

It should sound natural:

- short sentences;
- few technical terms;
- visible price;
- simple condition;
- “I’ll let you know beforehand” for extras;
- “let’s see whether it’s easy to resolve” when not yet inspected;
- do not send a three-minute report by chat.

---

19. Local SEO and GEO

19.1. Objective

Do not compete solely for generic national terms. Create local, technical content based on real problems.

19.2. Areas and terms

Combine naturally:

- renovations in Tarancón;
- rehabilitation in Tarancón;
- renovations in Uclés;
- renovations in Cuenca;
- old houses in the surrounding area;
- bathroom renovation;
- kitchen renovation;
- external concrete floor base;
- outdoor patio;
- damp;
- lime mortar;
- plumbing;

- owners’ associations;
- offices.

Do not artificially repeat place names.

19.3. Search intent

Informational

- “difference between a concrete floor base and a floor finish”;
- “why a damp stain returns”;
- “can plasterboard be installed on a damp wall”;
- “how a cistern float valve works”.

Commercial

- “outdoor concrete base price Tarancón”;
- “bathroom renovation Tarancón”;
- “old house renovation company Cuenca”;
- “damp repair Tarancón”.

Decision

- “breathable mortar or plasterboard”;
- “repair or replace toilet”;
- “tiling over tiles yes or no”;
- “ready-mixed or site-mixed concrete”.

19.4. GEO elements

Each article should include at least four:

- quick answer;
- definition;
- table;
- steps;
- FAQ;
- comparison;
- explained figure;
- common mistake;
- final summary.

20. Measurements and sketches for reconstructing plans

Geometrical interpretation errors appeared several times in the communal entrance, office toilets and other sketches. The editorial lesson is that a convincing image is not equivalent to a correct plan.

Data to collect

1. Name of each room and route to reach it.
2. Consistent orientation: entrance, rear, left and right, without changing reference points.
3. Total length of each wall and breakdown into sections.
4. Thickness of walls, arches, columns and partitions where relevant.
5. Doors: width, height, distance from the corner and opening direction.
6. Windows: width, height, sill height and distance from corners.
7. General clear height and height changes.
8. Steps, ramps and level changes, separate from the room plan.
9. Visible services: stacks, electrical panels, radiators, sanitary fittings, drains and ducts.
10. General photographs, photos of each wall and of junctions.

Useful description format for an LLM

- Start with the general shape: rectangle, L, irregular room or group of rooms.
- Describe the route from the entrance.
- Describe walls clockwise.
- Identify the object of each measurement: “wall”, “door opening”, “arch thickness” or “height”.
- Mark each datum as confirmed, approximate or not measured.
- Separate plan, elevation and section.
- Do not automatically turn a stair measurement into a wall measurement.
- Do not invent diagonals or add sections not defined as consecutive.

Checks before accepting the plan

- Section totals must match total length within measurement tolerance.
- Doors and windows must fit within the wall.
- The drawing must respect which elements are inside or outside the room.
- Horizontal and vertical dimensions must not be interchanged.
- Drawing proportions must correspond to measurements.
- Residual gaps must be explained.
- Opening directions must not obstruct routes or sanitary fittings.

- Uncertainties must remain visible rather than being hidden by a clean drawing.

Derived articles

- How to measure a home to draw a plan.
- Which photos a technical professional needs before a visit.
- How to describe an irregular room to an LLM.
- Common mistakes when measuring doors, arches and stairs.
- Plan, elevation and section: basic differences.
- How to check whether an AI-generated sketch makes sense.

---

21. Website and editorial consistency

21.1. Verified homepage message

The website communicates:

- “We renovate your home in Tarancón and the surrounding area”;
- actual measurement;
- clear work items;
- phased work;
- direct contact;
- renovations, repairs, plumbing, masonry, floors, finishes and waterproofing.

Articles must reinforce this message rather than contradict it.

21.2. Documented sections and assets

- homepage;
- services;
- how we work;
- real projects;
- clearly labelled visual inspiration;
- plans, measurements and design;
- renovations in progress;
- contact;
- quotation;
- galleries;
- legal information;

- blog/articles.

21.3. Editorial HTML rules

- a single H1;
- specific title;
- individual meta description;
- hierarchical H2/H3 subheadings;
- accessible tables;
- images with descriptive alt;
- do not use conceptual images as evidence of real work;
- link to WhatsApp and quotations without intrusive repetition;
- internal links to services and related articles;
- actual article date;
- review the footer year when updating the site.

PART IV — ARTICLE CATALOGUE

22. Cluster: concrete floor bases, patios and outdoors

1. Concrete floor base and floor finish: differences that change the quotation.
2. Concrete base and outdoor tile prices in Tarancón: a realistic example.
3. Ready-mixed concrete or concrete mixed on site.
4. How access affects the price of a concrete base.
5. Welded wire mesh and spacers: why mesh must not rest on the ground.
6. Contraction joints and perimeter joints.
7. How to create patio gradients.
8. Inspection chambers, channels and grates: which problem each solves.
9. Why not every m² of a patio costs the same.
10. Mistakes when pricing tiles and concrete together.
11. Localised waterproofing: when recommended and how to separate it in a quotation.
12. Internal patios: the hidden cost of wheelbarrows and narrow corridors.

23. Cluster: old houses and rehabilitation

1. How to renovate an old house without turning it into structural work.
2. Where to invest first: kitchen, bathroom, services or layout.

3. Lime mortar on old walls.
4. Lateral water ingress and rising damp: cautious distinctions.
5. Why gypsum plaster may fail on damp walls.
6. Hidden damage when stripping an old wall.
7. Selective renovation: retain useful elements and renew critical ones.
8. Tiling over tiles in an old home.
9. How to price rural renovation with accommodation and rubble.
10. Renovating a small bathroom without moving stacks.
11. Microcement: substrate requirements.
12. Renewing pipes before closing up finishes.
13. Stabilising a cave or cellar with lime mortar.
14. Galvanised mesh on vaults and earthen substrates.
15. Air lime, NHL and hybrid mortars: when to use each.
16. How to create a pilot room before lining a cave.
17. Brick arches and centring in rustic rehabilitation.
18. Rustic finish does not mean an unprepared substrate.

24. Cluster: damp and finishes

1. Breathable mortar or plasterboard wall lining.
2. Why plasterboard should not be bonded directly to a damp wall.
3. What renovation mortar for damp and salt-affected substrates is.
4. How to identify a hollow finish.
5. When to retain a previous treatment.
6. Fibre mesh: correct uses and false expectations.
7. Breathable paint versus emulsion paint.
8. How to repair an old entrance hall with arches and meters.
9. What a warranty can cover when damp is pre-existing.
10. Stipple coating over rehabilitated mortar: benefits and limits.
11. Damp returns: possible causes and checks.
12. Repairing a finish does not always eliminate the cause.

25. Cluster: bathrooms and plumbing

1. Fill valve and flush mechanism.

2. How to choose an angle valve for a cistern.
3. Flexible connector too short: risks and solution.
4. Repairing or replacing an old toilet.
5. Why a small repair can become complicated.
6. How to price a minimum viable repair.
7. Renovating a small bathroom without enlargement.
8. Moving a toilet: how the stack dictates options.
9. Shower waterproofing: what to include.
10. Bathroom extractor: test before replacing.
11. Moisture-resistant board, phenolic panels or masonry for cubicles.
12. What to ask before quoting a complete bathroom.
13. Two bathrooms in a narrow space: design decisions.
14. 90 and 110 mm drainage: compromises and limits.
15. Accessible inspection points beneath showers and service enclosures.
16. How to raise a tray without creating a hollow base.
17. Lime mortar and exposed beams in dry bathroom areas.
18. MS or PU adhesive for shower trays.
19. Why bending a board in a shower is inadvisable.
20. Cheap material does not eliminate execution cost.

26. Cluster: ceilings, painting and repaired leaks

1. How to repair a ceiling after a leak.
2. What stain-blocking primer does.
3. Painting only the patch or the whole ceiling.
4. How to measure whether a wall or ceiling remains damp.
5. Cracks around old patches.
6. Anti-damp paint: what it can and cannot do.
7. Protecting furniture and floors: actual repair time.
8. Why yellow rings return.
9. When a crack needs mesh.
10. How to define the scope of a surface repair.

27. Cluster: offices and technically knowledgeable clients

1. How to prepare a renovation quotation for a company.
2. Dividing renovation into selectable packages.
3. Acoustic partition with mineral wool and double boarding.
4. How to relocate a meeting room without losing heating and cooling.
5. Integrating two floor finishes when demolishing a partition.
6. Three cubicles in a small toilet: prior checks.
7. Cleaning or replacing suspended ceiling tiles.
8. Black stains around diffusers: hypotheses and inspection.
9. Why coordination has a price.
10. Payment milestones in corporate renovation.
11. How to authorise extras in writing.
12. What a client with construction knowledge reviews.

28. Cluster: quotations and method

1. Why price per m² is insufficient.
2. How to separate labour, materials and coordination.
3. Preliminary versus final quotation.
4. Reducing scope without degrading the work.
5. How to correct a quotation transparently.
6. Hidden damage: clear and fair clauses.
7. Commonly forgotten renovation items.
8. Gross margin is not net profit.
9. How to turn a quotation into a practical case study.
10. Measure before promising: the Riansares 4R method.
11. How to compare two quotations with different inclusions.
12. Why a low price may conceal exclusions.
13. What an unpriced bill of quantities is.
14. Architect’s estimate versus execution offer.
15. How to screen a job before a long visit.
16. When to decline work because of capacity or responsibility.
17. Lift building works versus equipment supply.
18. Small jobs: a practical working day versus an abstract hourly rate.

PART V — GENERATION TEMPLATES

29. Internal prompt for a technical article

Use this instruction with the local LLM:

Write an article in Spanish for Riansares 4R using only the canonical memory. The article must be technical but understandable, local and cautious. Distinguish facts, examples and information awaiting a visit. Do not invent regulations, current prices, completed work or warranties. Anonymise every case. Include a single H1, quick answer, H2 sections, a table or comparison, common mistakes, frequently asked questions and a brief CTA for Tarancón and the surrounding area. Do not mention internal tools or the existence of the memory.

30. Internal prompt for a practical case study

Create an anonymised practical case study based on [CASE NAME]. State that it is an analysed or quoted example if execution is not established. Separate: problem, confirmed data, approximate data, alternatives, recommendation, risks, costs only as a historical example, lessons and frequently asked questions. Do not publish names, addresses or conversations.

31. Internal prompt for a pricing article

Explain how the price of [WORK] is formed. Do not present historical figures as current rates. Separate areas, materials, labour, access, logistics, waste, coordination, finishing details and hidden damage. Include a rounded example and clarify what must be measured before quoting.

32. Internal prompt for a comparison

Compare [OPTION A] and [OPTION B] without declaring a universal winner. Explain when each makes sense, advantages, limits, required substrate, maintenance, relative cost and conditions that rule out an option. End with a recommendation conditional on a visit.

33. Pre-publication checklist

- [ ] A single H1.
- [ ] Individual title and meta description.
- [ ] The article answers a specific question.
- [ ] No private names or addresses.
- [ ] No proposal presented as completed work.
- [ ] Prices are dated or defined as examples.
- [ ] Hypotheses are labelled as hypotheses.
- [ ] No promise to eliminate damp without resolving its cause.
- [ ] No invented regulations.
- [ ] Concrete floor base and floor finish are not confused.

- [ ] Materials and fees are not confused.
- [ ] A useful conclusion.
- [ ] A brief local CTA.
- [ ] Related internal links.
- [ ] Figures and units reviewed.
- [ ] Generic or repetitive text avoided.

34. Minimum technical glossary

- **Concrete floor base:** base layer prepared to receive flooring.
- **Floor finish:** final flooring laid over the substrate.
- **Welded wire mesh:** metal reinforcement mesh; must be installed on spacers according to design.
- **Contraction joint:** cut or joint intended to control shrinkage cracking.
- **Perimeter joint:** separation at junctions with vertical elements.
- **Breathable mortar:** mortar compatible with vapour release; it does not eliminate active water.
- **Renovation mortar:** system for damp or salt-affected substrates, subject to specification and preparation.
- **Independent wall lining:** internal lining independent of the existing wall.
- **Moisture-resistant board:** board resistant to humid environments, not waterproof by itself.
- **Phenolic panel:** compact panel resistant to moisture and impacts, used in cubicles and intensive-use areas.
- **Stain-blocking primer:** product blocking stain migration before finishing.
- **Substrate consolidant:** consolidates a powdery substrate; does not correct deeper adhesion failure.
- **Float or fill valve:** mechanism filling the cistern and shutting off water.
- **Flush mechanism:** mechanism releasing water into the toilet bowl.
- **Angle valve:** local wall-mounted shut-off valve.
- **Flexible connector:** flexible connection between supply and fixture.
- **Hidden damage:** defect not visible before demolition, opening up or stripping back.
- **Work item:** specific economic and technical unit in a quotation.
- **Site resources:** protection, tools, scaffolding, consumables and resources needed for execution.
- **Contingency:** reserve for reasonable uncertainties, not duplicated profit.
- **NHL:** natural hydraulic lime; sets hydraulically and is often compatible with old masonry when correctly specified.
- **Triple-twist mesh:** flexible galvanised mesh adaptable to vaults and irregular surfaces.
- **Centring:** temporary formwork supporting an arch during construction and setting.

- **Inspection access:** removable access for inspecting, cleaning or repairing concealed services.
- **Compression coupling:** removable mechanical joint; must remain accessible and unstressed when used as a maintenance point.
- **PVC solvent welding:** solvent joint between compatible components; not a filler for gaps.
- **MS polymer:** high-performance elastic adhesive-sealant used in certain compatible installations.
- **Unpriced bill of quantities:** measurements without prices, or a preliminary estimate not automatically equivalent to an execution offer.
- **Lift building works:** pit, shaft and structure; do not necessarily include car, machinery, installation or regulatory approval.
- **Construction compromise:** solution accepted because of actual constraints that must not become a universal rule.
- **Beyond capacity:** work whose risk, structure, equipment or responsibility exceeds available resources.

Extension — real questions, quotations and evidence (November 2026)

Address the client’s intent first

For “what should I do about a leak?”, begin by stopping the leak and checking safety; for “can I replace tiles?”, begin with conditional feasibility; for “how much does it cost?”, request measurements, scope and quality levels. Never automatically answer with the price of a 7 m² kitchen when nobody said the kitchen measures 7 m².

Distinguish technical references from commercial prices

International guides (EPA, NARI, NAHB, HSE) provide general good practice, not local prices, commercial warranties or binding rules in Spain. Price depends on measurements, design, permits, materials and date. Extended source: sources/R4R_71_INTERNATIONAL_TECHNICAL_REFERENCES_2026.md.

Bilingual evaluation before publishing new examples

Repeat equivalent Spanish and English questions about the same kitchen, compare retrieved excerpts and citations, and record when the answer abstains. Fluency does not demonstrate documentary support; abstention may be correct when evidence is absent. Store actual run results and models, rather than assumptions.