

external controllers -> Venus gateways -> VE.Bus (state 2026-10-08 14:30)
solid = active control path, dashed = read only / inactive

