



Contents

1	Overview	Page 1 - 3
2	Preset System	4
3	Parametric EQ mode	5 - 7
4	Simple EQ mode	7 - 8
5	Pulteq EQ mode	8
6	Combo (dual EQ) Modes	9 - 10
7	Prototypes	11
8	Limiter and Stereo Expander	12 - 13
9	Channel Modes	13 - 14
10	Master Volume and Input Level Trim	15
11	Routing Configurations	16
12	Doing A/B Comparisons	17
13	Globals Settings	18 - 19
14	Resetting the Pedal	20
15	Firmware Update	20

Introduction

Enieqma is a multipurpose equalizer that packs a 5-band full parametric EQ, a 'simple EQ class' featuring 7 classic tone stacks, and a 3-band midrange equalizer that emulates the Pultec Midrange EQ processor. Enieqma offers unprecedented equalization capabilities in a pedal format.

Versatility


Enieqma's EQ engine can be harnessed not only for general purpose tone shaping, but also for realizing specific tonal effects such as guitar/bass speaker frequency responses, telephone, old radios, wah pedals, etc. To help users get up to speed and quickly tap into the power of Enieqma, we have provided an on-board extensive library of *ready-to-use* prototype EQs that covers everything from simple lowpass/highpass filters to elaborate cabsim filters.

Ease of use

Equalization, specially with a parametric EQ, can at times be a daunting task. All those power and capabilities would go to waste without an effective and user friendly interface. With Enieqma we've gone all out to provide intuitive interfaces and make sure that everything that the pedal offers can be quickly accessed, with no deep menus or dependency to computer apps!

1. Overview

This diagram below shows a simplified overall structure of the processing blocks inside the Enieqma.



Stereo Expander and **Limiters** are optional and can be disabled (default). These two processing elements can be configured in the Options menu.

The EQ, the Limiter, and the Booster have 2 channels: channel L and channel R. The two channels can be configured as **Linked** (their parameter settings are identical) or as **Independent** (they can have different parameter settings). Very flexible routing configurations allow Enieqma to be used as a true stereo EQ or as a mono EQ in a pre-post equalization setup (see chapter 11 - Routing Configurations).

Booster provides up to +15dB of clean boost. The booster is independent of the EQ, i.e it can be activated even when the EQ is off. The state of the booster is also saved as part of a preset. Therefore you can use the booster as a stand alone booster effect, or as part of the preset system.

Controls (common functions)

- Turn : Select EQ mode
- Twist: Select filter type
- Tap : Enter Options menu
- Hold : Enter Globals menu

* Twist = press and turn

- Turn : Master Volume
- *Twist: Boost Level

- Double Tap to activate / deactivate a ParaEq band.
- Tap once to bring an active ParaEq band into focus.

Bypass / Engage EQ

Bypass / Engage Booster



EQ parameters

EQ mode indicator LEDs

Inputs and Outputs



TS for 1 channel input

TRS for 2 channel input
Tip = Left
Ring = Right

channel R output

standard TS


channel L output

standard TS



MIDI

You can use any standard MIDI controller capable of sending Program Change (PC), Control Change (CC) messages to remotely change presets or to control other functions or parameters in Enieqma. The MIDI input accepts Type-A TRS-to-DIN5 pin mapping:




- Use the diagram above as your reference when ordering or making your own cable.
- Consult the "Midi Implementation Chart" document for PC/CC implementation details.



Aux Switches

An external switch box can be used to access various functions of Enieqma remotely. Single-button, dual-button, or triple-button switch boxes can be used. You can assign various functions such as, *Patch Up*, *Patch Down*, *Favorite Preset*, etc, to these switches. Aux switch configuration is done in the Global Settings menu.



Switches requirement:

- Normally-Opened,
- Momentary

2. Preset System

Up to 64 presets can be saved and recalled using the onboard footswitches, an external switchbox, or MIDI. The presets are arranged as a simple linear list: preset 1 to preset 64. The pedal ships with the first twelve preset locations programmed with factory presets. Users can overwrite these with their own presets if so they wish.

Saving a preset

1. Press and hold knob MODE/TYPE and knob GAIN, Release when the screen displays the preset save menu.
2. Turn the MODE/TYPE knob to choose the desired preset location.
 - Push the VOLUME/BOOST knob to cancel, or
 - Push the MODE/TYPE knob to confirm the save.

After saving the preset, you can edit the preset title from the Options menu:

Options

○ Preset Title editor



Preset location #

Preset limit

Calling a preset

1. Press and hold the EQ footswitch.
2. When the LEDs start blinking:
 - Tap the EQ switch to scroll down the preset list.
 - Tap the Boost switch to scroll up the preset list.
3. When you've reached the desired preset location:
 - Hold down the EQ footswitch to call the preset.



Tips: You can scroll up or down very quickly by turning the MODE/TYPE knob. Then tap the knob's button to call the preset.



Copying a preset to another location

1. Call the preset that you want to copy to another location.
2. Execute the save preset procedure described above, remember to choose the desired destination location first before committing the save!

2. Preset System

Up to 64 presets can be saved and recalled using the onboard footswitches, an external switchbox, or MIDI. The presets are arranged as a simple linear list: preset 1 to preset 64. The pedal ships with the first twelve preset locations programmed with factory presets. Users can overwrite these with their own presets if so they wish.

Saving a preset

1. Press and hold knob MODE/TYPE and knob GAIN, Release when the screen displays the preset save menu.
2. Turn the MODE/TYPE knob to choose the desired preset location.

- Push the VOLUME/BOOST knob to cancel, or
- Push the MODE/TYPE knob to confirm the save.

After saving the preset, you can edit the preset title from the Options menu:

Options

└─ **Preset Title editor**



Preset location #

Preset limit

Calling a preset

1. Press and hold the EQ (left-side) footswitch.
2. When the LEDs start blinking:
 - Tap the EQ switch to scroll down the preset list.
 - Tap the Boost switch to scroll up the preset list.
3. When you've reached the desired preset location:
 - Hold down the EQ (left-side) footswitch to call the preset.



Tips: You can scroll up or down very quickly by turning the MODE/TYPE knob. Then tap the knob's button to call the preset.



Copying a preset to another location

1. Call the preset that you want to copy to another location.
2. Execute the save preset procedure described above, remember to choose the desired destination location first before committing the save!

3. Parametric EQ Mode

The Parametric EQ mode is a 5-band full-parametric EQ. Each band has adjustable Gain, Q, Frequency, and Filter Type.



Working with the EQ bands.



Double tap on the touch button to active or deactivate a particular band. The LED on the touch button indicates the state of the band. At any given time, the Gain, Q, and Frequency knobs control a single band. The band that 'owns' the control is the 'focus band'. The breathing white LED tells you which band is currently the focus band.

To switch focus to another band: tap once on the touch button that belongs to the target band. A band must already be active to be able to get the focus.

Parametric EQ Types.

Each band can be configured to be one of 5 filter types:

- **Lowpass** : cuts the high frequency band, while passing the low frequencies intact.




Low Q values gives a more 'relaxed' EQ curve, as Q is increased the curve becomes 'tighter', and as it's increased further resonance starts to appear near the center frequency.


For this particular filter type the GAIN parameter is not used, the passband of the filter will stay at 0dB.

Parametric EQ Types.

- **Highpass** : cuts the low frequency band, while passing the high frequencies intact.




Q = 0.5




Q = 1.5

- **Low Shelving** : cuts or boost the low frequency band. Center frequency, Q, and Gain are adjustable.




Q = 0.7




Q = 0.4

- **High Shelving** : cuts or boost the high frequency band. Center frequency, Q, and Gain are adjustable.





Q = 0.7



Q = 0.4

Parametric EQ Types.

- **Bell** : cuts or boost a specific frequency band. Center frequency, Q, and Gain are adjustable.



4. Simple EQ Mode

The Simple EQ mode consists of a class of EQs that are simpler and more straightforward than the Parametric EQ. For this EQ class we have selected 7 types that we think are representative and can cover wide ranging use cases. In general, the Simple EQ mode is great for *broad strokes* tone shaping that doesn't require precision.

FILTER TYPE - press and turn



In this mode, the knobs are labeled BASS, MIDS, and TREBLE, however the actual functions depends on the selected filter type.

MASTER VOLUME
-9 dB to +9dB

Simple EQ Types.

This mode can be configured to be one of 7 filter types:

- **Tonestack "F"** : tone control of Fender* amps with Bass, Mids, and Treble controls.
- **Tonestack "M"**: tone control of Marshall* amps with Bass, Mids, and Treble Control.
- **Tonestack "V"** : tone control of Vox* amps with Bass and Treble control. The classic Vox amps doesn't use a Mids control, but we added one for enhanced flexibility.
- **Bass & Treble** : Baxandall type tone control with low-shelving and high-shelving filters.
Controls: - BASS
 - *FREQ* : sets the center frequency.
 - TREBLE

Simple EQ Types (continued...)

- Wah** : Recreation of a typical wah pedal frequency response.
Controls: - *LOWS* : turn this up for more low frequency energy (body).
 - *Q* : turn this up for sharper resonance (more squeaky).
 - *FREQ* : sets the resonance center frequency (400 Hz to 2200 Hz).

Tips: - This filter type can be used as it is to get the half-cocked wah pedal tone, but even better, you can use an expression pedal + midi controller to sweep the center frequency and turn Enieqma into a wah pedal.
- Tilt** : Tilt EQ ~ bass is increased/decreased when treble is decreased/increased.
Controls: - *TILT* : sets the low/high tilt.
 - *FREQ* : sets the center frequency where the tilt happens.
- Scooped Tilt** : Similar to the Tilt filter type, with an added mid-scoop.
Controls: - *TILT* : sets the low/high tilt.
 - *SCOOP* : sets the amount of mid scoop.
 - *FREQ* : sets the center frequency where the tilt (and scoop) happens.

5. Pulteq EQ Mode

The Pulteq EQ mode is an emulation of the classic Pultec* MEQ-5 Midrange EQ processor. In essence, it is a 3-band parametric EQ, with frequency ranges restricted to the midrange (200 Hz to 7 KHz) area.

The Pulteq EQ mode consists of 3 bands:

LOW PEAK	GAIN ~ 0dB to +10dB (<u>boost only</u>) FREQ (Hz) ~ 200, 300, 500, 700, 1K.
MID DIP	GAIN ~ 0db to -10dB (<u>cut only</u>) FREQ (Hz) ~ 200, 300, 500, 700, 1K, 1.5K, 2K, 3K, 4K, 5K, 7K.
HIGH PEAK	GAIN ~ 0dB to +10dB (<u>boost only</u>) FREQ (Hz) ~ 1.5K, 2K, 3K, 4K, 5K.




Since the frequency is adjusted in steps and Q is fixed, you don't get the full flexibility of a parametric EQ, however this can be a good thing, the frequencies seem to have been selected carefully and you can quickly obtain great tones with few knobs twiddling!


6. Combo (dual EQ) Modes

In addition to the three primary modes, we take the liberty to throw in two extra modes which are combinations of the primary modes. These two dual-EQ modes are:

- **SIMPLEQ + PARAEQ** - Simple EQ and Parametric EQ run together in series configuration.



- **PULTEQ + PARAEQ** - Pulteq EQ and Parametric EQ run together in series configuration.



Combining two different EQ modes is a powerful concept that allows users to construct more elaborate tone shapers while benefitting from the best aspects of the individual modes.

Simple EQ + Parametric EQ


In this mode, the Simple EQ (with filter types of your choice) and the Parametric EQ are both active. This configuration adds a layer of simplicity to the Parametric EQ mode. Assuming a time where a desired settings with Parametric EQ is achieved, layering it with Simple EQ would provide a way to make small or broad adjustments to the existing EQ, with the Simple EQ parameters, rather than directly tweaking the set Parametric EQ which contains more “moving parts”. Looking at it inversely, at the time where a desired settings with Simple EQ is achieved, a Parametric EQ on top of it would provide an ability to fine-tune the Simple EQ, if the user so desires.

Pultec EQ + Parametric EQ

In this mode, the Pulteq EQ and the Parametric EQ are both active. With the understanding that the Pulteq EQ works like a 3-band parametric EQ (with some constraints), this combo can then be seen as an 8-band Parametric EQ with 3 bands concentrated in the midrange frequencies. You can do A LOT with this! Here’s a practical example highlighting the usefulness of such a combo: at the time where the desired settings with Pulteq EQ is achieved, except perhaps some roll off on either side of the bands, for example, an added layer of Parametric EQ could provide extra filters to further fine-tune the desired sounds.

Dual EQ modes display

When a dual-EQ mode is active, the EQ curve displayed on the screen is the composite curve of the two active EQs.



If you feel the need to check the EQ curve of each mode in isolation you can do so by temporarily switching the EQ mode to the mode in question.

Dual EQ modes controls

At any given time when using the dual-EQ modes, one of the two modes has possession of the parameter knobs control. We provide a simple way to allow users to go back and forth editing the individual EQ mode. For example, when the [SIMPLEQ + PARAEQ] mode is active...

→ Simple EQ → Parametric EQ →


Simple EQ has control over the parameter knobs.
< SIMPLEQ led is breathing >

Tap the VOLUME/BOOST knob once to handover parameter control to ParaEQ

→ Simple EQ → Parametric EQ →

Parametric EQ now has control over the parameter knobs.
< PARAEQ led is breathing >

7. Prototypes



“Prototypes” is a library of pre-made EQ settings that you can quickly use as it is, or modify as you see fit and save the change as user presets.

How are Prototypes different from Factory Presets?

Prototypes and Factory-programmed presets both provides *ready-to-use* sound settings. The differences between the two are:

1. Scope

Factory presets are ‘system-wide’ settings, which include EQ, booster, limiter, stereo expander, channel mode settings, etc. Prototypes only concerns strictly on the EQ settings.

2. Permanence

Factory presets may be rewritten with user presets. Prototypes are *locked* and not user-editable (however, once loaded into the EQ engines users can freely modify it).

At the time this user manual is written, the prototypes library consists of 44 settings for ParaEQ mode, 12 settings for SimpleEQ mode, and 12 settings for PultEQ mode. The library may be expanded in the future through firmware updates.

Turn this knob for fast scrolling by page

- Turn to scroll though the list.

- Tap to confirm the selection.

OK

◀ page ▶

-cancel-

1. Electric Clean

2. Electric Chime

3. In Your Face Twang

4. Smooth & Mellow

Tap the button to cancel and exit the Options menu.

The EQ settings can be auditioned in real time as you scroll through the list.

Is it possible to load different prototypes to different channel?

If the EQ channel-mode is set to LINKED then the prototype will be loaded to both channels. If channel mode is set to INDEPENDENT, and the current focus is on channel L then the prototype will be loaded to channel L, similarly if the current focus is on channel R then the prototype will be loaded to channel R. So, the answer is yes!

8. Limiter

Options

○ Limiter

The limiter is an optional processing element that you can use to catch any peaks or transients from your signal and regulate them to a specified level, this keeps the output signal from clipping, which may occur with high EQ gain settings.

Parameters:

Input Gain: sets the input gain (0dB to +9dB) of the signal coming into the limiter. If you don't need any volume increase this control should be left at 0dB.

Threshold: controls the threshold level at which the limiter action sets in. Higher threshold level results in less limiting, and lower threshold level result in more limiting.

Attack: determines how fast the limiter respond to incoming peaks/transients. Lower value gives a tight and fast limiting action, while higher value will let some transients to pass through. This control allows some tradeoff between peaks control and dynamics preservation.

- Turn to toggle the Limiter Off / On
- Tap to save the changes.



OFF		ON	
+9	0	1.2	
dB	dB	ms	
0	-15	0.1	
In Gain	Threshold	Attack	

Stereo Expander

Options

○ Stereo Expander

The stereo expander is another optional processing element that can be used to enhance the stereo image of a mono input or a stereo input signal.

Algorithms:

Short Delay: a short delay (0 to 20 ms) is applied to the Right channel signal.

Dimensional Expansion: applies a 'dimensional chorus' type processing to create a 3D-like sound field.

(OFF) - not applicable.

(Short Delay) - sets the delay (0 to 20 milliseconds).


(Dimensional Expansion) - sets the expansion depth (0 to 100%).

- Turn to set the expander Off / On.


- Tap to save the changes.




Stereo Expander is disabled.



Stereo Expander is enabled:
'Short Delay' algorithm.



Stereo Expander is enabled:
'Dimensional Expansion' algorithm.




The stereo expander is useful only with **Mono-In/Stereo-Out** or **Dual-Mono (Stereo-In/Stereo-Out)** routing configuration. It should not be used when **Stereo-In/Mono-Out** routing mode is used.

Another occasion where the use of stereo expander would be inappropriate is when routing is set to Dual-Mono, and the two EQ channels are used in a pre-post equalization setup (see chapter 11, page 16).



Changes made to the Limiter and Stereo Expander settings are automatically saved to the current preset.

9. Channel Modes



The two channels of EQ, limiter, and booster can be configured as **Linked** (their parameter settings are identical) or as **Independent** (they can have different parameter settings).

‘L and R highlighted’ indicates that the two EQ channels are linked.



‘L is highlighted, and R is dimmed’ indicates that the two EQ channels are independent, and channel-L currently owns the *channel focus*.



Navigating two EQ channels configured as Independent

When the channels are configured as Independent, at any given time, one of the channels has the ‘channel focus’, that is, parameter changes are applied only to that particular channel. The [L-R] icon at the upper left corner of the screen tells which channel currently owns the channel focus. The EQ curve of both channels are displayed together, the curve belonging to the channel with the focus is highlighted, while the other is slightly dimmed.

To switch the channel focus to channel-L: hold the **left most** touch button for about 2 seconds.

To switch the channel focus to channel-R: hold the **right most** touch button for about 2 seconds.

Hold for about 2 seconds to switch channel focus to the Left channel.



Hold for about 2 seconds to switch channel focus to the Right channel.

Copy and Swap

When working with two independent EQ channels, there may be times you want to copy the parameter settings of the EQ in one channel to the EQ in other channel, or maybe swap the settings between the two channels. We've provided a mechanism to do this quick and easy.

1. Push the MODE/TYPE knob and the GAIN knob together to enter the copy/swap menu.
2. Turn the MODE/TYPE knob to choose the desired operation, choose < exit > if you want to cancel.
3. Push the MODE/TYPE knob to execute




10. Master Volume and Input Level Trim

Master volume control (-9dB to +9dB) is useful to set the overall output volume, to compensate for changes in volume level due to EQ processing. Each EQ mode has its own volume control, this makes it easy to maintain consistent volume level across different modes.

The master volume control is an integral part of the EQ engines, therefore it also comprises 2 channels: Volume-L and Volume-R.

Input Level Trim (0dB to -15dB) is also provided to allow users to dial down the input signal level to prevent output signal clipping which could occur with extreme EQ gain settings. The input level trim is configured in the Options menu:




It is recommended to leave Input Level trim setting at 0dB, and only set it to lower values if you are getting clipping in the output signals.




Changes made to the Input Level Trim settings are automatically saved to the current preset.


11. Routing Configurations




Mono In / Stereo Out




Dual Mono (Stereo In / Stereo Out)



👉 This routing configuration can be used in a *Pre/Post equalization* setup:



Stereo In / Mono Out



12. Doing A/B Comparisons

There are two types of A/B comparisons in Enieqma.

Full A/B Comparison

This is the usual kind of A/B comparison most people are familiar with. Suppose you'd like to compare two different EQ settings by quickly toggling between the two, here's what you do:

1. Set the EQ channel mode to Independent (see chapter 9).
2. Put one EQ settings on channel-L, and the other on the channel-R.
3. Enter the L/R Comparison scene by holding down the VOLUME / BOOST knob for about 2 seconds.



4. You can now tap on the BOOST footswitch to toggle between the EQ-L settings, and EQ-R settings. The sound that you hear on both output channels are either the EQ-L sound or the EQ-R sound. The screen will highlight which EQ channel is currently being solo-ed.



EQ channel-L is being solo-ed



EQ channel-R is being solo-ed

When you're done, you can exit the L/R comparison scene by pressing the VOLUME/BOOST knob button.

Partial A/B Comparison

In this type of A/B comparison, you're looking at the change in sound as a single parameter is toggled between two distinct values. Here's an example:

1. Choose an EQ mode, say the Simple EQ: Bass & Treble type.
2. Set one parameter, say the *Bass*, to a certain value, say 25.
3. Hold down the Bass knob for about 2 seconds, release the hold when "VALUE LATCHED!" appears on the screen.
4. Now adjust the *Bass* to some other values, say 75.
5. At this point, you can toggle the *Bass* parameter between 25 and 75 by tapping on the Bass knob button.

13. Globals Settings

Press and hold the MODE/TYPE knob button for about 2 seconds to enter the Global Setting menu.



If at any moment you wish to exit the menu without saving any changes you can do so by holding down the MODE/TYPE knob button again for about 2 seconds.

Globals

- **Routing**
 - Mono In / Stereo Out
 - Dual Mono (Stereo In / Stereo Out)
 - Stereo In / Mono Out
- **Top Preset** — [Preset 2 to Preset 64]

Sets the limit of accessible presets. For example, if you choose 'Presets 4', then the preset-change cycle is like this:

patch-1 patch-2 patch-3 patch-4 patch-1 ...

This self-imposed restriction is not applicable when calling a preset via MIDI. PC messages will be able to call any preset number regardless of this setting.
- **Power-up State**
 - Bypassed : Pedal powers up in bypassed state (**default**).
 - Engaged : Pedal powers up in engaged state.
- **Power-up Preset**
 - Last-used preset : Last-used preset is loaded on power up (**default**).
 - Favorite preset : Favorite preset is loaded on power up.
- **Midi Channel** — [Channel 1 to Channel 16] (**default is channel 1**)
- **Midi Out Polarity**
 - Tip Active (Type A) (**default is Type A**)
 - Ring Active (Type B)
- **Favorite Preset** — [Preset 1 to Preset 64] : Select your 'favorite' patch.



When you assign an aux switch to the 'favorite' function (see below), you can quickly call a favorite patch of your choosing by pressing that aux switch.

Globals

- Aux switch (Tip)
- Aux switch (Ring)
- Aux switch (Tip+Ring)

- * **Preset Up** - increment (scroll up) preset number by 1.
- * **Preset Down** - decrement (scroll down) preset number by
- * **Favorite Preset** - Call the favorite patch .
- * **Bypass/Engage (global)** - Toggle bypass / engage (global).
- * **Bypass/Engage (EQ-L)** - Toggle bypass / engage (EQ channel L only).
- * **Bypass/Engage (EQ-R)** - Toggle bypass / engage (EQ channel R only).
- * **Boost On/Off** - Toggle booster on and off.
- * **Load Next Preset** - increment preset number by 1, and load.
- * **Load Previous Preset** - decrement preset number by 1, and load.

- **PC Message Filter**
 - Process All PC : All program change will be processed.
 - Ignore 'same preset' : Program change that calls the same preset as is currently active will be ignored. This avoids the brief cut in the audio (**default**).
- < Added in firmware v1.2.1 >
- **Home Screen Display**
 - Preset Information : Preset number and title.
 - EQ Response Curve : EQ frequency response curve (**default**).
- < Added in firmware v1.2.3 >

14. Resetting the Pedal

Resetting the pedal will revert the parameters or configurations to factory default settings. There are 2 types of resets which can be performed independently: *Factory Reset* and *Global Settings Reset*.

Factory Reset

Factory Reset reverts all the presets back to factory settings. This operation will overwrite all user presets, but will not affect the saved global settings.

Step 1: Begin with the pedal powered down.

Step 2: Power up the pedal. While the lights are still flashing, press and hold down the EQ footswitch. Release when the display reads "FACTORY RESET".

Step 3: Press the EQ footswitch to confirm, or the BOOST footswitch to cancel.

Global Settings Reset

Global Settings Reset reverts the global configurations back to factory settings. This operation will *not* affect the saved presets.

Step 1: Begin with the pedal powered down.

Step 2: Power up the pedal. While the lights are still flashing, press and hold down the BOOST foot switch. Release when the display reads "GLOBALS RESET".

Step 3: Press the EQ footswitch to confirm, or the BOOST footswitch to cancel.

16. Firmware Update

Firmware updates may be made available for bug fixes and/or feature additions/modifications. You will need to connect your pedal to your computer via USB to perform a firmware update.

Before you begin the update, make sure you have the **latest version** of the EnieqLab editor software installed in your computer, and download the latest firmware for the Enieqma pedal on our website.

Tips: It's recommended to first back up your presets before starting the update. The EnieqLab software has the functionality to create a backup: *Menu > Backup*.

Update Procedure:

Step 1: Begin with the pedal powered down.

Step 2: Power up the pedal. While the lights are still flashing, press and hold down both footswitches together. Release when the display reads "FIRMWARE UPDATE".

Step 3: Connect the pedal to your computer via USB and start the EnieqLab software.

Step 4: If you have previously downloaded the firmware file, click the left button - otherwise click the right button (the file will be automatically downloaded).

Step 5: Run the update.

When the update is complete the pedal will automatically restart and will be ready for use.

Specifications :

- Input impedance : 1 Meg Ohm.
- Output impedance : 500 Ohm.
- Max input level : +7.23 dBV = 9.45 dBu = 2.3 V RMS = 6.5 Vpp.
(EQ set to 'flat' curve, input level is set to 0dB, and Boost is OFF)
- Max Boost level : +15dB.
- SNR : 114 dB typical.
- Frequency Response: 20 Hz to 20 KHz.
- AD/DA : 24-bit, 48 KHz .
- Latency : ~ 2ms.
- Bypass : Buffered.

-
- Input jack : 1/4" TRS (Tip: Left channel, Ring: Right channel).
 - Output jack : 1/4" TS.
 - MIDI In/Thru jacks : 1/8" TRS (Type A).
-

-
- Power source : 9VDC (negative center, 2.1 mm inner diameter)
 - Current draw : ~250 mA.
 - Dimension : 12 x 12 cm (4.7 x 4.7 inch)
-

Key Features :

- 2 channel EQ + Boost.
- The two processing channels can be linked or configured/run independently.
- 3 EQ engines (Parametric EQ, Simple EQ, and Pultec Midrange EQ emulation) with the ability to stack and run two engines simultaneously.
- 64 presets.
- Master Volume and Input Level trim.
- Built-in libraries of ready-to-use 'Prototype EQs' for quick tone-shaping workflow.
- Optional Limiter and Stereo Expansion processings.
- Flexible routing schemes : **Mono to Stereo**, **Dual Mono**, and **Stereo to Mono**.
- True EQ response curve display provides excellent visualization of the frequency response.
- Aux switches control input.
- MIDI Input and Thru.

Visit the product page at our website for more demo videos, sound clips, FAQs, and updates.

This product is designed and manufactured by :



Email : info@gfisystem.com

Web : www.gfisystem.com

GFI System

Jakarta, Indonesia.