
## **Performance Penthouse Light Board Cheat Sheet:**

- Turn on board via power switch under front lip of board (make sure all cables are plugged in first).
- Board will take a while to start up
- Use the top bank of sliders (they are labeled on the board) to create different lighting looks in the room and shift between them
- If you want to bring up specific lights, refer to the "magic sheet" on the back of this and type in the number corresponding to the lights you want to bring up on the number pad. Then hit [@] and a value from 0-100 and then [Enter] to set their brightness. Hit the [Undo] key several times to turn them off and release control of them.
- To shut the board down, move the mouse to the top of the screen so the menu bar appears, click on the File menu and then Click Exit. Then click the power button in the lower left corner of the screen, to the right of where it says "Run Palette." The board will then (slowly) shut down.
- In case the board crashes, you can hard power down the board by holding down the power button. Only do this if you absolutely need to.

Slider #	Function
1	House Lights (Hanging lights)
2	Big Stage (lighting for a large area against the sliding panels)
3	Small Stage (lighting for a smaller area against the sliding panels)
4	Panel (lighting for a panel near the sliding panels that won't wash out the projection screen)
5	Lectern (lighting for a lectern placed near the AV/Crestron panels)
6	Corner (lighting for a performance in the NE window corner of the room)
7	Color Wash (A blue/purple wash of color in the space)
8	Gobo (Wall Textures—lighting the wood panels with a textured pattern)
9	Foyer (foyer lights)



Wall Textures: 73-74