### Chapter 13

#### **Planning Life Tests for Estimation**

W. Q. Meeker, L. A. Escobar, and F. G. Pascual Iowa State University, Louisiana State University, and Washington State University.

Copyright 2021 W. Q. Meeker, L. A. Escobar, and F. G. Pascual.

Based on Meeker, Escobar, and Pascual (2021): Statistical Methods for Reliability Data, Second Edition, John Wiley & Sons Inc.

May 24, 2021 10h 59min

### Chapter 13 Planning Life Tests for Estimation

Topics discussed in this chapter are:

- The basic ideas behind planning a life test.
- A simple method to choose a sample size as a function of estimation precision.
- How to use simulation to anticipate life test results, visualize estimation precision, and assess tradeoffs between sample size and length of a study.
- How to obtain large-sample approximate variance factors for a general quantity of interest.
- How to obtain large-sample approximate variance factors for a function of the parameters of a log-location-scale distribution.

Chapter 13

Segment 1

Basic Ideas Behind Life-Test Planning, Planning Values, and the Sample-Size Tool

#### **Basic Ideas in Test Planning**

- The enormous cost of reliability studies makes it essential to do careful planning. Frequently asked **questions** include:
  - ► How many units do I need to test in order to estimate the 0.1 quantile of life?
  - ▶ How long do I need to run the life test?

More test units and more time will provide more information and thus more precision in estimation (e.g., narrower confidence intervals).


• To anticipate the results from a test plan and to respond to the questions above, it is necessary to have some **planning** information about the life distribution to be estimated.

### Engineering Planning Values and Assumed Distribution for Planning a Life Test

Want to estimate  $t_{0.1}$  of the life distribution of a metal spring. Tests are run at higher than usual cycling rate to cause failures to occur more quickly.

- Information from engineering:
  - ► The Weibull distribution will be used to describe the failure-time distribution.
  - ▶ The Weibull shape parameter  $\beta^{\square} = 2$  will be used.
  - ► Expect about 10% failures by 40 thousand cycles of operation  $(t_{0.10}^{\square} = 40)$ .
- Start by using a simple analytical method to suggest a sample size.
- Use simulation to get insight and fine-tune the test plan.

## Weibull Probability Paper Showing the Metal Spring cdf Corresponding to the Test Planning Values $t_{0.10}^\square=40$ and $\beta^\square=2$



### Motivation for Use of Large-Sample Approximate Test Plan Properties

Large-sample approximate test plan properties provide:

- Simple expressions giving **precision** of a specified estimator as a **function of sample size**.
- Simple expressions giving needed sample size as a function of precision of a specified estimator.
- Simple tables, graphs, and **software** that will allow easy assessments of tradeoffs in test planning decisions like sample size and test length.
- Can be fine tuned with simulation evaluation.

### Sample Size Formula for the Mean of a Normal Distribution

• A Wald approximate  $100(1-\alpha)\%$  confidence interval for the normal distribution mean  $\mu$  is

$$[\underline{\mu}, \ \widetilde{\mu}] = \widehat{\mu} \mp z_{(1-\alpha/2)} \frac{\widehat{\sigma}}{\sqrt{n}} = [\widehat{\mu} - \widehat{D}, \ \widehat{\mu} + \widehat{D}]$$

where the half-width  $\widehat{D}=z_{(1-\alpha/2)}\widehat{\sigma}/\sqrt{n}$  can be used to describe the precision for estimating  $\mu$  as a function of n.

• Substituting the planning value  $(\sigma^{\square})^2$  for  $\widehat{\sigma}$  and the target precision value  $D_T$  for  $\widehat{D}$  and solving for n gives the needed sample size to estimate  $\mu$  with **complete data** as

$$n = \frac{z_{(1-\alpha/2)}^2(\sigma^{\Box})^2}{D_T^2},$$

- This formula appears in most elmentary textbooks.
- This chapter generalizes this formula to allow for estimation of and desired quantile of a specified (log-)location-scale distributions and allowing for censoring.

### Confidence Interval for an Unrestricted Quantile (e.g., $-\infty < y_p < \infty$ )

• For an unrestricted quantile  $y_p$  a Wald approximate  $100(1-\alpha)\%$  confidence interval is given by

$$[\underline{y}_p, \ \widetilde{y}_p] = \widehat{y}_p \mp z_{(1-\alpha/2)} \sqrt{\widehat{\mathsf{Var}}(\widehat{y}_p)}$$
$$= [\widehat{y}_p - \widehat{D}, \ \widehat{y}_p + \widehat{D}]$$

where

$$\widehat{D} = z_{(1-\alpha/2)} \sqrt{\widehat{\operatorname{Var}}(\widehat{y}_p)} = z_{(1-\alpha/2)} \sqrt{\frac{\widehat{\sigma}^2}{n}} V_{\widehat{y}_p},$$

where  $V_{\widehat{y}_p}$  is a variance factor **depending on** p, the **amount of censoring**, and the underlying distribution  $\Phi(z)$ .

• The half-width  $\widehat{D}$  of the interval and can be used to assess estimation precision for  $y_p$  as a function of n and amount of censoring (related to the length of the test).

### Sample Size Formulas for an Unrestricted Quantile (e.g., $-\infty < y_p < \infty$ )

Recall the confidence interval half width

$$\widehat{D} = z_{(1-\alpha/2)} \sqrt{\widehat{\operatorname{Var}}(\widehat{y}_p)} = z_{(1-\alpha/2)} \sqrt{\frac{\widehat{\sigma}^2}{n}} V_{\widehat{y}_p},$$

• Substituting the planning value  $\sigma^{\square}$  for  $\widehat{\sigma}$  and the target half-width  $D_T$  for  $\widehat{D}$  and solving for n gives;

$$n = \frac{z_{(1-\alpha/2)}^2 (\sigma^{\square})^2 \mathsf{V}_{\widehat{y}_p}}{D_T^2}$$

as the sample size needed to estimate  $y_p$  with target precision  $\mathcal{D}_T.$ 

• The variance factor  $V_{\widehat{y}_p}$  can be obtained from tables, plots or computer algorithms.

### Sample Size For Estimating the 0.50 Quantile of Lightbulb Life

• The needed sample size to estimate  $t_p$ , a log-location-scale distribution p quantile with censored data and precision  $R_T$  is:

$$n = \frac{z_{(1-\alpha/2)}^2 (\sigma^{\Box})^2 V_{\widehat{y}_p}}{[\log(R_T)]^2}$$

where  $V_{\widehat{y}_p}$  is a variance factor depends on the **quantile of** interest p, the amount of censoring,  $p_c$  and the underlying distribution  $\Phi(z)$ .

### Confidence Interval for a Positive Quantile (e.g., $0 < t_p < \infty$ )

• For a positive quantile  $t_p$  a Wald approximate  $100(1-\alpha)\%$  confidence interval for  $\log(t_p)$  is given by

$$\left[ \underbrace{\log(t_p)}, \ \widetilde{\log(t_p)} \right] = \log(\widehat{t}_p) \pm z_{(1-\alpha/2)} \sqrt{\widehat{\operatorname{Var}}\left[\log(\widehat{t}_p)\right]}.$$

Taking antilogs yields a confidence interval for  $t_p$ 

$$[t_p, \ \widetilde{t_p}] = [\widehat{t_p}/\widehat{R}, \ \widehat{t_p}\widehat{R}]$$

where

$$\widehat{R} = \exp\left\{z_{(1-\alpha/2)}\sqrt{\widehat{\operatorname{Var}}\left[\log(\widehat{t}_p)\right]}\right\} = \exp\left\{z_{(1-\alpha/2)}\sqrt{\frac{\widehat{\sigma}^2}{n}V_{\widehat{y}_p}}\right\}.$$

• The unitless  $\hat{R} > 1$  precision factor is directly related to the width of the confidence interval and can be used to assess estimation precision for  $t_p$  as a function of sample size n and the length of the test.

### Sample Size Formulas for a Positive Quantile (e.g., $0 < t_p < \infty$ )

• The needed sample size to estimate  $t_p$ , a log-location-scale distribution p quantile with censored data and precision  $R_T$  is:

$$n = \frac{z_{(1-\alpha/2)}^2 (\sigma^{\Box})^2 V_{\widehat{y}_p}}{[\log(R_T)]^2}$$


where  $V_{\widehat{y}_p}$  is a variance factor depends on the **quantile of** interest p, the amount of censoring,  $p_c$  and the underlying distribution  $\Phi(z)$ .

The variance factor is defined as


$$V_{\widehat{y}_p} = \frac{n}{\sigma^2} Avar \left[ log(\widehat{t}_p) \right] = \frac{n}{\sigma^2} Avar[\widehat{y}_p]$$

where  $Avar[log(\hat{t}_p)]$  is the large-sample approximate variance of  $log(\hat{t}_p)$ .


### Sample Size Tool Weibull Distribution Test Planning Values $t_{0.10}^{\square}=40$ and $\beta^{\square}=2$ Censoring Time $t_c=50$ Thousand Cycles




### Sample Size Tool Weibull Distribution Test Planning Values $t_{0.10}^{\Box}=40$ and $\beta^{\Box}=2$ Censoring Time $t_c=50$ Thousand Cycles



# Variance Factor $V_{\log(\hat{t}_p)}$ for ML Estimation of Weibull Distribution Quantiles as a Function of $p_c$ , the Population Proportion Failing by Time $t_c$ , and p, the Quantile of Interest



# Variance Factor $V_{\log(\widehat{t}_p)}$ for ML Estimation of Lognormal Distribution Quantiles as a Function of $p_c$ , the Population Proportion Failing by Time $t_c$ , and p, the Quantile of Interest



### Figures for Sample Sizes to Estimate Weibull and Lognormal Quantiles

Figures give plots of the factor  $V_{\log(\hat{t}_p)}$  for the quantile of interest p as a function of  $p_c = \Pr(Z \leq \zeta_c)$  for the Weibull, lognormal, and loglogistic distributions. The plots show:

- Increasing the length of a life test (increasing the expected proportion of failures) will always reduce the asymptotic variance. After a point, however, the returns are diminishing.
- Estimating quantiles with large or small p generally results in larger variance factors than quantiles somewhat larger than the expected proportion failing  $p_c$ .
- When possible, it is better practice to run a life test long enough to avoid extrapolation (i.e., so that  $p_c > p$ ).

### Sample Size Formulas Estimating the 0.10 Quantile of Spring Life

• The needed sample size to estimate  $t_p$ , a log-location-scale distribution p quantile with censored data and precision  $R_T$  is:

$$n = \frac{z_{(1-\alpha/2)}^2 (\sigma^{\square})^2 V_{\widehat{y}_p}}{[\log(R_T)]^2}$$

where  $V_{\widehat{y}_p}$  is a variance factor depends on the **quantile of** interest p, the amount of censoring,  $p_c$  and the underlying distribution  $\Phi(z)$ .

The variance

### Meeting the Precision Criterion

- By the definition of a confidence interval, in repeated samples approximately  $100(1-\alpha)\%$  of the intervals for  $t_p$  will actually contain the true  $t_p$ .
- In repeated samples,  $\widehat{\text{Var}}[\log(\hat{t}_p)]$  is random because  $\widehat{\sigma}$  and the proportion failing in the test are random.
- If

$$\widehat{\mathsf{Var}}igl[\mathsf{log}(\widehat{t}_p)igr] > \mathsf{Avar}igl[\mathsf{log}(\widehat{t}_p)igr]$$

then

$$\hat{R} > R_T$$
.

- Generally,  $\Pr(\hat{R} > R_T) \approx 0.50$ .
- Thus there is about a 50% chance that the width of the interval will be greater than (or less than) the target.

Chapter 13


Segment 2

Using Simulation in Life-Test Planning


### Simulation as a Tool for Test Planning

- Use assumed model and planning values of model parameters to simulate data from the proposed study.
- Analyze the data perhaps under different assumed models.
- Assess precision provided.
- Simulate many times to assess actual sample-to-sample differences.
- Summarize the results.
- Repeat with different test plans to assess tradeoffs.
- Repeat with different input planning values to assess sensitivity to these inputs.


Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box} = 40$  and  $\beta^{\Box} = 2$  Test Plan: n = 45,  $t_c = 30$  Thousand Cycles




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box} = 40$  and  $\beta^{\Box} = 2$  Test Plan: n = 45,  $t_c = 50$  Thousand Cycles




Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box} = 40$  and  $\beta^{\Box} = 2$  Test Plan: n = 45,  $t_c = 30$  Thousand Cycles




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box}=40$  and  $\beta^{\Box}=2$  Test Plan: n=45,  $t_c=120$  Thousand Cycles




Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box} = 40$  and  $\beta^{\Box} = 2$  Test Plan: n = 45,  $t_c = 50$  Thousand Cycles




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 




Test Planning Values:  $t_{0.10}^{\square} = 40$  and  $\beta^{\square} = 2$ 



Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box}=40$  and  $\beta^{\Box}=2$  Test Plan: n=180,  $t_c=30$  Thousand Cycles



Summary of Simulated Weibull Life Tests Test Planning Values:  $t_{0.10}^{\Box} = 40$  and  $\beta^{\Box} = 2$  Test Plan: n = 45,  $t_c = 50$  Thousand Cycles



## Metal Spring Life Tests Trade-offs Between Test Length and Sample Size

The geometric mean of the precision factors  $\widehat{R}$  from 2000 simulated life tests for combinations of sample sizes n and test lengths  $t_c$  (conditional on  $r \geq 1$  failures).

Test Length $t_c$	Sample 45	e Size <i>n</i> 180
30	2.45 (2.6)	1.49 (10.4)
50	1.56 (6.8)	
120	1.46 (27.6)	

Numbers in parenthesis are the expected number of failures for the test plans.

## Summary of Simulations of the Proposed Metal Spring Life Tests to Estimate $t_{0.10}$

- For the  $t_c = 30$  and n = 45 life test:
  - ▶ Enormous amount of variability in the ML estimates.
  - ► For many of the simulated data sets, no ML estimates exist because all units were censored.
- For the  $t_c = 50$  and n = 45 life test:
  - ► A much more stable estimation process.
  - ► A substantial improvement in precision.
- For the  $t_c = 120$  and n = 45 life test:
  - ▶ Only a small improvement in estimation of  $t_{0.10}$ , relative to the  $t_c = 50$  and n = 45 test.
  - ► A big improvement for estimation of larger quantiles.
- For the  $t_c = 30$  and n = 180 life test:
  - ▶ Stable estimation and good precision, but
  - ► Some extrapolation is required.

## Chapter 13

## Segment 3

Large-Sample Approximate Variances,
Justification of the Sample-Size Formula,
and Exponential Distribution Example

#### Large-Sample Approximate Variances

Under certain regularity conditions, the following results hold asymptotically (large sample)

ullet  $\widehat{ heta}$   $\stackrel{.}{\sim}$  MVN $( heta, \Sigma_{\widehat{ heta}})$ , where  $\Sigma_{\widehat{ heta}} = I_{ heta}^{-1}$ , and

$$I_{\theta} = \mathbb{E}\left[-\frac{\partial^{2}\mathcal{L}(\theta)}{\partial\theta\partial\theta'}\right] = \sum_{i=1}^{n} \mathbb{E}\left[-\frac{\partial^{2}\mathcal{L}_{i}(\theta)}{\partial\theta\partial\theta'}\right].$$

ullet Usually, interest centers on a scalar function of eta, such as a quantile or a failure probability.

## Large-Sample Approximate Variances of Scalar Functions of the ML Estimators

• For a scalar quantity of interest (or a one-to-one function of a quantity of interest)  $g = g(\widehat{\theta}) \stackrel{.}{\sim} \text{NORM}[g(\theta), \text{Avar}(\widehat{g})],$  where

$$\operatorname{Avar}(\widehat{g}) = \left[\frac{\partial g(\boldsymbol{\theta})}{\partial \boldsymbol{\theta}}\right]' \Sigma_{\widehat{\boldsymbol{\theta}}} \left[\frac{\partial g(\boldsymbol{\theta})}{\partial \boldsymbol{\theta}}\right].$$

- A one-to-one function of a quantity of interest is often used to set the Wald confidence interal on a scale that is unrestricted (e.g., using  $y_p = \log(t_p)$  instead of  $t_p$ ).
- ullet Generally, a variance factor that does not depend on  $\sigma$  or n can be obtained from

$$V_{\widehat{g}} = \frac{n}{\sigma^2} \mathsf{Avar}(\widehat{g})$$

# Sample Size Needed to Estimate the Mean of an Exponential Distribution Used to Describe Insulation Life

- Need a test plan that will estimate the mean life of insulation specimens at highly-accelerated (i.e., higher than usual voltage to get failure information quickly) conditions.
- Desire a 95% confidence interval with endpoints that are approximately 50% away from the estimated mean (so  $R_T=1.5$ ).
- Can assume an exponential distribution with a mean  $\theta^{\square} = 1000$  hours.
- Simultaneous testing of all units; must terminate the test at 500 hours.

# Sample Size Needed to Estimate the Mean of an Exponential Distribution Used to Describe Insulation Life-Continued

• ML estimate of the exponential mean is  $\widehat{\theta}=TTT/r$ , where TTT is the total time on test and r is the number of failures. It follows that

$$V_{\widehat{\theta}} = n \operatorname{Avar}(\widehat{\theta}) = \frac{n}{\operatorname{E}\left[-\frac{\partial^2 \mathcal{L}(\theta)}{\partial \theta^2}\right]} = \frac{\theta^2}{1 - \exp\left(-\frac{t_c}{\theta}\right)}$$

from which, using the delta method,

$$V_{\log(\widehat{\theta})}^{\square} = \frac{V_{\widehat{\theta}}^{\square}}{(\theta^{\square})^2} = \frac{1}{1 - \exp(-\frac{500}{1000})} = 2.5415.$$

Thus the number of needed specimens (note that implicitly  $\sigma^\square=1$ ) is

$$n = \frac{z_{(1-\alpha/2)}^2 V_{\log(\widehat{\theta})}^{\square}}{[\log(R_T)]^2} = \frac{(1.96)^2 2.5415}{[\log(1.5)]^2} \approx 60.$$

Chapter 13

Segment 4

Computation of Approximate Variance Factors for Log-Locations-Scale Distributions and an Example

# Location-Scale Distributions and Single Right Censoring Asymptotic Variance-Covariance

Here we specialize the computation of sample sizes to situations in which

- log(T) is location-scale  $\Phi$  with parameters  $(\mu, \sigma)$ .
- ullet When the data are Type I singly right censored at  $t_c$ ,

$$\frac{n}{\sigma^{2}} \Sigma_{(\widehat{\mu},\widehat{\sigma})} = \begin{bmatrix} V_{\widehat{\mu}} & V_{(\widehat{\mu},\widehat{\sigma})} \\ V_{(\widehat{\mu},\widehat{\sigma})} & V_{\widehat{\sigma}} \end{bmatrix} = \begin{bmatrix} \frac{\sigma^{2}}{n} I_{(\mu,\sigma)} \end{bmatrix}^{-1} = \begin{bmatrix} f_{11} & f_{12} \\ f_{12} & f_{22} \end{bmatrix}^{-1} \\
= \left( \frac{1}{f_{11} f_{22} - f_{12}^{2}} \right) \begin{bmatrix} f_{22} & -f_{12} \\ -f_{12} & f_{11} \end{bmatrix}$$

where the  $f_{ij}$  values depend only on  $\Phi$  and the standardized censoring time  $\zeta_c = [\log(t_c) - \mu]/\sigma$  [or equivalently, the proportion failing by  $t_c$ ,  $p_c = \Phi(\zeta_c)$ ].

# Location-Scale Distributions and Single Right Censoring Fisher Information Elements

The  $f_{ij}$  values are defined as:

$$f_{11} = f_{11}(\zeta_c) = \frac{\sigma^2}{n} \mathbb{E} \left[ -\frac{\partial^2 \mathcal{L}_i(\mu, \sigma)}{\partial \mu^2} \right]$$

$$f_{22} = f_{22}(\zeta_c) = \frac{\sigma^2}{n} \mathbb{E} \left[ -\frac{\partial^2 \mathcal{L}_i(\mu, \sigma)}{\partial \sigma^2} \right]$$

$$f_{12} = f_{12}(\zeta_c) = \frac{\sigma^2}{n} \mathbb{E} \left[ -\frac{\partial^2 \mathcal{L}_i(\mu, \sigma)}{\partial \mu \partial \sigma} \right]$$

The  $f_{ij}$  values are available from tables or algorithm LSINF for the SEV (Weibull), normal (lognormal), largest extreme value (Fréchet), and logistic (loglogistic) distributions.

For a single fixed censoring time, the asymptotic variance-covariance factors  $V_{\widehat{\mu}}$ ,  $V_{\widehat{\sigma}}$ , and  $V_{(\widehat{\mu},\widehat{\sigma})}$  are easily tabulated as a function of  $\zeta_c$ .

## Table of Information Matrix Elements and Variance Factors

Table C.20 provides for the normal/lognormal distributions, as functions of the standardized censoring time  $\zeta_c = [\log(t_c) - \mu]/\sigma$ :

- 100 $\Phi(\zeta_c)$ , the percentage in the population failing by the standardized censoring time.
- Fisher information matrix elements  $f_{11}, f_{22}$ , and  $f_{12}$ .
- The asymptotic variance-covariance factors  $V_{\widehat{\mu}}$ ,  $V_{\widehat{\sigma}}$ , and  $V_{(\widehat{\mu},\widehat{\sigma})}$ .
- Asymptotic correlation  $\rho_{(\widehat{\mu},\widehat{\sigma})}$  between  $\widehat{\mu}$  and  $\widehat{\sigma}$ .
- The  $\sigma$ -known asymptotic variance factor  $V_{\widehat{\mu}|\sigma}=(n/\sigma^2) \operatorname{Avar}(\widehat{\mu}|\sigma)$ , and the  $\mu$ -known factor  $V_{\widehat{\sigma}|\mu}=(n/\sigma^2) \operatorname{Avar}(\widehat{\sigma}|\mu)$ .

## Sample Size to Estimate a Quantile of T when log(T) is Location-Scale $(\mu, \sigma)$

- Let  $g(\theta) = t_p$  be the p quantile of T. Then  $y_p = \log(t_p) = \mu + \Phi^{-1}(p)\sigma$ , where  $\Phi^{-1}(p)$  is the p quantile of the standardized random variable  $Z = [\log(T) \mu]/\sigma$ . Suppose that the censoring time is  $t_c$ .
- ullet The needed sample size, for a given target precision  $R_T$  factor is n is

$$n = \frac{z_{(1-\alpha/2)}^2 (\sigma^{\square})^2 V_{y_p}}{[\log(R_T)]^2}$$

where

$$V_{y_p} = V_{\widehat{\mu}} + \left[\Phi^{-1}(p)\right]^2 V_{\widehat{\sigma}} + 2\left[\Phi^{-1}(p)\right] V_{(\widehat{\mu},\widehat{\sigma})}$$

is obtained a function of the quantile of interest p and and the proportion failing at the end of the test  $p_c = \Pr(T \leq t_c)$ .

• Figure 10.5 gives  $V_{y_p}$  as a function of p and  $p_c$  for the Weibull distribution.

## Generalization: Location-Scale Parameters and Multiple Censoring

In some applications, a life test may run in parts, each part having a different censoring time (e.g., testing at two different locations or beginning as lots of units to be tested are received). In this case we need to generalize the single-censoring formula. Assume that a proportion  $\delta_i$   $(\sum_{i=1}^k \delta_i = 1)$  of data are to be run until right censoring time  $t_{c_i}$  or failure (which ever comes first). In this case,

$$\frac{n}{\sigma^2} \Sigma_{(\widehat{\mu}, \widehat{\sigma})} = \begin{bmatrix} V_{\widehat{\mu}} & V_{(\widehat{\mu}, \widehat{\sigma})} \\ V_{(\widehat{\mu}, \widehat{\sigma})} & V_{\widehat{\sigma}} \end{bmatrix} = \begin{bmatrix} \frac{\sigma^2}{n} I_{(\mu, \sigma)} \end{bmatrix}^{-1}$$

$$= \left( \frac{1}{J_{11} J_{22} - J_{12}^2} \right) \begin{bmatrix} J_{22} & -J_{12} \\ -J_{12} & J_{11} \end{bmatrix}$$

where  $J_{11} = \sum_{i=1}^k \delta_i f_{11}(z_{c_i}), J_{22} = \sum_{i=1}^k \delta_i f_{22}(z_{c_i}),$  and  $J_{12} = \sum_{i=1}^k \delta_i f_{12}(z_{c_i})$  where  $z_{c_i} = (\log(t_{c_i}) - \mu)/\sigma$ .

In this case, the asymptotic variance-covariance factors  $V_{\widehat{\mu}}$ ,  $V_{\widehat{\sigma}}$ , and  $V_{(\widehat{\mu},\widehat{\sigma})}$  depend on  $\Phi$ , the standardized censoring times  $z_{c_i}$ , and the proportions  $\delta_i$ ,  $i=1,\ldots k$ .

#### References

Meeker, W. Q., L. A. Escobar, and F. G. Pascual (2021). Statistical Methods for Reliability Data (Second Edition). Wiley. [1]