
Lab 4


Part 1

Step 7: Test the simulator in the presence of noise. Increase the message word length to Na=1000 bits and simulate Nf=1000 message words. For EbN0/ in the range of 0 dB to 10 dB with a step size of 1 dB, plot the BER vs. EbN0/ in a graph.




Nt = 20


Repeat the experiment for different training sequence lengths (NT=1, NT=10, NT=20, and NT=100)



Nt = 1



Nt = 10



Nt = 100