



90_MIPI_AP_TO_DISPLAY_D0_CONN_P
90_MIPI_AP_TO_DISPLAY_D0_CONN_N
90_MIPI_AP_TO_DISPLAY_D1_CONN_P
90_MIPI_AP_TO_DISPLAY_D1_CONN_N
90_MIPI_AP_TO_DISPLAY_D2_CONN_P
90_MIPI_AP_TO_DISPLAY_D2_CONN_N

90_MIPI_AP_TO_DISPLAY_D3_CONN_P
90_MIPI_AP_TO_DISPLAY_D3_CONN_N
90_MIPI_AP_TO_DISPLAY_CLK_CONN_P
90_MIPI_AP_TO_DISPLAY_CLK_CONN_N
I2C_DISPLAY_SDA_IV8
I2C_DISPLAY_SCL_IV8

IO_AOP_FROM_DISPLAY_TE
IO_AOP_TO_DISPLAY_MIPI_PWR_DWN
CLK_GPIO_SEQ_PMU_TO_DISPLAY_32K_IV8_CONN
GPIO_AP_FROM_DISPLAY_PANEL_ID_CONN
GPIO_DISPLAY_TO_TOUCH_BSYNCL_IV8_CONN
PPIV2_DISPLAY_S2_CONN

PPIVX_DISPLAY_S2_CONN
PP3V0_DISPLAY_S2_CONN
PPIV8_DISPLAY_DVDD_CONN