

Departure Route Description

Unless otherwise assigned by ATC:

Rwy 14L – ½: Maintain **10000**. Contact Edmonton Centre passing **5300**. Do not exceed 240 kt until KODEM. Climb track **141°** to OVDAB, then track **144°** to KODEM, then via assigned route.

Rwy 14R – ½: Maintain **10000**. Contact Edmonton Centre passing **5300**. Do not exceed 240 kt until KODEM. Climb track **141°** to KODEM, then via assigned route.

Expect clearance to flight planned altitude/flight level within 10 minutes after departure.

DEPARTURE CLIMB RATE V/V (FPM)

GROUND SPEED	90	120	140	160	180	200	250	300
310 FT/NM	470	620	730	830	930	1040	1300	1550
350 FT/NM	530	700	820	940	1050	1170	1460	1750
430 FT/NM	650	860	1010	1150	1290	1440	1800	2150

VIGBO TRANSITION: Requires a minimum climb gradient of **310 ft/NM** to **4400**.
(KODEM4.VIGBO) Climb track **086°** to URSEK, then to VINVI, then to DUNDU. Then climb track **124°** to ALIXU, then climb track **125°** to VIGBO to the assigned route.

LESEX TRANSITION: Requires a minimum climb gradient of **350 ft/NM** to **4900**.
(KODEM4.LESEX) Climb track **141°** to VETVO, then to ALOVA. Then climb track **124°** to LESEX to the assigned route.

EMKUR TRANSITION: Requires a minimum climb gradient of **430 ft/NM** to **7200**.
(KODEM4.EMKUR) Do not exceed 240 kt until NOREP. Climb track **086°** to URSEK, then climb track **039°** to NOREP. Then climb track **313°** to IMISA, then climb track **326°** to ULUKA. Then climb track **333°** to AGPIX, then climb track **323°** to EMKUR to the assigned route.

Communication Failure

On recognition of failure 10 minutes or less after take-off and in IFR weather conditions proceed as follows:

1. Select transponder code 7600.
2. Maintain last assigned altitude until:
 - ALIXU if on VIGBO transition, or
 - VETVO if on LESEX transition, or
 - ULUKA if on EMKUR transition.
3. Upon reaching ALIXU, VETVO or ULUKA, climb to flight planned altitude/flight level.
4. Proceed directly on course.

Note: If communication failure occurs more than 10 minutes after take-off, comply with the appropriate procedure for communication failure enroute.