

NOISE ABATEMENT PROCEDURES

Turbo Jet

Departure Procedures

Rwy	NADP
08, 13, 31	1 or 2

Rwys 08 and 13:
Maximum allowable rate of climb on runway heading to **4000'** ASL before proceeding on course.

Rwy 26:
No restrictions.

Rwy 31:
On right turn out, climb on runway heading to **4000'** ASL before proceeding on course. Other directions unrestricted.

All Aircraft
Consistent with safe operating procedures, controllers will assign runways to divert as many departures and arrivals as possible from flight over noise sensitive areas.

During periods when the tower is not in operation, pilots will be expected to use rwy 08 or 13 for landing and rwy 26 or 31 for take-off when operational conditions permit.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved