

Departure Route Description

Rwy08: Climb direct UDGOR for vectors to assigned route.
Maintain **3000** or higher as assigned.

Communication Failure

On recognition of communication failure 10 minutes or less after take-off and in IFR weather conditions, proceed as follows:

- 1. Transponder 7600;
- 2. Upon reaching **3000** or last assigned altitude, whichever is higher, proceed directly on course;
- 3. Maintain this altitude for 10 minutes after take-off; then,
- 4. Climb to flight planned altitude.

Note: If communication failure occurs more than 10 minutes after take-off, comply with the appropriate procedures for communication failure enroute.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved