

Departure Route Description

Rwy 20: Climb hdg **200°** to **2900**, then direct to OBMOX, then track **200°** via HAMPO for vectors to assigned route. Maintain **6000** or flight planned altitude, whichever is lower.

Note: Refer to Noise Abatement Procedures for additional requirements.

Communication Failure

On recognition of failure 10 minutes or less after take-off and in IFR weather conditions, proceed as follows:

- 1. Select transponder code 7600;
- 2. Maintain **6000**;
- 3. Upon reaching HAMPO, proceed on course and climb to flight planned altitude.

Note: If communication failure occurs more than 10 minutes after take-off, comply with the appropriate procedure for communication failure enroute.

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved