

NOISE ABATEMENT PROCEDURES

APPLICATION

These procedures apply to all aircraft.

PREFERENTIAL RUNWAYS

ATC will designate runways to maximize airport capacity. Use of other than designated runways should only be requested to meet operational necessity.

Taking into consideration the following conditions and except as authorized by ATC, aircraft can expect the following preferential runway combinations between the hours of 0630 and 2230 local:

Rwy Combination	Primary Departure Rwy	Secondary Departure Rwy	Primary Arrival Rwy	Secondary Arrival Rwy
30/02	02	Not designated	30	02
30/20	20	Not designated	30	20
12/02	02	12	12	02
12/20	12	Not designated	20	12

1. Physical condition of the surface.
2. Effective tailwind component not to exceed 5 knots.
3. Effective crosswind component not to exceed 25 knots.
4. Effective crosswind component not to exceed 15 knots on a wet runway.
5. When two (2) arrival runways are available, arrivals destined for locations north of the main apron should not plan arrival on rwys 12 or 30, with the exception of the 30/20 rwy combination.
6. Other safety considerations declared by the Captain of the aircraft.

TURBO JET/TURBO FAN**Departure Procedures**

Rwy	NADP
All rwys	1 or 2

Rwy 12:

Turbo-jet/Turbo-fan aircraft. No right turns W of KEKBI.

Arrival Procedures – VFR and Visual Approach

- a. Avoid flying over the town of Leduc below **5000'** ASL.
- b. Rwy 30 – right hand circuits.