



Arrival Procedures

- 1. Jet aircraft circuit altitude is **3200** ASL, conventional circuit altitude is **2500** ASL (weather permitting).
- 2. Jet aircraft in the circuit will maintain **3200** ASL until commencing base turn.
- 3. Jet aircraft straight-in approaches, maintain **3000** ASL as long as practicable before commencing final descent.
- 4. When rwy 13 in use, remain on or above the PAR or PAPI glide slope to the extent practicable. Consistent with safety of operations, aircraft should be flown on the approach so as to give the best possible performance with respect to noise abatement (flap and gear selection, power settings).

Source of Canadian Civil Aeronautical Data: © 2026 NAV CANADA All rights reserved

