

Turbo Jet/Turbo-Fan

Departure Procedures

Rwy	NADP
13, 18, 36	1 or 2
31	N/A

Rwy 13:

Climb to **4000** before commencing any assigned turn.

Rwy 18:

RNAV: Do not commence any assigned turn until DUXUS.

Vector: Do not commence any assigned turn until **4.3 DME**.

Rwy 36:

- Between **0701 - 2259** local time: climb to **4000** before commencing any assigned right turn.
- Between **2300 - 0700** local time: climb to **4000** before commencing any assigned turn.

Arrival Procedures

- Intercept final apch at or outside the NDB final approach fix for the runway in use. (Circuit t/c may turn inside the FAF as required.)
- Intercept final apch at or above **2000 ASL**.

All Aircraft

Preferential Runway Determination

Consistent with safe operating procedures, ATC will assign runways to divert as many departures and arrivals as possible from flight over noise-sensitive areas. Unless operational conditions do not permit, pilots shall accept runways as assigned by ATC.

The preferred order for runway usage is:

Arrivals: 13, 18, 36, 31

Departures: 36, 31, 18, 13

Rwy 36 is the preferred calm wind runway for departure except for:

- Propeller driven acft, and;
- Westbound acft may be auth or assigned 31.

Arrival Procedures

- Circuit height is **2000 ASL** (weather permitting).
- Maintain **2000 ASL** or above as long as practicable before commencing final descent and remain on or above the ILS or PAPI glide slope.
- Consistent with safety of operations, aircraft should be flown on the approach so as to give the best possible performance with respect to noise abatement (flap and gear selection, power settings).

NOTE: For night operations – See **Night Restrictions** on the following page.