COOKING PROGRAMME TABLE

| Cooking Time Programs Automatic | Food | Default | Range | Temperature (°C) Manual (adjust temp. setting) | Food Type | Default | Range | Temperature Closed |
|---|---|---|---|---|---|---|---|---|
| Simmer | 4 | Veg<br>Fish<br>Poultry<br>Veg | 30min<br>40min<br>50min<br>60min | 5min-3h | | | | 100 °C |