COOKING PROGRAMME TABLE

Cooking Time Programs Automatic	Food	Temperature (°C) Default	Range		Manual (adjust temp. setting)
Food Type	Default	Range			
Programs Automatic	Food	Default	Range	Temperature	Closed
Braise	1	25min	5min-3h	100 °C	