COOKING PROGRAMME TABLE

Cooking Time Programs Automatic	Food	Temperature (°C) Default	Range	Manual (adjust temp. setting)
Food Type	Default	Range		
Programs Automatic	Food	Default	Temperature Range	Closed
Braise	1	25min	5min-3h	