

DUAL INDUCTION THERMOSTATIC
SENSOR FAUCE


感应面盆龙头

MODEL/型号 :6172

BEFORE YOU BEGIN

- Please read the instructions carefully
●Please give the instructions to the end customer after installation.
●The shape and components of the product do not necessarily comply with the illumination which is only for your reference.
●The installation process is easy to implement, but we highly recommended that the plumbing is carried out by a qualified plumber.
●Please prepare the following tools: Monkey wrench, Glove, Batteries(4pcs of AA),etc.
- 请详细阅读本说明书
●安装完毕后，请务必将本说明书交给最终客户。
●产品外形及所包含配件以实物为准，示意图仅供参考。
●建议客户请专业的安装人士安装,若您认为您有较好的动手能力经验和安装经验，可自行安装。
●准备以下工具：活动扳手、手套、电池（4节5号）等。


- The following pictures for your reference do not necessarily comply with the products.
Please contact the seller if you have any question related to installation.
●Make sure all the parts are ready.
- 以下图例安装步骤仅供参考，一切以所购买实物为准，如遇到不清楚之处，请联系您的销售商。
●确认配件是否齐全。




NO	Part's name	Quantity
01	Faucet body	1
02	Power wire	1
03	Dental tube	1
04	Rubber gasket	1
05	Steel gasket	1
06	Locked nut	1
07	L Wrench 2.5	1
08	L Wrench 5	1
09	Battery box	1
10	Inlet pipe	2

编号	配件名称	数量
01	龙头组	1
02	电源线	1
03	牙管	1
04	橡胶垫	1
05	钢垫片	1
06	锁紧螺母	1
07	L扳手2.5	1
08	L扳手5	1
09	电池盒	1
10	进水管	2

- ATTENTIONS BEFORE INSTALLATION
- 安装前注意事项
1. The use who chooses AC adapter for power supply,please be sure the voltage should be 220V in the area.
2. Apply tap water to the machine. Do not use untreated sewerage or the electromagnetic valve may be damaged.
3. Avoid direct sunshine or intense light for the sensing window while choosing installation position or the performance of the machine may be affected.
4. Install an additional pressure booster when the water pressure is lower than 0.05MPa or the flush performance may be affected.
5. Install an additional pressure decreasing device when the water pressure is higher than 0.7MPa or the machine may be damaged.
6. Please turn off the angle valve before installation.
7. Suit basin as following picture.




Available for under counter basin
台下盆可安装




Unavailable for above counter basin
台上盆不可安装


- INSTALLATION OF THE FAUCET
- 龙头安装步骤
- First step:**
Align the water inlet pipe with the valve core seat hole and rotate it to the right until it is tightened.Pay attention to the left red and right blue.
Second step:
Fix the faucet on the countertop, and pass the countertop locking group one by oneTighten the water inlet/outlet hose on the screw pipe of the faucet body group, and thenTighten the two locking screws with a screwdriver.
Third step:
Put 4 AA alkaline batteries into the battery box (as shown in Figure 1Show), then connect the power cord and fix the battery box on the wall
- 第一步:**
把进水管对准阀芯座孔位向右旋转，直至拧紧，注意左红右蓝。
第二步:
固定水龙头在台面上，将台面锁紧组件依次穿过软管旋紧在龙头主体的牙管上，再用螺丝刀分别拧紧两个锁紧螺丝。
第三步:
将4节5号AA碱性电池放入电池盒中(如图一所示)，然后连接电源线并把电池盒固定在墙上



- Points to note when connecting the cold/hot water inlet hose to the angle valve:
- The first point:**
Drain the dirty water from the pipe before connecting the faucet to the water inlet pipe,Turn off the water again.
The second point:
When the water inlet hose is connected, there must be no large bending, twisting, or pulling.Wait until the state is stretched, otherwise there will be hidden dangers such as water leakage or even pipe bursting.
The third point:
When connecting the water inlet hose to the angle valve, use two suitable wrenches, oneFix the water inlet hose and the other movable nut that rotates the hose,Avoid twisting the hose when rotating with the nut; hot and cold water inlet pipeRespectively connect with the cold and hot water inlet angle valves.
- 冷/热进水管与角阀连接时注意点:**
第一点:
水嘴与进水管道连接前先把管道中脏水排尽，再关闭水源。
第二点:
进水软管连接时不能有大幅度折弯、扭曲、拉伸等状态，否则后续会有漏水甚至爆管等隐患。
第三点:
进水软管连接角阀时，选用合适扳手两把，一把固定进水软管，另一把旋转软管的活动螺母，避免软管随螺母一同旋转而扭曲；冷热水水管分别与冷热进水角阀相应连接。




- FUNCTIONS AND FEATURES
- 功能与特点
- 1.Quick response. Smart Liteon induction technology, 0.5 second switch response time, open and close the water instantly.
2.Free your hands. Open and close the water automatically with manual switch, easy to use.
3.Hygiene.The water process does not need to switch the handle, care for the health of the family.
4. Water saving. A. Water saving structure: Detailed structural design, reaching national first-level faucet water saving efficiency of 0.08L/s; B. Water saving process: Efficient and time-saving water use process.
5. Safety. PPO integrated watercourse design, The precipitation of heavy metal and other harmful substances are much lower than the national standard, real environmental protection; High pressure hose, safe and reliable.
6.Stability. Integrated, modular structure design, Greatly improve the structure accuracy, Eliminate leakage, valve core leakage and other annoying phenomenon.
7.Durability. The core components of the solenoid valve and sensor module have passed 1,000,000 times endurance test.
8.Waterproof. The waterproof design for whole product with grade IP54(splash proof type).
9.Functional protection. Weak power indicating function, Power-off automatic shutoff valve function, 1 minute timeout protection function for hand-washing, 3 minutes timeout protection function for taking water, and mandatory shutoff function.
10.Considerate.External filter net can effectively remove particulate impurities such as fine sand in water. Check valve is provided to prevent the reverse flow of hot and cold water at different pressure. Ensure safe use.
- 1.极速响应。灵动Liteon感应技术，0.5秒开关响应时间，瞬间开关水。
2.解放双手。自动开关水，无需手动，使用起来得心应手。
3.卫 生。用水过程无需开关手柄，呵护家人健康。
4.节 水。A,结构节水；精细的结构设计，达到国家一级龙头节水效能0.08L/s; B,过程节水；高效省时的用水过程。
5.安 全。PPO全塑集成式水道设计，重金属等有害物质析出远低于国家标准，真正环保；耐高压软管，安全可靠。
6.稳 定。集成式、模块化结构设计，大大提高结构精度，杜绝滴漏、阀芯渗漏等烦人现象。
7.耐 久。电磁阀与感应模块之核心部件通过100万次寿命试验；
8.防 水。整机防水设计，防水等级达到IP56(防溅型)。
9.功能保护。弱电指示功能、无电自动关阀功能、洗手1分钟超时保护功能、接水3分钟超时保护功能、强制关水功能。
10.周 到。加配外置过滤网,有效滤除水中细沙等颗粒物杂质;加配止回阀,防止停水或冷水水压不同时，冷热水的倒流;保障用水安全。



TECHNICAL STATISTICS

技术参数



Input voltage	DC 6V (4pcs of AA alkaline batteries)	
Sensing distance	Detection from front side: 230mm(±20mm)	Test on standard A4 white paperboard
	Detection from right or left side: 100mm(±20mm)	
Working water pressure	0.05-0.7MPa (0.5-7Kg/cm2)	
Water usage	4.8±0.3L/ m, Test under dynamic water pressure 0.2MPa	
Available diameter of hole for installation	Φ 32mm-35mm	
Diameter of cold/hot water hose inlet	DN15 (G1/2)	
Length of hose	600mm	
Available water temperature range	4-80℃ (40-176°F)	
Environment temperature	1-40 ℃	
Environment humidity	≤95%RH	
Water-saving efficiency	Grade I	
Waterproof grade	IP56 (splash proof type)	
Weight	About 2kgs	
Executive standard	GB18145-2014 CJ/T194-2014	

输入电源	A用50次/天<开关水一次计为一次>，南孚AA碱性电池为参照)
感应距离	正面进入感应: 230mm(±20mm) 白色A4纸为参照
	侧面进入感应: 100mm(±20mm) 白色A4纸为参照
适用水压	0.05-0.7MPa (0.5-7Kg/cm2)
额定流量	4.8±0.3L/m，动态水压0.2MPa下测试
适用安装孔径	Φ32mm-35mm
冷/热进水管径	DN15 (G1/2)
软管长度	600mm
适用水温范围	4-80℃ (40-176° F)
工作环境温度	1-40℃
工作环境湿度	≤95%RH
节水效能	I 级
防水等级	IP56 (防溅水型)
重 量	约2Kg
执行标准	GB18145-2014 CJ/T194-2014

NOTES OF USE

使用注意事项

Do not clean with water instead with clean and dry soft cloth. 请勿用粗糙麻布或铁砂擦洗，请使用柔软、洁净的毛巾。


Do not shake the faucet in case of any damage. 请勿撞击、摇晃龙头，否则易引起故障。

Do not wash with alkaline or acid detergents. 请勿使用强酸碱类、强洗涤剂清洁。

USE EXPOSITION

使用说明

1. Instant water mode (front side sensor) : water is turned on automatically when hands into sensor range and water is turn off when hands leave. Water will stop itself when 1 minute.
2. Right or left side sensor: hands wave 1 time to turn on water, hands wave again to turn off. Water will stop itself when 3 minutes.
3. Rotate the handle to the end of anticlockwise to close the water.
4. Rotate the handle clockwise or anticlockwise to adjust the water temperature according to the indication of cold (blue) and hot (red).
- 1 前感应窗口, 当感应到有手靠近, 则即时出水, 当感应到手离开后停止出水。(1分钟后自动关闭)
- 2 侧感应窗口, 感应一次长时间出水(3分钟后自动关闭), 或者再次感应关闭。
- 3 应急关水: ON方向旋转手动模式, OFF方向旋转自动模式。默认是自动模式(即在OFF方向), 在紧急情况下可以启用手动模式(往ON方向旋转)。
- 4 调节水温: 按照冷 (蓝色)、热 (红色) 指示, 前后旋转调节水温。



MAINTENANCE

维护保养

Cleaning the filter net:
The filter nets of newly installed products are very likely to be blocked by the sands in the pipe. Please screw off the filter net and wash it when the water volume decreases.

Note: The filter net is at the water inlet. Please close triangle valve before take out the filter net.

清洗过滤网:

新安装的产品, 因管道中的沙石等容易在过滤网中产生淤堵, 如果使用中发现出水量减少或不出水时, 请及时旋下过滤网冲洗, 并按原样装回。

注意: 过滤网装在角阀与转接头之间, 取下过滤网前须关闭角阀。

BATTERY CHANGING

更换电池

When the batteries is out of power, the indicate light will flash at an intermittance of 3-4 seconds to note the maintenance department to change batteries.

When there is no power left in the battery, the sensor will shut down the battery valve to avoid wasting water.

Step 1:
Screw off the 4 screws on the cover of the battery box to remove the cover.

Step 2:
Change 4 new No.5 alkaline batteries and install the battery cover.

Note: The polarity of batteries must be correct. Do not mix old and new batteries or batteries of different brands.

更换电池

电池电量低时, 该指示灯每隔3-4秒闪亮一次, 需更换电池。电池电量耗尽时, 感应器将强制关闭电磁阀, 防止水资源浪费。

第一步:
拔出电池盒上盖。

第二步:
换上四节新的5号碱性电池, 安装完毕后照原样装回。

注意: 电池的正负极性必须正确, 新旧不同或不同品牌的电池不能混用。

COMMON TROUBLE SHOOTING

常见故障排除

Anomalies	Possible cause	Solution
No water out	The battery is out of power	Change new batteries
	Blots on the sensing window	Clean the blots
	Water supply stops	Wait for water to come
	The filter net is blocked by debris	Clean the filter net
	The water pressure is not suitable	Reference of technical parameters
Water can't be turned off	Power off (AC. 220V)	Wait for power supply
	The battery is out of power	Change new batteries
	The water pressure is not suitable	Reference of technical parameters
Low water volume	The water pressure is too low	Reference of technical parameters
	The filter net is blocked by debris	Clean the filter net
Short battery life span	Use of low quality batteries	Change for quality and standard batteries
No response	The battery is out of power	Change new batteries
	Power off (AC 220V)	Wait for power supply

异常现象	可能原因	排除方法
不出水	电池电能耗尽	更换新电池
	感应窗有污垢	排除污垢
	停水	等待来水
	过滤网太脏造成淤堵	清洗过滤网
	水压不在适用范围	参考技术参数表
	停电(AC 220V)	等待来电
不关水	电池电能耗尽	更换新电池
	水压不在适用的范围	参考技术参数表
	水压不在适用范围	参考技术参数表
关水后还有少量流水	水压太低	参考技术参数表
	过滤网太脏	清洗过滤网
水量小	水压太低	参考技术参数表
	过滤网太脏	清洗过滤网
电池使用时间短	使用不合规的电池	更换规定电池
不感应	电池电能耗尽	更换新电池
	停电(AC 220V)	等待来电

ONE-YEARWARRANTY

一年有限担保

*Our company has an extensive quality promise to the end customers. Our products proved to be correctly installed and properly used enjoy a maintenance period of 1 year during which any products with quality defects shall be repaired without any charge.

*Quality defects caused by the following factors are not included in the promise:

1) Quality defects caused by improper installation, replacing and repairing are not included in the promise.

2) Products of industrial and commercial use are not included in the promise. However the end customers are included.

3) Quality defects caused by misuse, abuse, carelessness and employment of no our components are not included in the promise.

*Please keep your invoice of our product properly to ensure better service from us.

*The company keep its right of use the latest component for repairing.

*我司对产品的最终用户有广泛的质量保证, 产品在被证明正常安装和使用的前提下, 保修期为1年。

在保修期内对有质量问题的产品免费维修。

*对于在以下行为中产生质量问题的, 不包括在此保证范围内:

1) 因非正常安装、替换、修理及类似的行为中产生的质量问题不包括在此保证范围内。

2) 对于工业和商业用途的产品不包括在此保证范围内, 但此保证会自动延续到此用途的用户手中, 依此类推。

3) 对于误用、滥用、疏忽和使用非我司配件所产生的质量问题不包括在此保证范围内。

*请妥善保管购买我司产品时的发票, 以便我们能更好地为您服务。

*公司保留维修时使用最新配件的权利。