Limpide on the TempoPAD C16

Choose a bank with **CTRL BANK**, then **A** to **D**. Set every knob to **Relative #1**, and each button as marked: Momentary or Toggle. The pads play the synth.

A Oscillators

K1 CC 1 Osc 1 Octave	K2 CC 2 FM	K3 CC 3 Ring	K4 CC 4 Pulse Width
K5 CC 5 Osc 2 Octave	K6 CC 6 Semitone	K7 CC 7 Detune	K8 CC 8 Osc 2 Env Amount
F1 CC 33 Osc 1 level	F2 CC 34 Osc 2 level	F3 CC 35 Noise level	F4 CC 36 Sub level
M1 CC 49 Momentary Previous Preset	M2 CC 52 Momentary Next Preset	M3 CC 55 Momentary Freeze	M4 CC 58 Momentary Hold
S1 CC 50 Toggle free	S2 CC 53 Toggle free	S3 CC 56 Momentary Snapshot	S4 CC 59 Toggle Sub Octave
R1 CC 51 Momentary Osc 1 Waveform	R2 CC 54 Momentary Osc 2 Waveform	R3 CC 57 Toggle Noise Colour	R4 CC 60 Toggle Sub Waveform

B Filter

K1 CC 9 Cutoff	K2 CC 10 Resonance	K3 CC 11 Velocity	K4 CC 12 Key Track
K5 CC 13 Env Amount	K6 CC 14 Mode	K7 CC 15 free	K8 CC 16 free
F1 CC 37 Attack	F2 CC 38 Decay	F3 CC 39 Sustain	F4 CC 40 Release
M1 CC 61 Momentary Previous Preset	M2 CC 64 Momentary Next Preset	M3 CC 67 Momentary Freeze	M4 CC 70 Momentary Hold
S1 CC 62 Toggle free	S2 CC 65 Toggle free	S3 CC 68 Momentary Snapshot	S4 CC 71 Toggle free
R1 CC 63 Toggle Slope	R2 CC 66 Toggle free	R3 CC 69 Toggle free	R4 CC 72 Toggle free

C Amp

K1 CC 17 Voices	K2 CC 18 Glide	K3 CC 19 free	K4 CC 20 free
K5 CC 21 free	K6 CC 22 free	K7 CC 23 free	K8 CC 24 Volume
F1 CC 41 Attack	F2 CC 42 Decay	F3 CC 43 Sustain	F4 CC 44 Release
M1 CC 73 Momentary Previous Preset	M2 CC 76 Momentary Next Preset	M3 CC 79 Momentary Freeze	M4 CC 82 Momentary Hold
S1 CC 74 Toggle free	S2 CC 77 Toggle free	S3 CC 80 Momentary Snapshot	S4 CC 83 Toggle free
R1 CC 75 Toggle free	R2 CC 78 Toggle free	R3 CC 81 Toggle free	R4 CC 84 Toggle free

D LFO & Envelopes

K1 CC 25 LFO 1 Waveform	K2 CC 26 LFO 1 Destination	K3 CC 27 LFO 2 Waveform	K4 CC 28 LFO 2 Destination
K5 CC 29 LFO 1 Depth	K6 CC 30 LFO 1 Rate	K7 CC 31 LFO 2 Depth	K8 CC 32 LFO 2 Rate
F1 CC 45 free	F2 CC 46 free	F3 CC 47 free	F4 CC 48 free
M1 CC 85 Momentary Previous Preset	M2 CC 88 Momentary Next Preset	M3 CC 91 Momentary Freeze	M4 CC 94 Momentary Hold
S1 CC 86 Toggle free	S2 CC 89 Toggle free	S3 CC 92 Momentary Snapshot	S4 CC 95 Toggle free
R1 CC 87 Toggle LFO 1 Retrigger	R2 CC 90 Toggle free	R3 CC 93 Toggle LFO 2 Retrigger	R4 CC 96 Toggle free

On every bank: M1 Previous Preset, M2 Next Preset, M3 Freeze, M4 Hold, S3 Snapshot. Free places stay Toggle, the C16's own setting. All on MIDI channel 1. gijom33.github.io/limpide