Guide\_raspiSerie\_02\_Flash\_Sdcard

Guide#raspiSerie\_02\_FLASH\_CARD

The PI Countdown and Liftoff - The Initial Launch!!! 02 #piSerie

Configuring your PI

Expand rootfs

Basic Commands to Explore Your Pi

- 1. sudo su -
- 2. cat /proc/cpuinfo
- 3. ip addr show eth0
- 4. sudo raspi-config
- 5. sudo reboot
- 6. df / -h
- 7. free -h
- 8. date
- 9. exit
- 10. sudo shutdown -h now

Keeping your System Software Up-To-Date

- 1. sudo apt-get update
- 2. sudo apt-get dist-upgrade

Keeping your System Firmware Up-To-Date

- 1. sudo wget http://goo.gl/1BOfJ -0 /usr/bin/rpi-update && sudo chmod +x
  /usr/bin/rpi-update
- 2. sudo apt-get install git-core
- 3. sudo rpi-update

Wi-Fi Network Setup

- 1. startx
- Double-click on the WiFi Config icon located on the desktop;
- 3. From the Network drop-down menu, select Add;
- 4. Fill out the information for your access point and click on the Add button;

## Guide\_raspiSerie\_02\_Flash\_Sdcard

- 5. Your Wi-Fi adapter will associate immediately with the access point and should receive an IP address as listed under the Current Status tab;
- 6. From the File drop-down menu, select Save Configuration;
- 7. Exit the application and log out of the desktop environment:

exit