
EK-G78SXB User Guide

2016/11/16


G

G78S Breakout Schematic






XBee Breakout Schematic







Front-End Schematic (only available on G76S)








Level Shifter Schematic


























Breakout Pin Definition







Only available on G76S




USB TO TTL

USB TO TTL Driver (<u>FTDI</u> FT230XQ)

Top view




Breakout Pin Definition



G

Component Location



Bottom view

