


Glot MQTT Module Binding




1. Login Page

https://cust00-01.giotgateway.com/giot-mqtt/




2. Input E-mail and Password






3. Let this app access your info




4. Home

1) Modify account password




2) User/Edit






3) First login, click 'Launch MQTT Server' icon.






4) MQTT Information




5. Binding Steps:

1) Binding Page




2) Click '+' symbol






3) Binding /Add






4) Input MAC address and PIN code




5) Press OK button or '+' to add more






Finish module binding




7) Click delete icon to remove bound module



6. Setting





7. Logout

