

GOIP SMS Management Server Manual 1.0

Introduction:


GOIP SMS Management Server is used to control sending message. User can send search or other operations on the web server

Installation Requirements:

Be sure that apache2(or above version), php4(or above version) and mysql4(or above version) has been installed on the Linux system. The software is used UTF-8 character coding. Installation

—, Windows system installation

- 1, install php, mysql and apsche
- 2 decompression the software: http://118.142.51.162/update/goip install-v1.10.4.tgz to the directory of apache server (maybe the default directory is htdocs/ or www/)
- 3. click "import_sql.cmd" in goip\inc, you will see the screen. Then input password of root.(the mysql process should be started up. If "mysql command is not recognized" appeared, you should input database by yourself: click "start-> run", input "cmd" and then input command: mysql installation path/mysql/bin/mysql -uroot -p < apache server directory/goip/inc/goipinit.sql)
- 4, double click "install.cmd" to install
- 5. The default enabled UDP port is 44444.If a firewall installed, please join the trust 44444 UDP port list.
- 6. Input GOIP manager URL: http://your_ip/goip in your brower, user: root password:root
- 7. Click "system management", add ID and password to goip parameter management.
- 8. Open GOIP configuration webpage, fill the parameters in corresponding blank, the default port is 44444
- 9. Create groups and contact, then you can send message
- 10, you should set International Tel number in "System Manage->Provider Manage"



二、Linux system installation

1) Login Linux system as root

input command

wget http://118.142.51.162/update/goip install.tgz

input command

tar -xzvf goip_install-

linux.tgz input command

cd goip_install

input command



./goip_install.sh

2) installation processing as this:

./goip_install.sh (Starting GoIP SMS System install)

Configure httpd config:

Enter the httpd config file PATH:

The default httpd configuration file path is "/etc/httpd/conf/httpd.conf", default press Enter

Choose your Mysql Database version:

4

5

The default mysql version is 4

Import GOIP databased

Input the Mysql root password if the password exists:

Enter your Mysql PATH

The default Mysql path is "/usr/bin/mysql", default press Enter

Copying file to /usr/local/goip

Install finished

- 3) The default enabled UDP port is 44444.If a firewall installed, please join the trust 44444 UDP port list.
- 4) Then restart your httpd.
- 5) Input GOIP manager URL: http://your_ip/goip in your brower, user: root password:root
- 6) Click "system management", add ID and password to goip parameter management.
- 7) Open GOIP configuration webpage, fill the parameters in corresponding blank, the default port is 44444
- 8) Create groups and contact, then you can send message
- 9) you should set International Tel number in "System Manage->Provider Manage"

