


Wire your piezo sensor to the Trinket like so ...



The resistor for the piezo sensor is brown-black-orange-gold (10k0hm)