




Porsche AG, Macan H2 SUV, as from model year 2023



PORSCHE



Note: The maximum possible equipment is shown.

	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Pedestrian protection active system
			Gas strut / Preloaded spring		High strength zone		Zone requiring special attention		
	Battery low voltage		High-voltage battery		High-voltage power cable		Low voltage device that disconnects high voltage		Fuse box disabling high voltage
	Air tank		High voltage component						




Porsche AG, Macan H2 SUV, as from model year 2023

PORSCHE

1. Identification / recognition



The lack of engine noise does not mean that the vehicle is turned off.
Restart is possible until the vehicle is decommissioned.



Equipment-dependent




2. Immobilization / stabilisation / lifting

Immobilizing the vehicle

Actuate electric parking brake



Lifting points





Suitable lifting points

High-voltage battery

Switching off ignition

Press "Start-Stop" button on the instrument panel




3. Disable direct hazards / safety regulations

The high-voltage system is automatically disabled in the event of accidents in which the airbag is triggered. The high-voltage system is de-energised approx. 20 seconds after the disabling.

Disabling high-voltage system

Option 1: from the engine compartment







Porsche AG, Macan H2 SUV, as from model year 2023


PORSCHE



Option 2: from the vehicle rear





Do not touch, cut or open high-voltage components and high-voltage battery!
Wear appropriate protective equipment!




Disconnecting 12-volt battery

Disconnect negative terminal from the body contact point

Disconnecting from charging station (emergency release), left and right



4. Access to the occupants




Glass types

- ① Laminated safety glass
- ② Equipment-dependent: Single-pane safety glass or laminated safety glass
- ③ Equipment-dependent: Single-pane safety glass




The centre airbag is located inside the driver's seat inner backrest padding.

5. Stored energy / liquids / gases / solids



LI ION
800 V



12 V



Porsche AG, Macan H2 SUV, as from model year 2023

PORSCHE



If coolant is leaking from the battery cooling system, there is the risk of a thermal reaction in the high-voltage battery.
Monitor high-voltage battery temperature.



6. In case of fire



Lithium-ion batteries may self-ignite or re-ignite after the fire has been extinguished!
Wear appropriate protective equipment!



7. In case of submersion

After recovering the vehicle from the water, disable the high-voltage system (see section 3) and allow the water to drain. Wear appropriate protective equipment!

8. Towing / transportation / storage



Lithium-ion batteries may self-ignite or re-ignite after the fire has been extinguished!
Wear appropriate protective equipment!



In the case of vehicles involved in an accident or if the HV battery is damaged or unusual: disable high-voltage system (see section 3). Park vehicle a safe distance from buildings and other vehicles (quarantine area).



Do not tow a vehicle involved in an accident on its drive axles.



9. Important additional information

You can find further information on assistance in the event of an accident and recovery of vehicles with high-voltage systems at:

<https://www.vda.de/de/themen/automobilindustrie/standards-und-normung/retten-und-bergen>

10. Explanation of pictograms used



Electric Vehicle



General warning sign



Warning, Electricity



Flammable



Explosive



Corrosives



Hazardous to the human health




Environmental hazard



Bonnet



Boot



Remove smart key



Use thermal Infrared camera



Dangerous voltage



Use water to extinguish the fire