ELEC 221 Lecture 20 Amplitude modulation

Thursday 17 November 2022

Announcements

■ Quiz 9 on Tuesday

We have seen convolution and multiplication properties in a few different contexts now:

The latter is sometimes known as the modulation property.

We have used modulation in a few different contexts already.


On Tuesday we did some simple amplitude modulation:

```
def amplitude_modulation(signal, time_range, carrier_frequency):
    """Apply sinusoidal amplitude modulation.


Args:
        signal (array[float]): The modulating signal.
        time_range (array[float]): The explicit times over which the signal has been sampled (in seconds).
        carrier_frequency (int): The frequency (in Hz) of the carrier signal.


Returns:
        array[float]: The modulated signal.
    """
    return signal * cos_wave(time_range, carrier_frequency)
```

In lecture 10 (and homework 4) we explored how modulation could be leveraged for frequency-selective filtering.




We modeled sampling as multiplication by a periodic impulse train.





We briefly discussed the application of phone signal transmission.




Today

Learning outcomes:

- perform sinusoidal amplitude modulation (AM) and demodulation
- describe the process of frequency-domain multiplexing
- differentiate between double- and single-sideband modulation

Modulation

The process of embedding an information-bearing signal into a second signal. (Extracting the signal: demodulation)



We will discuss two types:

- amplitude modulation (AM) (today)
- frequency modulation (FM) (next time)

Visualization: https://global.oup.com/us/companion.websites/fdscontent/uscompanion/us/static/companion.websites/9780199922963/images/AM_FM.gif

We focus on two types of carrier signals:

complex exponential signal


sinusoidal signal

Complex exponential amplitude modulation

We've already seen what happens with the first one.


Suppose

(set $\theta_c = 0$, we will deal with it later).




Complex exponential amplitude modulation

Consider the Fourier spectrum of both signals:




Complex exponential amplitude modulation


Convolution of the spectra leads to the original spectrum being moved into a different frequency regime.




Demodulation is straightforward.





What if we modulate instead by a sinusoidal signal?





- Any foreseeable problems with this?
- How do we recover the signal?





Let's check the math:

Exercise: sinusoidal amplitude modulation

8.3. Let x(t) be a real-valued signal for which $X(j\omega) = 0$ when $|\omega| > 2{,}000\pi$. Amplitude modulation is performed to produce the signal

$$g(t) = x(t)\sin(2,000\pi t)$$
.

A proposed demodulation technique is illustrated in Figure P8.3 where g(t) is the input, y(t) is the output, and the ideal lowpass filter has cutoff frequency $2,000\pi$ and passband gain of 2. Determine y(t).





Figure P8.3

Exercise: sinusoidal amplitude modulation

Exercise: sinusoidal amplitude modulation



More generally, we need to consider the phases in both the modulating and demodulating signals:


Output after the lowpass filter is

If $\phi_c = \theta_c$ we call this synchronous demodulation. What could go wrong?


Suppose the following is true:

- x(t) is positive
- ullet ω_c is much larger than ω_m


The transmitted signal will look something like this:




Design a system to track the envelope (we won't go into details).





If x(t) is not positive, choose A sufficiently large and add to signal:






Suppose $|x(t)| \le K$. Must have A > K. Then m = K/A is known as the *modulation index*.






(Oppenheim 8.27)



There is inefficiency because we are sending the carrier signal too. Suppose $x(t) = \cos(\omega_m t)$, $\omega_m < \omega_c$ and A + x(t) > 0.

- 1. What is the modulation index m?
- 2. What is the average power as a function of m?
- 3. What is the *efficiency* (ratio of power in sideband to total power)?



What is the modulation index m?

$$y(t) = (A + \cos(\omega_m t))\cos(\omega_c t)$$

What is the average power as a function of m? For periodic signal,


$$P = \frac{1}{T} \int_{T} |y(t)|^2 dt$$


Hint: use Parseval's theorem.


$$y(t) = (A + \cos(\omega_m t))\cos(\omega_c t)$$

What is the efficiency (ratio of power in sideband to total power)?


Suppose we have more than one signal we wish to transmit:









Modulation can help us send them at the same time!



This is called *frequency-division multiplexing*.



How to separate out the channels?




AM radios

See Oppenheim problem 8.36.




This is inefficient...




We are using twice as much bandwidth as we need to!

A modulated signal's spectrum can be divided into upper/lower *sidebands*:




In single-sideband modulation, keep and transmit only one band:





How do you think this is done?

Alternative: "90* phase-shift network"



Exercise: see how this works by analyzing what happens to the spectra of $x_p(t)$, $y_1(t)$, $y_2(t)$, and y(t) in the frequency domain.





Today

Learning outcomes:

- perform sinusoidal amplitude modulation (AM) and demodulation
- describe the process of frequency-domain multiplexing
- differentiate between double- and single-sideband modulation

Oppenheim practice problems: 8.1, 8.2, 8.4, 8.7-8.9, 8.21, 8.22, 8.26, 8.28

For next time

Content:

- pulse-amplitude modulation, frequency modulation
- Quiz 9 on Tuesday

Action items:

1. Assignment 6 (computational) available soon

Recommended reading:

- From this class: Oppenheim 8.0-8.4
- For next class: Oppenheim 8.5-8.9