## RUN THE 16MHZ CLOCK STEPS\_ 3 NHO 8

- (1) USE RECZ
- 3 BYPASS THE PLL
- 3) SPECIFY FRQ IN XTAZ OF RCC
- H) CLEAR POURDNZ TO ACTIVATE PIL
- ENABLE/CONFIGURE CLOCK DIVIDER

  USING SYSDIVZ

  WAIT FOR PLL TO STABILITE

  CONNECT/ENABLE PPL (CLEAR BYPASSI)