

3.1 Equipment

Item	Requirement	Why
VSX3000 sensor on a rigid stand	Stand mechanically separate from the robot base, on an isolated floor or table	Prevents robot motion from moving the sensor
6-axis robot	Repeatability ≤ 0.05 mm (ISO 9283); payload above the heaviest target plus adapter	Commanded, repeatable target poses
Quick-change target adapter	Dowel-pinned, re-mount repeatability ≤ 0.02 mm	Targets can be swapped without re-registering
Enclosure or blackout curtains, IR light meter	Ambient IR held constant and logged	Ambient IR changes the noise level
Temperature loggers (sensor housing and air)	1 sample/min	For drift attribution
Capture PC	VSX3000 SDK, LRVisionLibs MatCloud reader, robot interface that logs the actual pose read back from the robot	Synchronized capture and logging