

Glorb broom — receiver boards (one SRx4 per 2×4)

front-left OPEN (driver sightline) · front is the TOP edge · bird's-eye view from ABOVE

EVERY BOARD: ID dial → A · all 4 DIP switches UP (Only/Last) · one cat5 per board, nothing chained
FRONT (front-left open · F = front-right)



Zones:

- A Left-Front (port 1/2)
- D Right-Back (port 7/8)

- B Left-Back (port 3/4)
- E Right-Front (port 9/10)

- C Back (port 5/6)
- F Front-Right (port 11)

Board A1

tubes L01–L14

cat5 → K128D jack 1-4 (port 1)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	L01	1–123
A · out 2	L02	124–246
A · out 3	L03	247–369
A · out 4	L04	370–492
B · out 1	L05	493–615
B · out 2	L06	616–738
B · out 3	L07	739–861
B · out 4	L08	862–984
C · out 1	L09	985–1107
C · out 2	L10	1108–1230
C · out 3	L11	1231–1353
C · out 4	L12	1354–1476
D · out 1	L13	1477–1599
D · out 2	L14	1600–1722
D · out 3-4 — unused		

Board A2

tubes L15–L28

cat5 → K128D jack 5-8 (port 2)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	L15	1723–1845
A · out 2	L16	1846–1968
A · out 3	L17	1969–2091
A · out 4	L18	2092–2214
B · out 1	L19	2215–2337
B · out 2	L20	2338–2460
B · out 3	L21	2461–2583
B · out 4	L22	2584–2706
C · out 1	L23	2707–2829
C · out 2	L24	2830–2952
C · out 3	L25	2953–3075
C · out 4	L26	3076–3198
D · out 1	L27	3199–3321
D · out 2	L28	3322–3444
D · out 3-4 — unused		

Board B1

tubes L29–L42

cat5 → K128D jack 9-12 (port 3)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	L29	3445–3567
A · out 2	L30	3568–3690
A · out 3	L31	3691–3813
A · out 4	L32	3814–3936
B · out 1	L33	3937–4059
B · out 2	L34	4060–4182
B · out 3	L35	4183–4305
B · out 4	L36	4306–4428
C · out 1	L37	4429–4551
C · out 2	L38	4552–4674
C · out 3	L39	4675–4797
C · out 4	L40	4798–4920
D · out 1	L41	4921–5043
D · out 2	L42	5044–5166
D · out 3-4 — unused		

Board B2

tubes L43–L56

cat5 → K128D jack 13-16 (port 4)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	L43	5167–5289
A · out 2	L44	5290–5412
A · out 3	L45	5413–5535
A · out 4	L46	5536–5658
B · out 1	L47	5659–5781
B · out 2	L48	5782–5904
B · out 3	L49	5905–6027
B · out 4	L50	6028–6150
C · out 1	L51	6151–6273
C · out 2	L52	6274–6396
C · out 3	L53	6397–6519
C · out 4	L54	6520–6642
D · out 1	L55	6643–6765
D · out 2	L56	6766–6888
D · out 3-4 — unused		

Board C1

tubes B01–B12

cat5 → K128D jack 17-20 (port 5)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	B01	6889–7011
A · out 2	B02	7012–7134
A · out 3	B03	7135–7257
A · out 4	B04	7258–7380
B · out 1	B05	7381–7503
B · out 2	B06	7504–7626
B · out 3	B07	7627–7749
B · out 4	B08	7750–7872
C · out 1	B09	7873–7995
C · out 2	B10	7996–8118
C · out 3	B11	8119–8241
C · out 4	B12	8242–8364

Board C2

tubes B13–B24

cat5 → K128D jack 21-24 (port 6)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	B13	8365–8487
A · out 2	B14	8488–8610
A · out 3	B15	8611–8733
A · out 4	B16	8734–8856
B · out 1	B17	8857–8979
B · out 2	B18	8980–9102
B · out 3	B19	9103–9225
B · out 4	B20	9226–9348
C · out 1	B21	9349–9471
C · out 2	B22	9472–9594
C · out 3	B23	9595–9717
C · out 4	B24	9718–9840

Board D1

tubes R01–R14

cat5 → K128D jack 25-28 (port 7)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	R01	9841–9963
A · out 2	R02	9964–10086
A · out 3	R03	10087–10209
A · out 4	R04	10210–10332
B · out 1	R05	10333–10455
B · out 2	R06	10456–10578
B · out 3	R07	10579–10701
B · out 4	R08	10702–10824
C · out 1	R09	10825–10947
C · out 2	R10	10948–11070
C · out 3	R11	11071–11193
C · out 4	R12	11194–11316
D · out 1	R13	11317–11439
D · out 2	R14	11440–11562
D · out 3-4 — unused		

Board D2

tubes R15–R28

cat5 → K128D jack 29-32 (port 8)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	R15	11563–11685
A · out 2	R16	11686–11808
A · out 3	R17	11809–11931
A · out 4	R18	11932–12054
B · out 1	R19	12055–12177
B · out 2	R20	12178–12300
B · out 3	R21	12301–12423
B · out 4	R22	12424–12546
C · out 1	R23	12547–12669
C · out 2	R24	12670–12792
C · out 3	R25	12793–12915
C · out 4	R26	12916–13038
D · out 1	R27	13039–13161
D · out 2	R28	13162–13284
D · out 3-4 — unused		

Board E1

tubes R29–R42

cat5 → K128D jack 33-36 (port 9)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	R29	13285–13407
A · out 2	R30	13408–13530
A · out 3	R31	13531–13653
A · out 4	R32	13654–13776
B · out 1	R33	13777–13899
B · out 2	R34	13900–14022
B · out 3	R35	14023–14145
B · out 4	R36	14146–14268
C · out 1	R37	14269–14391
C · out 2	R38	14392–14514
C · out 3	R39	14515–14637
C · out 4	R40	14638–14760
D · out 1	R41	14761–14883
D · out 2	R42	14884–15006
D · out 3-4 — unused		

Board E2

tubes R43–R56

cat5 → K128D jack 37-40 (port 10)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	R43	15007–15129
A · out 2	R44	15130–15252
A · out 3	R45	15253–15375
A · out 4	R46	15376–15498
B · out 1	R47	15499–15621
B · out 2	R48	15622–15744
B · out 3	R49	15745–15867
B · out 4	R50	15868–15990
C · out 1	R51	15991–16113
C · out 2	R52	16114–16236
C · out 3	R53	16237–16359
C · out 4	R54	16360–16482
D · out 1	R55	16483–16605
D · out 2	R56	16606–16728
D · out 3-4 — unused		

Board F1

tubes F01–F12

cat5 → K128D jack 41-44 (port 11)

ID DIAL: A · DIPs: all 4 UP (Only/Last)

group · out → tube	channels	
A · out 1	F01	16729–16851
A · out 2	F02	16852–16974
A · out 3	F03	16975–17097
A · out 4	F04	17098–17220
B · out 1	F05	17221–17343
B · out 2	F06	17344–17466
B · out 3	F07	17467–17589
B · out 4	F08	17590–17712
C · out 1	F09	17713–17835
C · out 2	F10	17836–17958
C · out 3	F11	17959–18081
C · out 4	F12	18082–18204