LAB 3: Writing a small application in assembly language.

This lab is a two-week lab.

This lab consists of the following tasks:

- Write a 48-bit unsigned multiplication subroutine in PIC24F assembly language.
- Write a subroutine which implements the algorithm for the rand48 pseudorandom number generators in PIC24F assembly language (the methodology is given below.)
- Write setup code in PIC24Fassembly language to initialize bits RB2, RB3, ..., RB9 as outputs.
- Write code to initialize the pseudo-random number generator (the methodology is given below) in PIC24F assembly language.
- Debug and simulate your code.
- Wire up the circuit as shown.
- Demonstrate that you have done this correctly by producing, on the output, the proper sequence of pseudo-random numbers (or at least their least-significant bytes).

You program should initially start with all LED's off. Then, for each press of the switch, it should display a pattern on the LED's indicating, in binary (with off representing 1, and on representing 0, or vice versa as you choose, so long as you document it) the number it generated. You'll have to debounce your switch properly to make this happen.

Before you come to lab you should build the project, and, using the MPLABX simulator, you should have spent some time simulating the operation of the program so that you are comfortable that it should work. While some people may be able to accomplish all that is required in the 6 hours in lab, the time required for completion of software has a huge variance. Unless you are certain you can do the job in 6 hours, I suggest you do as much as you can before lab starts.

The lab TA has the sequence of pseudo-random numbers your circuit should display and will immediately be able to tell if you have succeeded or failed.

The test circuit for this lab consists of hooking up the power and ground, the two capacitors, plus a resistor to tie the reset pin high (inactive), as well as 8 LED's and current-limiting resistors and the switch. The schematic shows an additional connector (SV1), but that is optional. This circuit will be used for the fourth lab as well.

1. Turn in a printed copy of your code.

- 2. Use the simulator and its stopwatch to measure the time required to compute the random number.
- $3. \ \, \text{Also}$ measure the time required for the 48-bit multiply.

Remember, Always put decoupling capacitors in your circuit, even if not shown!

rand 48 functions work by generating a sequence of 48-bit integers, X_i , according to the linear congruential formula:

}

 $X_{n+1}=(a\times X_n+c)\ mod\ m,$ where $n\geq 0$ The parameter $m=2^{48},$ hence 48-bit integer arithmetic is performed. a and c are given by:

```
a = 0x5DEECE66D;
    c = 11;
   X_0 is initialized using setseed
48, given here as a C function:
void setSeed(unsigned long int seed)
    seedx = seed;
    seedx = seedx << 16;</pre>
    seedx = seedx + 0x330E;
```

By default, set Seed is called at initialization with seed = 1.