## First Class Levers

Load fulcrum 
$$F_E = 2.0N$$

$$F_E = \frac{F_L \times d_L}{d_E}$$

$$F_E = \frac{F_L \times d_L}{d_E}$$

$$F_E = \frac{10.0 \times 10.0}{50.0}$$

$$F_E = 2.0N$$